

Using Pc Cards; Hot Swapping - Toshiba L20/L25 User Manual

Toshiba user's guide notebook computer l20/l25

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256



•

[Table of Contents](#)

•

Bookmarks



Using PC Cards

For information on inserting or removing a PC Card, see ["Inserting and removing PC Cards" on page](#)

Hot swapping

With PC Cards, you can replace one PC Card with another while the computer is on. This is called "hot swapping."

Hot swapping precautions

Although you can insert a PC Card at any time, remember not to remove a card while it is in use. Otherwise, you could lose

valuable information. For example:

Do not remove a hard disk card while the system is accessing it.

Do not remove a network card while you are connected to a network



Do not remove a SCSI card while any of the SCSI devices connected to it are operating.

Before removing a PC Card, stop it by clicking the Safely Remove Hardware icon on the System tray. After the PC Card is stopped, it is safe to remove.

Exploring Your Computer's Features

TECHNICAL NOTE: For PCMCIA-compatible PC Cards, check the package to make sure they conform to the PCMCIA 2.1 standard (or later). Other cards may work with your computer, but are likely to be much more difficult to set up and use.

Using PC Cards

140.

ManualsLib.com

141

[Previous Page](#)
[Next Page](#)

1
...
140
141
142
143

Related Manuals for Toshiba L20/L25

[Laptop Toshiba Satellite L20 Series Maintenance Manual](#)

Personal computer (264 pages)

[Laptop Toshiba Satellite L20 Series User Manual](#)

(190 pages)

[Laptop Toshiba Satellite L20-SP119 User Manual](#)

Portable personal computer (178 pages)

[Laptop Toshiba Satellite L25-S119 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1192 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1193 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1194 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1195 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1196 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S121 Specifications](#)

Toshiba satellite l25-s121: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1215 Specifications](#)

Toshiba satellite l25-s1215: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1216 Specifications](#)

Toshiba satellite l25-s1216: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1217 Specifications](#)

Toshiba satellite l25-s1217: specifications (10 pages)

[Laptop Toshiba Satellite L20-S310TD Specifications](#)

Toshiba satellite l20-s310td: specifications (7 pages)

[Laptop Toshiba L2-S022 User Manual](#)

L2-s022 user's guide (260 pages)

[Laptop Toshiba Tecra L2-S022 Specifications](#)

Toshiba tecra l2-s022: specifications (7 pages)

Related Content for Toshiba L20/L25

[Tecra S1 Series Inserting And Removing Pc Cards](#)

Toshiba Tecra S1 Series

[Satellite 2410 Series Inserting Pc Cards](#)

Toshiba Satellite 2410 Series

[Portege 2010 Pc Cards](#)

TOSHIBA Portege 2010

[TECRA A6 Pc Cards And Express Cards](#)

Toshiba TECRA A6

[Satellite A205 Series Using Pc Cards](#)

Toshiba Satellite A205 Series

[Portege 2010 Using Pc Cards](#)

Toshiba Portege 2010

[Satellite A35 Series Using Pc Cards](#)

Toshiba Satellite A35 Series

[Tecra 500CS What Do Pc Cards Do](#)

Toshiba Tecra 500CS

This manual is also suitable for:

[L20-s310tdL25-s119L25-s1192L25-s1193L25-s1194L25-s1195](#) ... [Show all](#)