

Sound System Problems; Pc Card Problems - Toshiba L20/L25 User Manual

Toshiba user's guide notebook computer l20/l25

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256



•

[Table of Contents](#)

•

Bookmarks



178

If Something Goes Wrong

Resolving a hardware conflict

If the problem is with a data CD or DVD, refer to the software's documentation and check that the hardware configuration meets the program's needs.

The disc will not come out of the drive when you

click

the eject button on the screen.

Press the button on the DVD-ROM drive itself. For additional

information see

[tray does not slide out." on page](#)

Sound system problems

You do not hear any sound from the computer.

Adjust the volume control.

Try pressing

If you are using external headphones or speakers, check that

they are securely connected to your computer.

The computer emits a loud, high-pitched noise.

This is feedback between the microphone and the speakers. It

occurs in any sound system when input from a microphone is

fed to the speakers and the speaker volume is too loud.

Adjust

the volume control.

PC Card problems

PC Cards (PCMCIA-compatible) include many types of devices, such as a removable hard disk, additional memory,

or a pager.

Most PC Card problems occur during installation and setup

of new cards. If you are having trouble getting one or more of

these devices to work together, several sections in this chapter

may apply.

Resource conflicts can cause problems when using PC Cards.

See

["Resolving hardware conflicts on your own" on page](#)

164.

["You press the disc eject button, but the drive to see if volume mute is disabled.](#)

Fn + Esc

177.

[Previous Page](#)
[Next Page](#)

1

...

177

178

179

180

Related Manuals for Toshiba L20/L25

[Laptop Toshiba Satellite L20 Series Maintenance Manual](#)

Personal computer (264 pages)

[Laptop Toshiba Satellite L20 Series User Manual](#)

(190 pages)

[Laptop Toshiba Satellite L20-SP119 User Manual](#)

Portable personal computer (178 pages)

[Laptop Toshiba Satellite L25-S119 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1192 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1193 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1194 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1195 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1196 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S121 Specifications](#)

Toshiba satellite l25-s121: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1215 Specifications](#)

Toshiba satellite l25-s1215: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1216 Specifications](#)

Toshiba satellite l25-s1216: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1217 Specifications](#)

Toshiba satellite l25-s1217: specifications (10 pages)

[Laptop Toshiba Satellite L20-S310TD Specifications](#)

Toshiba satellite l20-s310td: specifications (7 pages)

[Laptop Toshiba L2-S022 User Manual](#)

L2-s022 user's guide (260 pages)

[Laptop Toshiba Tecra L2-S022 Specifications](#)

Toshiba tecra l2-s022: specifications (7 pages)

Related Content for Toshiba L20/L25

[Portege 2010 Sound System Problems](#)

Toshiba Portege 2010

[Satellite A35 Series Sound System Problems](#)

Toshiba Satellite A35 Series

[Qosmio X70-A series Sound System Problems](#)

Toshiba Qosmio X70-A series

[Satellite L550 Series Sound System Problems](#)

Toshiba Satellite L550 Series

[TECRA A50 series Sound System Problems](#)

Toshiba TECRA A50 series

[Satellite T210 Series Sound System Problems](#)

Toshiba Satellite T210 Series

[Satellite P200 Series Sound System Problems](#)

Toshiba Satellite P200 Series

[Qosmio X300 Series Sound System Problems](#)

Toshiba Qosmio X300 Series

This manual is also suitable for:

[L20-s310tdL25-s119L25-s1192L25-s1193L25-s1194L25-s1195](#) ... [Show all](#)