




# If Something Goes Wrong - Toshiba SATELLITEPRO S300 User Manual

Toshiba laptop user manual



1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56



•

[Table of Contents](#)

•

## Bookmarks







## **If something goes wrong**

---

### **Problems that are easy to fix**

#### **Your program stops responding.**

If you are working with a program that suddenly freezes all operations, chances are the program has stopped responding. You can exit the failed program without shutting down the operating system or closing other programs.

To close a program that has stopped responding:

**1**

Press

## **Task Manager.**

The Windows

**2**

Click the Applications tab.

If a program has stopped responding, the words "not responding" appear beside its name in the list.

**3**

Select the program you want to close, then click End Task. Closing the failed program should allow you to continue working. If it does not, continue with the next step.

**4**

Close the remaining programs one by one by selecting the program name, then End Task.

To power off your computer:

**1**

Click Start, and then click the arrow next to the Lock button in the lower-right part of the Start menu.

The Shut Down menu appears.

Start

*(Sample Image) Shut Down menu*

**2**

Select Shut Down.

The computer shuts down completely.

,

, and

simultaneously (once), then click Start

Ctrl

Alt

Del

®

Task Manager window appears Photo Gallery



Connect To

## If something goes wrong

Arrow

Shut Down Menu

---

# 47

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
44  
45  
46  
47  
48  
49  
50  
51

Quick Links:

[Table of Contents](#)

[Introduction](#)

[Learning the Basics](#)

[If Something Goes Wrong](#)

[Features and Specifications](#)

[Index](#)

## Related Manuals for Toshiba SATELLITEPRO S300

[Laptop Toshiba Satellite Pro S300 Maintenance Manual](#)

(464 pages)

[Laptop Toshiba S300-EZ1511 User Manual](#)

S300-ez1511 user's guide (251 pages)

[Laptop Toshiba TECRA A10 Series User Manual](#)

(246 pages)

[Laptop Toshiba PTMB3U-00X00X User Manual](#)

User manual (242 pages)

[Laptop Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz User Manual](#)

Toshiba user's guide for satellite s300/s300m (windows vista) (242 pages)

[Laptop Toshiba TECRA A10 Satellite Pro S300 Series User Manual](#)

(242 pages)

[Laptop Toshiba TECRA A10/S10/M10/SATELLITEPRO S300 TECRA S10 User Manual](#)

Vizio mouse user manual (240 pages)

[Laptop Toshiba Satellite Pro S300-EZ1511 Specifications](#)

Toshiba satellite pro s300-ez1511: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ1513 Specifications](#)

Toshiba satellite pro s300-ez1513: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ2502 Specifications](#)

Toshiba satellite pro s300-ez2502: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-S1001 Specifications](#)

Toshiba satellite pro s300-s1001: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-S2503 Specifications](#)

Toshiba satellite pro s300-s2503: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300M-EZ2402 Specifications](#)

Toshiba satellite pro s300m-ez2402: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300M-EZ2421 Specifications](#)

Toshiba satellite pro s300m-ez2421: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300M-S2403 Specifications](#)

Toshiba satellite pro s300m-s2403: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300L-SP5919 Specifications](#)

Toshiba satellite pro s300l-sp5919: specifications (3 pages)

## Related Content for Toshiba SATELLITEPRO S300

[Satellite P25 Series If Something Goes Wrong](#)

Toshiba Satellite P25 Series

[Portege 3500 Series If Something Goes Wrong](#)

Toshiba Portege 3500 Series

[Satellite 1955 Series If Something Goes Wrong](#)

Toshiba Satellite 1955 Series

[Satellite 5205 Series If Something Goes Wrong](#)

Toshiba Satellite 5205 Series

[Satellite A60 Series If Something Goes Wrong](#)

Toshiba Satellite A60 Series

[Tecra S1 Series If Something Goes Wrong](#)

Toshiba Tecra S1 Series

[Satellite 2410 Series If Something Goes Wrong](#)

Toshiba Satellite 2410 Series

[Portege X20W-D If Something Goes Wrong](#)

Toshiba Portege X20W-D

This manual is also suitable for:

[Satellite pro s300-ez1511](#)[Satellite pro s300-ez1512](#)[Satellite pro s300-ez1513](#)[Satellite pro s300-ez1514](#)[Satellite pro s300-ez2501](#)[Satellite pro s300-ez2502](#) ... [Show all](#)