

User Password - Toshiba PORTABLE PERSONAL COMPUTER L500 User Manual

Toshiba personal computer user manual


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



L500/L505/L500D/L505D

General

This window displays the BIOS version and contains two buttons:

Default

About

Setup

This field displays BIOS Version and date.

When finish BIOS update, please restart your computer and press F2 into BIOS setup manual and load BIOS default one time.

Password

User Password

This option allows you to set or reset the user password for power on.

Not Registered

Registered

To enter a user password:

1. Select Registered to display the following prompt:

Enter a password of up to 8 characters. The character string you enter is displayed as a string of asterisks. For example, if you enter a password consisting of four characters, the display is shown as:

2. Click the OK button. The following message appears, allowing you to verify the password.

3. If character strings match, the password is registered click OK button.

If they do not match, the following message appears. You must repeat from step 1.



To delete a user password:

1. Select Not Registered to display the following prompt:

2. Enter the currently registered password. The character string you enter is displayed as a string of asterisks.

7-2

Return all HW Setup values to the factory settings.

Display the HW Setup version.

Changes or remove the password. (Default)

Sets the password. A dialogue box will appear to allow you to set the password.

Enter Password:

Enter Password: ****

Verify Password:

Entry Error!!!

Enter Password:

Enter Password: ****

User's Manual

[Previous Page](#)
[Next Page](#)

1

...

113

114

115

116

Quick Links:

[Equipment Checklist](#)

[Features](#)

[Left Side](#)

Chapters

[Table of Contents](#) 12

[Pointing Device](#) 186

Related Manuals for Toshiba PORTABLE PERSONAL COMPUTER L500

[Laptop Toshiba L500-ST2521 User Manual](#)

L500-st2521 user's guide (234 pages)

[Laptop Toshiba Satellite L505 Manual Del Usuario](#)

User guide 2 (231 pages)

[Laptop Toshiba Satellite L550 series User Manual](#)

(218 pages)

[Laptop Toshiba Satellite L500 User Manual](#)

(214 pages)

[Laptop Toshiba Satellite L505-GS5035 User Manual](#)

Portable personal computer (192 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite L500D Maintenance Manual](#)

(246 pages)

[Laptop Toshiba Satellite L550-ST5707 Resource Manual](#)

Toshiba satellite I550-st5707: reference guide (60 pages)

[Laptop Toshiba Satellite L505D-S5986 Specifications](#)

Toshiba satellite I505d-s5986: specifications (4 pages)

[Laptop Toshiba Satellite L505D-S5994 Specifications](#)

Toshiba satellite I505d-s5994: specifications (4 pages)

[Laptop Toshiba Satellite A505-S5993 Specifications](#)

Toshiba satellite a505-s5993: specifications (4 pages)

[Laptop Toshiba PSLU0U-0MX035 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite L505-ES5015 Specifications](#)

Toshiba satellite I505-es5015: specifications (4 pages)

[Laptop Toshiba Satellite L505-S5997 Specifications](#)

Toshiba satellite I505-s5997: specifications (4 pages)

[Laptop Toshiba L505-SP6015L Product Specification](#)

Toshiba laptop user manual (3 pages)

[Laptop Toshiba SATELLITE L505-S6951 User Manual](#)

Toshiba laptop user manual (3 pages)

Related Content for Toshiba PORTABLE PERSONAL COMPUTER L500

[SATELLITE R850 User Password](#)

Toshiba SATELLITE R850

[NB500 User Password](#)

Toshiba NB500

[Satellite L630 Series User Password](#)

Toshiba Satellite L630 Series

[Satellite Using A User Password](#)

Toshiba Satellite

[Satellite P500 User Password](#)

Toshiba Satellite P500

[Satellite L500 User Password](#)

Toshiba Satellite L500

[Satellite Pro R50-B Series User Password](#)

[Toshiba Satellite Pro R50-B Series](#)

[Satellite Pro Series Using A User Password](#)

[Toshiba Satellite Pro Series](#)

This manual is also suitable for:

[L505dL500dL505Satellite a505-s5993Satellite I505-es5015Satellite I505-s5997](#) ... [Show all](#)