

Left Side - Toshiba PORTABLE PERSONAL COMPUTER L500 User Manual

Toshiba personal computer user manual


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



L500/L505/L500D/L505D

Keep foreign metal objects, such as screws, staples and paper clips, out of the Bridge media slot. Foreign metal objects can create a short circuit, which can cause damage and fire, possibly resulting in serious injury.



Left side

The following figure shows the computer's left side.

1. Cooling vents
2. External monitor port
3. LAN jack

*4. HDMI out port

* Depending on the model you purchased.

Cooling vents

Do not block the cooling vents. Keep foreign metal objects, such as screws, staples and paper clips, out of the cooling vents. Foreign metal objects can create a short circuit, which can cause damage and fire, possibly resulting in serious injury.



External monitor port

LAN jack

Do not connect any cable other than a LAN cable to the LAN jack. It could cause damage or malfunction.

Do not connect the LAN cable to a power supply. It could cause damage or malfunction.

2-2

1

Figure 2-2 The left side of the computer

The cooling vents help keep the processor from overheating.

This port allows you to connect an external monitor to the computer.

This jack lets you connect to a LAN. The adaptor has built-in support for Ethernet LAN

(10 megabits per second, 10BASE-T) and Fast Ethernet LAN (100 megabits per second, 100BASE-TX). The LAN has two indicators.

Refer to Chapter 4,

2

3

4

5

5. eSATA/USB combo port

6. Microphone jack

7. Headphone jack




Operating

Basics, for details.

6

7

User's Manual



ManualsLib.com

[Previous Page](#)
[Next Page](#)

1
...
33
34
35
36
37
38
39
40

Quick Links:

[Equipment Checklist](#)

[Features](#)

[Left Side](#)

Chapters

[Table of Contents](#) 12

[Pointing Device](#) 186

Related Manuals for Toshiba PORTABLE PERSONAL COMPUTER L500

[Laptop Toshiba L500-ST2521 User Manual](#)

L500-st2521 user's guide (234 pages)

[Laptop Toshiba Satellite L505 Manual Del Usuario](#)

User guide 2 (231 pages)

[Laptop Toshiba Satellite L550 series User Manual](#)

(218 pages)

[Laptop Toshiba Satellite L500 User Manual](#)

(214 pages)

[Laptop Toshiba Satellite L505-GS5035 User Manual](#)

Portable personal computer (192 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite L500D Maintenance Manual](#)

(246 pages)

[Laptop Toshiba Satellite L550-ST5707 Resource Manual](#)

Toshiba satellite I550-st5707: reference guide (60 pages)

[Laptop Toshiba Satellite L505D-S5986 Specifications](#)

Toshiba satellite I505d-s5986: specifications (4 pages)

[Laptop Toshiba Satellite L505D-S5994 Specifications](#)

Toshiba satellite I505d-s5994: specifications (4 pages)

[Laptop Toshiba Satellite A505-S5993 Specifications](#)

Toshiba satellite a505-s5993: specifications (4 pages)

[Laptop Toshiba PSLU0U-0MX035 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite L505-ES5015 Specifications](#)

Toshiba satellite I505-es5015: specifications (4 pages)

[Laptop Toshiba Satellite L505-S5997 Specifications](#)

Toshiba satellite I505-s5997: specifications (4 pages)

[Laptop Toshiba L505-SP6015L Product Specification](#)

Toshiba laptop user manual (3 pages)

[Laptop Toshiba SATELLITE L505-S6951 User Manual](#)

Toshiba laptop user manual (3 pages)

Related Content for Toshiba PORTABLE PERSONAL COMPUTER L500

[Satellite Pro R50-C Series Left Side](#)

Toshiba Satellite Pro R50-C Series

[Satellite L40-C Series Left Side](#)

Toshiba Satellite L40-C Series

[Satellite U930 Series Left Side](#)

Toshiba Satellite U930 Series

[Tecra A40 C Series Left Side](#)

Toshiba Tecra A40 C Series

[Satellite Radius 15 P50W-C Left Side](#)

Toshiba Satellite Radius 15 P50W-C

[C70-A Series Left Side](#)

Toshiba C70-A Series

[PT930 Left Side](#)

Toshiba PT930

[Satellite Pro R50-D Series Left Side](#)

Toshiba Satellite Pro R50-D Series

This manual is also suitable for:

[L505dL500dL505Satellite a505-s5993Satellite I505-es5015Satellite I505-s5997](#) ... [Show all](#)