Connecting A Dtv Receiver/Set-Top Box With Component Video And A Vcr - Toshiba 43H71 Owner's Manual

Toshiba projection television owner's manual

18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			

Table of Contents


•

Troubleshooting

•

Bookmarks

•



Connecting a DTV receiver/set-top box with component video and a VCR

This connection allows you to watch DTV (digital TV broadcast), VCR, and TV programs, and record DTV and TV programs. You can record from one source while watching a program from another source.

Your TV has ColorStream (component video) inputs. Connecting your TV to a component video-compatible DTV receiver can greatly enhance picture quality and realism.

You will need:

- one coaxial cable
- three pairs of audio cables (two single and one pair of audio
- cables for a mono VCR)
- two video cables

 one set of ColorStream (component video) cables (one S-video cable for a non-ColorStream DTV receiver; see notes at right)
Stereo VCR

From antenna IN from ANT OUT to TV TV S-VIDEO VIDEO L/ MONO AUDIO R VIDEO-1 VIDEO-2 From DTV antenna Satelite IN S-VIDEO DTV receiver with component video VIDEO AUDIO OUT L Y COMPONENT VIDEO VIDEO OUT

Note:

For the highest possible picture quality, use ColorStream (component video) cables between the TV and DTV receiver. You can connect the ColorStream cables from the DTV receiver to either ColorStream jack on the TV (HD1 or HD2).


The ColorStream HD1 and HD2 jacks can be used with Progressive (480p) and Interlace (480i,1080i) scan systems.

If your DTV receiver is not ColorStreamcompatible, use the S-video connections (both audio and video) instead of the ColorStream connections. Do not connect both S-video and ColorStream cables between the TV and DTV receiver at the same time.

To record from the DTV receiver, set the VCR to Line IN. To monitor recording from the DTV receiver, set the VCR to Line IN, and set the TV to Video-1.

Caution:

The unauthorized recording of television programs, videotapes, DVDs, and other materials may infringe upon the provisions of



, copyright laws.

L R 9

Table of Contents

Previous Page Next Page

Related Manuals for Toshiba 43H71

TV Toshiba 43HX71 Service Manual (102 pages) Projection TV Toshiba 43H71 Owner's Manual (53 pages) TV Toshiba 53HX71 Service Manual (8 pages) Projection TV Toshiba 43H72 Owner's Manual Toshiba owner's manual projection television 43h72, 50h72 (56 pages) Projection TV Toshiba 43H72 Specifications Theaterview hd (2 pages) Projection TV Toshiba 43HX71 Owner's Manual Toshiba owner's manual projection television 43hx71, 53hx71 (56 pages) Projection TV Toshiba 43A61 Owner's Manual Projection television (52 pages) Projection TV Toshiba 43A10 Owner's Manual Colorstream projection television (47 pages) Projection TV Toshiba COLORSTREAM 43A10 Owner's Manual (47 pages) Projection TV Toshiba 43H70 Owner's Manual Colorstream projection television (48 pages) Projection TV Toshiba COLORSTREAM 43A61 Owner's Manual (53 pages) Projection TV Toshiba 43AX60 Owner's Manual Colorstream projection television (54 pages) Projection TV Toshiba COLOASTREAM 43AX60 Owner's Manual (54 pages) Projection TV Toshiba 50PH46P Service Manual Wh4 chassis (78 pages) Projection TV Toshiba 43PH46P Service Manual (78 pages) Projection TV Toshiba 50HX70 Owner's Manual Colorstream projection television (56 pages)

Related Content for Toshiba 43H71

TheaterWide 52HM84 Connecting A Dtv Receiver/Set-Top Box With Colorstream (Component Video) And A Vcr Toshiba TheaterWide 52HM84 46H83 Connecting A Dtv Receiver/Set-Top Box With Colorstream ® (Component Video) And A Vcr Toshiba 46H83 43HX71 Connecting A Dtv Receiver/Set-Top Box (With Or Without Component Video) And A Vcr Toshiba 43HX71 43H72 Connecting A Dtv Receiver/Set-Top Box With Colorstream® (Component Video) And A Vcr Toshiba 43H72 42H83 Connecting A Dtv Receiver/Set-Top Box With Component Video And A Vcr Toshiba 42H83 65H14 Connecting A Dtv Receiver/Set-Top Box With Colorstream (Component Video) And A Vcr Toshiba 65H14 62HM14 Connecting A Dtv Receiver/Set-Top Box With Colorstream (Component Video) And A Vcr Toshiba 62HM14 52HMX85 Connecting A Dtv Receiver/Set-Top Box With Colorstream (Component Video) And A Vcr Toshiba 52HMX85

This manual is also suitable for:

53h7161h71