



Toshiba STRATA CIX-CTX-QRG-VB VERSION B1 Quick Reference Manual

Dkt / ipt telephone

1
2
3
4
5
6
7
8
9
10
11
12
Table Of Contents
13

--

-

[Table of Contents](#)

•

Bookmarks

--

Quick Links

[1 What's My Line](#)

[2 Which Outgoing/Incoming Call Features Do I Have](#)

[3 Voice Mail Call Monitor](#)

[4 Flexible Button Codes](#)

[Download this manual](#)



STRATA

TOSHIBA
CIX/CTX

DKT / IPT Telephone

Quick Reference Guide

Business Telephones

Helping You

TOSHIBA

Communicate Better

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba STRATA CIX-CTX-QRG-VB VERSION B1

[Telephone System Toshiba Strata CTX Programming Manual](#)

Digital business telephone systems (533 pages)

[Software Toshiba Strata CIX Programming Manual](#)

Application release 5 (248 pages)

[Telephone Toshiba STRATA CIX User Manual](#)

Ipt/dkt telephone (179 pages)

[Telephone Toshiba CTX IPT/DKT User Manual](#)

Strata cix and ctx ipt/dkt telephone (171 pages)

[Telephone Toshiba DKT3220-SD - Digital Phone - Charcoal User Manual](#)

Ipt/dkt telephone (151 pages)

[Telephone System Toshiba Strata CIX Programming Manual](#)

Telephone button programming manual (144 pages)

[Telephone System TOSHIBA STRATA CTX User Manual](#)

Dkt/ipt telephone with digital business telephone systems (139 pages)

[Telephone Toshiba DKT User Manual](#)

Strata ctx dkt/ipt telephone (116 pages)

[Telephone Toshiba DKT3010-SD - Digital Phone User Manual](#)

Strata ctx digital business telephone systems dkt/ipt telephone (114 pages)

[Music Mixer Toshiba Strata CIX User Manual](#)

Ip windows operator console, business communications division (89 pages)

[DJ Equipment Toshiba Strata CIX User Manual](#)

Digital attendant console user guide (80 pages)

[Telephone Toshiba Strata CIX User Manual](#)

Standard telephone (44 pages)

[Telephone Toshiba Strata CIX Installation Manual](#)

Strata cix pc digital attendant console (38 pages)

[Server Toshiba Strata Installation Manual](#)

Cix media application server (28 pages)

[Telephone Accessories Toshiba STRATA CTX Installation Manual](#)

Attendant console (24 pages)

[Music Mixer Toshiba STRATA CTX Quick Reference Manual](#)

Ip attendant console (8 pages)

Summary of Contents for Toshiba STRATA CIX-CTX-QRG-VB VERSION B1

[Page 1](#) STRATA CIX/CTX DKT / IPT Telephone Quick Reference Guide Business Telephones
Helping You Communicate Better...

[Page 2: What's My Line](#)

Introduction This quick reference guide applies to Toshiba DKT3200-series digital telephones and Internet Protocol (IPT1020-SD, IPT2000-series and SoftIPT) telephones connected to a Strata CIX/CTX system. See your Telephone System Administrator to find out which features you have.

Use the check boxes or blank lines to enter the variable selections for your telephone.

[Page 3: Hot Dialing](#)

Call 5. Press Back 6. Press Strata CIX/CTX DKT/IPT Telephone Quick Reference Guide 11/05 Spkr Mode from your telephone (shown right). The soft key to start the Dial-directory search. soft key to go through the directory until you see soft key to call.

[Page 4: Handsfree Answerback](#)

You should hear confirmation tone if the code is valid or two short tones if it is invalid. 3. Dial a telephone number if you entered the code after accessing an outside line or resume talking or hang up if you entered the code after the call.

[Page 5: Conference Calls](#)

6. To supervise a tandem call, press the extension button. If the parties have finished, hang up or if the parties are still talking, Cnf/Trn press Strata CIX/CTX DKT/IPT Telephone Quick Reference Guide 11/05 Cnf/Trn Cnf/Trn again to return to the Cnf/Trn and hang-up.

[Page 6](#) No. + Timer Press Ext. + #6051 Cancel: ! ...or program a flexible button to perform the sequence See "Flexible Buttons" for instructions. Strata CIX/CTX DKT/IPT Telephone Quick Reference Guide 11/05 Hold Hold twice. (No one can accidentally Hold _____ + Destination No.

[Page 7: Call Park Orbits](#)

3. Dial the extension that is holding the ringing or held call to be picked up. Echo Cancel ! If you experience echo while conversing on your IP telephone, " Paging ! To make a page announcement to a phone or external speakers 1.

[Page 8: Speed Dial](#)

If these steps do not work, you may have to create a One Touch button (see "Flexible Buttons" ! To Use a One Touch Button, just press it. Strata CIX/CTX DKT/IPT Telephone Quick Reference Guide 11/05 Redial #9876 or dial to store the entry.

[Page 9: Voice Mail Call Monitor](#)

! To adjust Ring Tone, Handsfree Answerback and Speaker Off-hook Call Announce With an idle phone and handset on-hook, press When you hang up, volume returns to default. Strata CIX/CTX DKT/IPT Telephone Quick Reference Guide 11/05 button. button. Call Monitor...

[Page 10: Flexible Buttons](#)

3. Select someone from the list by pressing the Soft Key next to the name. Flexible Buttons There are 10, 14 or 20 Flexible Buttons on your telephone. You can program features onto Flexible Buttons for easy access. #9876 1. Press Hold 2.

[Page 11: Flexible Button Codes](#)

Not all features have a Flexible Button Code. For additional codes, see your System Administrator. CAUTION! Do not use cleansers that contain benzene, paint thinner, alcohol or other solvents on the telephone's rubber feet. The color of the rubber may transfer to the desk or mounting surface.

[Page 12](#) 9740 Irvine Blvd., Irvine, CA 92618-1697 (949) 583-3700 www.telecom.toshiba.com
© 2007 Toshiba America Information Systems, Inc. All product, service and company names are trademarks, registered trademarks or service marks of their respective owners. Information including without limitation product prices, specifications, availability, content of services, and contact information is subject to change without notice.

This manual is also suitable for:

StrataDkt3200 seriesCtxStrata cixStrata ctxlpt1020-sd ... [Show all](#)