

Dk8 Side View Dimension And Plug/Jack Locations - Toshiba Strata DK 16 Installation And Maintenance Manual

Toshiba digital key telephone systems installation and maintenance manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118


119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218

219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268

269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318

319
320
321




•

[Table of Contents](#)


•

Bookmarks



TO HPFB
FG
SCREW
AC POWER
CORD AND
PLUG 4' 7"
STATION TIP/RING
AMPHENOL 25-PAIR
JACK (FEMALE)
TIE WRAP
SUPPLIED WITH
DK8 TO HOLD
AMPHENOL
CONNECTOR
LEFT SIDE VIEW

FIGURE 4-3



DK8 SIDE VIEW DIMENSION AND PLUG/JACK LOCATIONS

3"
TIE-WRAP
HOLDER
SMDR/
TTY
TIE-WRAP HOLDER

4-3 INSTALLATION-DK8 KSU & PCB

TIE-WRAP
HOLDER
RESERVE BATTERY
(HPFB) CONNECTOR
BATT
DC ON/OFF
POWER SWITCH

6-WIRE SMDR/TTY
MODULAR JACK
RJ11 CO LINE JACKS
CO4
CO2
CO1
CO3
PFT

RJ11 POWER FAILURE
TRANSFER JACK
RIGHT SIDE VIEW

SECTION 100-816-204
MARCH 1993




Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
46
47
48
49
50
51
52
53

Quick Links:

[Programming](#)

[Dk16 Co Line/Station Configuration Guide \(Base...](#)

Chapters

[Section 1](#) 6

[Section 2](#) 14

[Table of Contents](#) 21

[Table of Contents](#) 45

[Table of Contents](#) 67

[Table of Contents](#) 109

[Table of Contents](#) 132

[Table of Contents](#) 193

Related Manuals for Toshiba Strata DK 16

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Telephone Toshiba Strata DK User Manual](#)

Electronic telephone (134 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Digital telephone (90 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Dk digital lcd telephone (48 pages)

[Telephone System Toshiba Strata DK8 General Description Manual](#)

Digital key telephone system (46 pages)

[Telephone Toshiba Strata DK16 User Manual](#)

Add-on module and direct station selection console (18 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

Related Content for Toshiba Strata DK 16

[Strata DK14 Main View](#)

Toshiba Strata DK14

[Strata CTX Network Jack Lan Device Assignment](#)

Toshiba Strata CTX

[Strata DK8 Strata Dk8 & Dk16 Peripherals](#)

Toshiba Strata DK8

[Strata CIX40 Moh/Bgm Jack +Volume Control](#)

Toshiba Strata CIX40

[Strata CIX Event Trace Side Change](#)

Toshiba Strata CIX

[Strata DK Admin View Cabinet Diagram](#)

Toshiba Strata DK Admin

This manual is also suitable for:

[Strata dk8](#)