



# **TOSHIBA**

## Toshiba WAL7C User Manual

Wall mounting for lcd color tv



1  
2

|  |
|--|
|  |
|--|


•

Bookmarks

|  |
|--|
|  |
|--|

[Download this manual](#)

### Quick Links



Enlarged version





# Wall mounting bracket V-MWC for LCD color TV

## Instruction for Installation

Thank you for purchasing this Toshiba Wall mounting.

For correct installation, please read this manual carefully.

This manual should be saved and kept on hand as a convenient reference.

This Wall mounting is designed exclusively for a Toshiba LCD color TV.

**Special technology and knowledge are required for the wall fixing. Please ask qualified applicators for installation.**

**For safety of the user, please make sure the installation area has strength enough to bear the weight of LCD color TV and Wall mounting, and install with care.**

**Please read the warnings and notice on the back carefully for correct use.**

### Installation Notice

To prevent harm to the user, please read the following content such as the installation method and the record with full understanding of the following diagram & marks and observe the recorded items.

#### [Marks]

##### Mark

Indicates "It could result in your death or serious injury"

### Warning

Instructions"

Indicates "It could result in your injury"

### Caution

Instructions"

\*1: Serious injury herein refers to conditions such as blindness, wound, burn (whatever high or low temperature), electric shock, fracture, poisoning etc. which may leave a sequela and require hospitalization or long medical treatment.

\*2: Injury herein refers to conditions such as wound, burn or electric shock etc. which does not require hospitalization or long medical treatment.

\*3: Property damage herein refers to damage of house, household, livestock or pet involved.

#### [Diagrams]

##### Diagram

" indicates a prohibited action (Do not do).

The action prohibited is described within or near the symbol by diagram or word.

##### Prohibition

" indicates a required action (Do).

The action required is described within or near the symbol by diagram or word.

##### Direction

##### Exemptions

Toshiba is not liable for any damage caused by natural disaster (such as fire, earthquake), uses by third person, accidents, owner's intentional misuse, or uses in other improper conditions.

Toshiba is not liable for mental damages (such as profit loss or interruption in business, TV watching fee loss etc.) caused by use or unable use of the product.

Toshiba is not liable for any damage caused by neglect of the instruction described in the instruction manual.

Toshiba is not liable for any injury/damage caused by improper installation of this product.

If the product is installed to the wall and then disassembled, the screw hole and fixing bolts will remain on the wall.

Over an extended period of use of your LCD color TV, dirt or discoloration may occur to the supporting wall.

#### Meaning of the mark

1 if you don't follow

2 if you don't follow

3 or property damage\*

if you don't follow

#### Meaning of the diagram

## Warning

Please ask qualified applicators to install the equipment to the wall. The inadequate application may cause the fall of a LCD color TV, resulting in injury.

##### Direction

Reinforce the installation area to make sure it is capable to bear the weight including the LCD color TV and resistant to impact of earthquake or shock. The inadequate application may cause the fall of the LCD color TV resulting injury. So, please reserve the following instructions.

##### Direction

A socket should be used for the power supply of a LCD color TV. Please use a socket out of which the plug can be pulled easily.

#### <Installation on wood walls>

Make sure the total weight is borne by the beam. The beam should be reinforced in case of inadequate strength. Please do not install the product on the plasterboard.

#### <Installation on concrete walls>

Please use the market available anchor bolt which can bear the weight of the LCD color TV.

Embed the metal hook fixed on the wall into the metal hole of the LCD color TV completely, slide and make sure it is in place. Otherwise the TV may fall resulting in injury.

Direction

- 

The wall mounting is designed exclusively for a Toshiba LCD color TV. Do not use it elsewhere. Otherwise it may fall causing injury.

Prohibition

Caution

- 

Do not jam the LCD color TV blowhole on the top of the screen. If the blowhole is jammed, heat will gather inside the TV, causing a fire.

Prohibition

- 

Do not install at places near the vent of air conditioner or frequently vibrate, or places directly blown by moisture, dust, smoke or steam (stove, electric cooker, humidifier etc.). Otherwise may cause fire or electric shock.

Prohibition

- 

The angle of the screen of an installed LCD color TV cannot be changed. The forced turn may loosen fixing bolt leading to the fall of the LCD color TV.

Direction

**DALIAN TOSHIBA TELEVISION CO., LTD.**

VF2A00172000



[Next Page](#)

1  
2

## Related Manuals for Toshiba WAL7C

[TV Mount Toshiba WAL13CS Operation Manual](#)

Wall mounting for lcd color tv (13 pages)

## Summary of Contents for Toshiba WAL7C

[Page 1](#) Direction Exemptions • Toshiba is not liable for any damage caused by natural disaster (such as fire, earthquake), uses by third person, accidents, owner's intentional misuse, or uses in other improper conditions. • Toshiba is not liable for incidental damages (such as profit loss or interruption in business, TV watching fee loss etc.) caused by use or unable use of the product.

[Page 2](#) Model applicable : 19AV550 Series Assemble (TV set body and stand fix type) □1□  
Please take out the LCD color TV from the LCD TV case. The supplied screws and paddings should be used. Other screws and paddings may cause function change, electric shock (in case of long screws), or lead to insufficient strength (in case of short screws) etc.