



# Toshiba TA-FVW100 Instruction Manual

Cordless steam iron



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40

---


- 

Troubleshooting

•

## Bookmarks

Available languages



The language selection bar features a decorative top border with a repeating pattern of dark blue, white, and red geometric shapes. Below this, three language options are presented as horizontal bars with rounded ends. The first bar is blue and contains the text 'EN'. The second bar is red and contains the text 'CN'. The third bar is light gray and contains the text 'KO'.

## Quick Links

[Download this manual](#)







**TOSHIBA**

Model    型号    형명  
**TA-FVW100/T**

Instruction Manual



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

# Related Manuals for Toshiba TA-FVW100

## [Iron Toshiba TA-FLW900 Instruction Manual](#)

Cordless steam iron (household use) (6 pages)

## Summary of Contents for Toshiba TA-FVW100

### [Page 2: Safety Precautions](#)

Safety Precautions Please follow these instructions Important information is written on the product and in this instruction manual about how to use the product safely and correctly to avoid damage to property or injury to people using the product or to other people. You should fully understand these precautions (symbols and icons) and follow the instructions here before reading the main part of this manual.

[Page 3](#) To avoid a fire, electric shocks, burns, injuries, or other problems Power cord and power plug Do not damage, sharply bend, stretch, twist, bundle, pinch, modify, or place heavy objects on the power cord. Do not use the power cord or power plug (power supply side or stand side) if it is damaged or if the power plug is loose when plugged into the electrical outlet.

[Page 4](#) Attention To avoid malfunction or breakage to the iron □ Do not apply too much force to the handle. Do not iron hard things, such as buttons or fasteners. It may cause breakage. It may cause damage. Do not touch the soleplate against the surface of the Do not pour water on the surface of the stand or the stand or the case.

[Page 5](#) Getting ready to use the iron Remove the case Put water (add more water) Turn on the power Hold the open buttons on both If you are using the iron for dry ironing, you do not sides of the case, pull them both Plug the stand side power plug outward ( ) as the arrows show,...

### [Page 6: Names And Functions Of Parts](#)

Names and functions of parts Contacts Soleplate Stand Iron □ □ Steam vents Contacts (52 vents) Contact pins Stand surface Controls Lock button Case Handle Handle of the iron's case Soleplate (FVW100: Nickel boron coating) Iron (FVW90: Silver titanium diamond coating) Cover Antibacterial glass and platinum ball FVW100:Antibacterial glass and platinum ball...

[Page 7](#) Functions Functions of the FVW100. Mist outlet Steam / Dry lever Fill opening Steam (select from 2 types of steam) Lid of the fill opening Steam Shower Steam Mist button Press this button to spray mist. Shot button Press the button to do Ultra shots and Hanger shots. (Set the temperature to [HIGH] to use this.) Temperature lamp When the temperature is correct, the temperature lamp...

[Page 8](#) How to use the iron Steam ironing Temperature settings Steam □ Press the SET / OFF button to set the temperature according to the fabric you are ironing. The temperature lamp flashes. (See page 7) According to fabric Shower Steam, Ultra shot, and Hanger shot □...

[Page 9](#) How to use ultra shot and hanger shot You can do shots when the Steam / Dry lever is in the Dry, Steam, or Shower position. We recommend regular ironing to remove the wrinkles from cotton and linen. Wrinkles may be difficult to remove, depending on the amount of wrinkles, thickness and kind of the fiber. You can remove wrinkles from woolen clothes You can use an ultra shot vertically.

[Page 10](#) How to use the iron Dry ironing Temperature settings Press the SET / OFF button to set the temperature according to the fabric you are ironing. The temperature lamp flashes. (See page 7) According to fabric Attention If you are ironing a blended fiber, set the temperature according to the lower temperature fiber. Getting started flashing You can use the iron when the temperature lamp stops...

## Page 11: Storing The Iron

Charging the iron When not using the iron, or when straightening the clothes, return Straight onto the the iron to the stand so it goes straight onto the contacts. contacts until it stops If the temperature lamp is flashing, wait until it stops flashing and stays lit before you use the iron.

## Page 12: Cleaning The Iron

Cleaning the iron Attention Always unplug the power plug from the electrical outlet, and allow the iron to cool completely. Dirt on the iron and stand Use a soft dry cloth or a damp cloth to wipe the iron and stand. Dirt on the contact pins Wipe with a dry cloth.

## Page 13: Troubleshooting

Troubleshooting Refer to the following points if you think something is wrong. Problem Where to check Solution Does not heat up. Power plug Plug the power plug completely into an electrical outlet. SET / OFF button Change the setting to the temperature that is most appropriate for the fabric.

**Page 14** 請將電源插頭從電源插座中拔出，並允許熨斗完全冷卻。熨斗和底座上的污垢 使用乾淨的軟布或潮濕的布擦拭熨斗和底座。接觸針上的污垢 用乾布擦拭。

**Page 15** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 16** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 17** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 18** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 19** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 20** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 21** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。

**Page 22** 請將熨斗完全冷卻後，將電源插頭從電源插座中拔出。請將熨斗和底座上的污垢用乾淨的軟布或潮濕的布擦拭。請將接觸針上的污垢用乾淨的布擦拭。



.....  
.....  
.....  
.....  
.....

[Page 39](#) Memo

.....  
.....  
.....  
.....  
.....

This manual is also suitable for:

[Ta-fvw90](#)