



Whirlpool 1159801 Use And Care Manual

Whirlpool air conditioners 1159801 use & care guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22

•

[Table of Contents](#)

-


Troubleshooting

•

Bookmarks


--

Available languages



Quick Links

[Download this manual](#)



AIR CONDITIONERS

Use & Care Guide

1159801 Rev. B

\345

Use & Care Gui

[Table of Contents](#)

[Next Page](#)

- 1
- 2
- 3
- 4
- 5

Chapters

English 2

Español 12

Related Manuals for Whirlpool 1159801

[Air Conditioner Whirlpool 1157672 Installation Instructions](#)

(4 pages)

[Air Conditioner Whirlpool 1187361 Use And Care Manual](#)

Whirlpool air conditioner 1187361 use & care guide (32 pages)

[Air Conditioner Whirlpool 1188177 Use And Care Manual](#)

Through-the-wall air conditioner (32 pages)

[Air Conditioner Whirlpool ACE082XR0 Use And Care Manual](#)

Whirlpool room air conditioner use & care guide (28 pages)

[Air Conditioner Whirlpool ACE184XR0 Use And Care Manual](#)

Whirlpool air conditioner use & care guide air conditioner (36 pages)

[Air Conditioner Whirlpool ACS088PR0 Use And Care Manual](#)

Room air conditioners for slider and casement windows (44 pages)

[Air Conditioner Whirlpool ACS102PP Use And Care Manual](#)

Room air conditioners for slider and casement windows (28 pages)

[Air Conditioner WHIRLPOOL 1188018 Use And Care Manual](#)

(44 pages)

[Air Conditioner WHIRLPOOL 1187680 Use And Care Manual](#)

Through-the-wall air conditioner (28 pages)

[Air Conditioner Whirlpool ACE184XS0 Use & Care Manual](#)

(36 pages)

[Air Conditioner Whirlpool 1186896B User Manual](#)

(20 pages)

[Air Conditioner Whirlpool 1172397 Installation Instructions Manual](#)

(38 pages)

[Air Conditioner Whirlpool AC0052 Use And Care Manual](#)

Whirlpool air conditioners use and care ac0052, acq062 (16 pages)

[Air Conditioner Whirlpool ACC082XR0 Use And Care Manual](#)

Whirlpool room air conditioner use & care guide room air conditioner (32 pages)

[Air Conditioner Whirlpool ACD052PK0 Use & Care Manual And Installation Instructions](#)

Whirlpool room air conditioner use and care guide (36 pages)

[Air Conditioner Whirlpool ACE184PT0 Use And Care Manual](#)

Whirlpool air conditioner use & care guide (36 pages)

Summary of Contents for Whirlpool 1159801

[Page 2: Table Of Contents](#)

Contents Important Safety Instructions Operating Your Air Conditioner.. Starting your air conditioner..The exhaust control ... Changing air direction..Cleaning Your Air Conditioner.. Cleaning front panel and air filter..5 Caring For Your Air Conditioner..6 Annual maintenance..

[Page 3: Operating Your Air Conditioner](#)

Operating Your Air Conditioner Electrical Shock Hazard Plug into a grounded three-prong outlet. Do not remove ground prong. Do not use an adapter. Failure to follow these instructions result in death or electrical shock. Starting your air conditioner Fire Hazard Do not use an extension Doing so can result in death, fire, or electrical...

[Page 4: The Exhaust Control](#)

Operating Your Air Conditioner Continued The exhaust control The Exhaust Control setting draws stale or smoky air from the room. 1. To exhaust room air: Set Exhaust Control to OPEN. If no cooling is desired, use FAN ONLY setting. For cooling, set System Control to desired COOL setting.

[Page 5: Cleaning Your Air Conditioner](#)

Cleaning Your Air Conditioner TabS Proper use and care of your air conditioner will help ensure longer life of the unit and lower operating costs. Follow these instructions carefully. Call your authorized servicing dealer for an annual checkup. Cleaning front panel and air filter Explosion Hazard Unplug power cord from outlet before...

[Page 6: Caring For Your Air Conditioner](#)

Caring For Your Air Conditioner Annual maintenance Electrical Shock Hazard Unplug power cord from outlet before servicing. Be sure no liquid gets into the motor, electrical control box, or compressor terminals. Failure to follow these instructions can result in death, electrical shock, or serious injury.

[Page 7: Energy Saving Tips](#)

Remove side curtains. Slide curtains out to fullest width. From the back side, remove the phillips-head screws which attach the curtains to the cabinet. (See A in illustration at left.) Remove slotted-hex head screws holding top channel. (See B in illustration at left.) Remove slotted-hex head screws on sides of cabinet.

[Page 8: Troubleshooting](#)

Troubleshooting Before you call for service . . . If you are having an operating problem, check the chart to see what the cause might be before you call for assistance. PROBLEM CHECK IF Unit won't run. Power cord is plugged into a live circuit with proper voltage.

[Page 9: Requesting Assistance Or Service](#)

Requesting Assistance or Service For service in the U.S. 1. If you need assistance* . . . Call our Consumer Assistance Center telephone number. Dial toll free from any- where in the U.S.A.: 1-800-253-1301 and talk with one of our trained consultants. consultant can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary,...

[Page 10: Warranty](#)

D. The removal and reinstallation of your air conditioner if it is installed in an overhead or other inaccessible location or not installed in accordance with published installation instructions. E. Repairs to parts or systems caused by unauthorized Service under the full warranties must be provided by an authorized Whirlpool service company. WHIRLPOOL CORPORATION SHALL NOT BE LIABLE FOR INCIDENTAL DAMAGES.

[Page 11](#) ACONDICIONADORES DE AIRE Instrucciones para su us0 ycuidado...

[Page 12](#) Contenido Instrucciones Importantes de Seguridad Instrucciones de Operaci3n3 Encendiendo el acondicionador de aire El control de extraccion de aire .

[Page 13: Instrucciones De Operación](#)

Instrucciones de Operación Peligro de Choque Eléctrico Enchufe en una salida de puesta a tierra de tres pines. No remueva la pata de puesta a tierra. No use un adaptador. Si no se siguen estas precauciones puede resultar en la muerte o choque eléctrico.

[Page 14: El Control De Extracción De Aire](#)

Instrucciones de Operación Continuación Lengüeta El control de extracción de aire El Control de Extracción de aire remueve el aire impuro o cargado de humo de la habitación. 1. Para remover el aire de la habitación: Ajuste el Control de Extracción de aire a OPEN (abierto).

[Page 15: Limpieza Del Acondicionador](#)

Limpieza del Acondicionador de Aire Lengüetas El uso y cuidado debidos de su acondicionador de aire ayudara a prolongar la duración de la unidad y reducir los costos de operación. estas instrucciones cuidadosamente. Pídale a su concesionario de servicio autorizado que haga una verificación cada año.

[Page 16](#) Limpieza del Acondicionador de Aire Continuación Remueva el filtro del panel delantero quitando la banda elástica que lo mantiene en su lugar. Limpie el filtro usando una aspiradora o, si está muy sucio, lave el filtro con agua tibia y un detergente suave.

[Page 17: Cuidado Del Acondicionador](#)

Cuidado del Acondicionador de Aire Mantenimiento anual Peligro de Choque Eléctrico Desenchufe el cable eléctrico tomacorriente antes de dar mantenimiento. Asegurese que ningún líquido entre en el motor, caja del control eléctrico terminales del compresor. Si no se siguen estas precauciones puede resultar en la muerte, choque eléctrico...

[Page 18](#) Cuidado del Acondicionador de Aire Continuación NOTA: No levante empuje o tire de ninguna pieza con espuma blanca (poliestireno expandido). 1. Desenchufe el cable eléctrico. 2. Remueva el panel delantero. (Vea "Limpieza del panel delantero y filtro" en la página 5). 3.

[Page 19: Consejos Para Ahorrar Energía](#)

Consejos para ahorrar energía Mejore el aislamiento de su casa. Selle las puertas y ventanas. Cierre el tubo humero del hogar. Cierre las persianas o las cortinas en el lado soleado de la casa. Atienda toldos a las ventanas. Mantenga limpio el filtro de aire. No obstruya el flujo de aire con cortinas o muebles.

[Page 20: Diagnóstico De Problemas](#)

Diagnóstico de Problemas Antes de llamar para obtener asistencia . . . Si tiene un problema de operación, revise la tabla para ver si encuentra la causa antes de llamar por asistencia. PROBLEMA El acondicionador Se enchufó la unidad en un circuito de aire no "viva"...

[Page 21](#) Solicitando Ayuda o Servicio Técnico Para servicio en los EE.UU. 1. Si necesita asistencia'... Llame al Centro de Asistencia al Consumidor de Whirlpool. Llame gratis desde cualquier lugar en los Estados Unidos: 1-800-253-1301 y hable con uno de nuestros consultantes capacitados.

[Page 22](#) B. Recoger y entregar. Este producto está diseñado para ser reparado en su hogar. C. Daños al acondicionador de aire causados por accidentes, actos de la naturaleza o el uso de productos que no fueron aprobados por Whirlpool. D. El desmontaje y la reinstalación...