

Whirlpool LE3300XS Use & Care Manual

Estate series automatic dryers

ł.

Bookmarks

•

Download this manual

Quick Links





Ovens. Trash Compaclors. Room Air Condlloners. Dehumldlfws.

Automatic Washers. Clothes Dryers. freezers, Refrlgeralor-f

Next Page

Related Manuals for Whirlpool LE3300XS

Dryer Whirlpool LE3000XM Use And Care Manual Automatic dryers (8 pages) Dryer Whirlpool LE3000XK Use And Care Manual Whirlpool corporation dryer use & care guide le3000xk, lg3001xk (8 pages) Dryer Whirlpool LE3000XP Use & Care Manual Automatic dryers (12 pages) Dryer Whirlpool LE3000XS Use And Care Manual Automatic dryers (13 pages) Dryer Whirlpool LE3005XP Use & Care Manual Automatic dryers (12 pages) Dryer Whirlpool LE3300XP Use & Care Manual Estate series automatic dryers (12 pages) Dryer Whirlpool LE3305XP Use & Care Manual Estate series automatic dryers (12 pages) Dryer Whirlpool LE3300XPWO Parts List Whilpool electric dryer parts list (7 pages) Dryer Whirlpool WED5800 Installation Instructions Manual 29" (73.7 cm) electric dryer (28 pages) Dryer Whirlpool LE4900XM Use & Care Manual Automatic dryers (12 pages) Dryer Whirlpool LE5200XT Use And Care Manual Automatic dryer (12 pages) Dryer Whirlpool LE5720XS Use & Care Manual Automatic, electric/gas (12 pages) Dryer Whirlpool LE9380XT Use & Care Manual Super capacity automatic dryer (16 pages) Dryer Whirlpool LER3622HQ1 Use And Care Manual 240-volt electric compact dryer (20 pages) Dryer Whirlpool LE6098XFQ0 Use & Care Manual Super capacity automatic dryers (16 pages) Dryer Whirlpool LER56000 Use & Care Manual (21 pages)

Summary of Contents for Whirlpool LE3300XS

Page 1 /zizzq AUTOMATIC DRYERS Electric Model LE3300XS Akrowave Ovens. Trash Compaclors. Room Air Condlloners. Dehumldlfws. Automatic Washers. Clothes Dryers. freezers, Refrlgeralor-f...

<u>Page 2</u> ...ASSISTANCE ...WHIRLPOOL WARRANTY ... 01987 Whirlpool Corporation Remove Consumer Buy Guide label before using your dryer. It will be easier to remove.

<u>Page 3</u> Additional Safety Instructions and Your Responsibilities ALWAYS unplug the power or turn off electrical payer tempting to service the dryer. NEVER use or store flammable [dry-cleaning solvents. gasoline, osene) in or near your dryer. stances give off vapors that can create

FIRE HAZARD EXPLOSION.

<u>Page 4</u> Operating instructions Starting Your Dryer Before starting your dryer, be sure laundry properly (see your "Dryer Guide"). Select CYCLE and TIME Turn the Control Knob either way to point to the time setting the cycle you want. To stop and .

Page 5 Selecting a Cycle Each dryer cycle chart below to help you decide TYPE OF LOAD COTTONS HEAVY - Bedspreads, MEDIUM AND LIGHTWEIGHT - Shirts, dresses, sheets, diaoers, towels. PERMANENT PRESS HEAVY - Work clothes, jackets, MEDIUMWEIGHT Shirts, uniforms, dresses.slacks, etc. KNITS HEAVYWEIGHT - COTTONS, RAYONS, BLENDS - T-Shirts, slacks, poloshirts.etc.

<u>Page 6</u> Lint screen Clean the lint screen increase drying time and may be a FIRE HAZARD. Open the lid and pull the lint screen straight out. Lint removal Lint can gather inside the dryer and create should be removed at least every 2 to 3 years, or more otten, depending on dryer usage.

<u>Page 7</u> Remove loose and sharp from pockets and cuffs before drying pins, buckles, etc. Close metal zippers. Wipe off all spills with a damp, cloth. Spills allowed to remain dull or damage the finish. Never leave wet or damp in your dryer. Sharp or heavy objects...

<u>Page 8</u> If you need service or assistance, we suggest you follow these five steps: Before calling for assistance... Performance problems from little things you can find and fix yourself without tools of any kind. IF YOUR DRYER DOES NOT RUN: Is the power supply live circuit with the proper Is the door closed...

<u>Page 9</u> If you need FSP" replacement parts%. FSP is a registered Whirlpool net- parts. Look for this symbol whenever Serv- part for your Whirlpool replacement serv- work right, because to fulfill the the same after- used to build in the appliance.

Page 10 Notes...

<u>Page 12</u> C. Pick up and dellvery. the home. D. Damage to dryer caused of God or use of products WHIRLPOOL CORPORATION QUENTIAL DAMAGES. Some states do not allow Incidental or consequential not apply to you. This warranty also have other rights which...