




Whirlpool LE6800XP Use & Care Manual

Automatic dryers

| |
|-------------------|
| 1 |
| Table Of Contents |
| 2 |
| 3 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 10 |
| 11 |
| 12 |



•


[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



AUTOMATIC
DRYERS

Electric Model
LE6800XP

and

Gas Model
LG680IXP

use & care guide

Wave Ovens, Trash Compactors, Room Air Conditioners, Dehumidifiers, Automatic Washers, Clothes Dryers, Freezers, Refrigerator-Freezer



Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool LE6800XP

[Dryer Whirlpool LE6090XT Use And Care Manual](#)

Large capacity automatic dryers (16 pages)

[Dryer Whirlpool LE6800XS Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE6810XP Use & Care Manual](#)

Whirlpool automatic dryers use & care guide le6810xp, lg6811xp (12 pages)

[Dryer Whirlpool LE6805XP Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE6880XS Use & Care Manual](#)

Whirlpool use & care guide automatic dryers le6880xs (12 pages)

[Dryer Whirlpool LG6881XS Use And Care Manual](#)

Super capacity automatic dryers (16 pages)

[Dryer Whirlpool LE6098XT Use & Care Manual](#)

Super capacity automatic dryers (16 pages)

[Dryer Whirlpool LE6098XFQ0 Use & Care Manual](#)

Super capacity automatic dryers (16 pages)

[Dryer Whirlpool LG6811XS Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE5320XT, LE5530XS, LE5600XS, LE5650XM, LE5700XS, E5705XP, LE6055XS, LG5321XT, LG5531XS, LG5601XS, LG5651XM, LG5701XS, LG5706XP, Use And Care Manual](#)

Large capacity automatic dryers (16 pages)

[Dryer WHIRLPOOL LE6090XS Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE6098XS Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE6400XK Use And Care Manual](#)

Whirlpool dryer lg6401xk, le6400xk use & care guide (8 pages)

[Dryer Whirlpool LE6405XP Use & Care Manual](#)

Estate series automatic dryers (12 pages)

[Dryer Whirlpool LE6660XP Use & Care Manual](#)

Estate series automatic dryers (17 pages)

[Dryer Whirlpool LE6090XTW0 Patrs List](#)

Whirlpool le6090xtw0 electric dryer patrs list (9 pages)

Summary of Contents for Whirlpool LE6800XP

[Page 1](#) Ovens. Trash Compactors. Room AH Condltioners. Oehumidlwrs, Automatic Washers, Clothes Dryers. Freezers, Relrlgerator-Freezer AUTOMATIC DRYERS Electric Model LE6800XP Gas Model LG680IXP...

[Page 2: Table Of Contents](#)

TUMBLE PRESS@ Setting ..x 8 Drying Times..Mixed Loads End-of-Cycle Signal . . 01984
Whirlpool Corpomtion Remove the Con- sumer Buy Guide la- before using your dryer. It will be

easier to remove.

[Page 3: Your Responsibilities](#)

Your Responsibilities Read this "Use and Care Guide" and your "Dryer Guide" carefully important use and safety information. personally responsible making sure that your dryer.. is installed by a qualified installer. is properly maintained. is installed in an area protected from the weather.

[Page 4: Timed Drying](#)

TYPE OF LOAD COTTONS - LINENS EXTRA HEAVY - Bedspreads, mattress padsquilts. HEAVYWEIGHT FABRICS - Towels, jeanscorduroys. work clothes MEDIUMWEIGHT COTTONS - Sheets, pillowcases, cotton underwear, diapers LIGHTWEIGHT COTTONS - Batistes, organdieslingerie PERMANENT PRESS, SYNTHETICS AND BLENDS HEAVYWEIGHT FABRICS -Work clothes, jackets, raincoats...

[Page 5](#) Select a 1. CYCLE Turn the Control Knob either way to point to the cycle and setting want. See page 6 for information the cycles. Push the 3. START Button The dryer will start tumbling when you push the START Button. The Cycle Control Knob should...

[Page 6](#) Operating instructions The automatic cycles The automatic cycles allow you to select the degree of dryness you prefer for the clothes being dried. The Control Knob moves and stops several times until the load reaches the dryness setting you selected. Then the knob automatically moves to...

[Page 7: Drying Tips](#)

Drying tips The dryer does not heat when the Temperature Selector is set on FLUFF AIR This setting can be used to fluff bedding, plastic tablecloths, foam rubber pillows, stuffed toysneakers. etc. 1. Turn the Temperature Selector FLUFF AIR. Turn the Control Knob to the number of minutes you want in the TIMED DRYING Cycle.

[Page 8: Drying Times](#)

Drying times Drying times will vary depending amount of moisture in the clothes. type and weight of the fabric. size of the load. room temperature around dryer temperature of the wash rinse water. amount of lint in the lint screen. dryertemperature selection.

[Page 9: Lint Screen](#)

Lint screen Clean the lint screen before increase drying time and may be a FIRE HAZARD. Open the lid and pull the lint screen straight out. Lint removal Lint can gather inside the dryer and create should be removed every 2 to 3 years, dryer usage.

[Page 10: Caring For Your Dryer](#)

Caring for your dryer Remove sharp objects from clothing before drying - pins, buckles, etc. Close metal zippers. Wipe off all spills with a damp, soft cloth.Spills allowed to remain dull or damage the finish. Non-colorfast items can stain the drum.

[Page 11: If You Need Service Or Assistance](#)

DRYING TIME SEEMS LONG: Is the lint screen clean? See page 6 in your"Dryer Guide:' 2. If you need assistance*... Call Whirlpool COOL-LINE@ serv- ice assistance telephone number. Dial free from: Continental U.S. . (800) 253-1301 Michigan .

[Page 12: 01984 Whirlpool Corpomtion](#)

Making your world a little easier. Part No. 693689 Printed in U.S.A. 01984 Whirlpool Corporation matlc Washers, Clothes Dryers. Freezers. Refrigerator-Freezers, Ice Makers. Olshwashers. Bwlt-In Ovens and Surface Units. Ranees. Mlcrr...

This manual is also suitable for:

[Lg680lxpLg6801xp](#)