


Whirlpool LEi5800XM Use And Care Manual

Automatic dryers

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12



•

[Table of Contents](#)

•

Bookmarks

Quick Links

[1 Parts and Features](#)

[2 Table of Contents](#)

[Download this manual](#)



Electric Model

LEi5800XM

at1 d

&IS Model

LG5801XM

AUTOMATIC DRYERS

Electric
Ovens, Trash Compactors,
Room Air Conditioners,
Dehumidifiers,
Automatic
Washers Clothes
Dryers
Freezers,
Refrigerator-Freezer

use & care guide



Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool LEi5800XM

[Dryer Whirlpool LEW0050PQ Job Aid And Service Manual](#)

24" electric dryer (48 pages)

[Dryer Whirlpool LEQ8000JQ User Instructions](#)

User instructions (16 pages)

[Dryer Whirlpool LDR3422A Use And Care Manual](#)

Compact automatic dryers (16 pages)

[Dryer Whirlpool LE4900XS, LE4930XS, LG4931XS Use And Care Manual](#)

Compact electric / gas automatic dryers (12 pages)

[Dryer Whirlpool LE5705XP Use & Care Manual](#)

Electric and gas automatic dryer (13 pages)

[Dryer Whirlpool LE5650XK Use And Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE5650XM Use And Care Manual](#)

Automatic dryers (13 pages)

[Dryer Whirlpool LE5650XMW1 Use & Care Manual](#)

Electric & gas automatic dryers (12 pages)

[Dryer Whirlpool LE5920XM Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE7800XS Use & Care Manual](#)

Automatic dryers (12 pages)

[Dryer Whirlpool LE9680XW Use & Care Manual](#)

Super capacity automatic dryers (16 pages)

[Dryer Whirlpool LE9800XM Use & Care Manual](#)

Electric and gas automatic dryers, solid state mark ii series electronic touch control (12 pages)

[Dryer Whirlpool LER5848EQ2 Use And Care Manual](#)

Easy-to-use electric and gas dryers (24 pages)

[Dryer Whirlpool LER3624EQ1 Use & Care Manual](#)

Electric and gas dryers (21 pages)

[Dryer Whirlpool LER56000 Use & Care Manual](#)

(21 pages)

[Dryer Whirlpool GEQ9800PW Installation Instructions Manual](#)

27 in. (69 cm) electric dryer (24 pages)

Summary of Contents for Whirlpool LEi5800XM

[Page 1](#) AUTOMATIC DRYERS Ekctric Model LEi5800XM at1 d &IS Model LG58oIXM Wa 1ers Clothes Dryers Freezers. Relrwrator-Free2t Ovens. Trash Compactors, Room AM Condlittonerr. Dehumldflfers. Automallc...

[Page 2: Table Of Contents](#)

Parts and features CYCLE CONTROL KNOB LAUNDRY INFORMATION CENTER TEMPERATURE SELECTOR When need service or call question, have this informcltion 1. Complete Model Senal

[from the plate located as shown] 2. Purchase date from sales slip Copy this information in these Keep this book, your...

[Page 3: Your Responsibilities](#)

Your Responsibilities Read this "Use Care Guide" your "Dryer Guide" carefully important use and safety information. You are personally responsible making sure that your dryer... is installed by a qualified installer. is properly maintained. 9 is installed in an area protected from the weather.

[Page 4](#) TYPE OF LOAD COTTONS - LINENS -- - EXTRA HEAVY - Bedspreads, mattress pads, quilts. HEAVYWEIGHT FABRICS - Towels, jeans, corduroys, work clothes MEDIUMWEIGHT COTTONS Sheets, pillowcases, cotton underwear, diapers LIGHTWEIGHT COTTONS - Batistes. organdies, lingerie PERMANENT PRESS, SYNTHETICS AND BLENDS HEAVYWEIGHT FABRICS - work clothes.

[Page 5](#) Select a 1. CYCLE Turn the Control Knob either point at the cycle setting want. See page 6 for information on the cycles Push the START Button The dryer will start tumbling when you push the START Button Changing a setting The setting be changed at any...

[Page 6: Operating Instructions](#)

Operating instructions The automatic cycles The automatic cycles allow you to select the degree of dryness prefer for the clothes being dried. The Control Knob moves and stops several times until the load reaches the dryness setting you selected Then the knob automatically moves to OFF and tumbling...

[Page 7: Drying Tips](#)

Drying tips FLUFF The dryer does not heat when Temperature Selector is set on FLUFF AIR This setting be used to fluff bedding, plastic tablecloths, foam rubber pillows, stuffed toys, sneakers. 1. Turn Temperature Selector FLUFF AIR. 2. Turn Control Knob to the number of minutes you want in the TIMED...

[Page 8: Mixed Loads](#)

Mixed loads When drying a load with different kinds weights of fabrics, use the cycle suggested for the lightest fabrics. When the dryer stops, remove dry items reset the control To reduce wrinkling, take load from dryer as soon tumbling stops.

[Page 9: Lint Removal](#)

Lint screen Clean the lint screen before each increase drying time and make sure a FIRE HAZARD Open the lid and pull the lint screen straight DO NOT run the dryer with the lint screen loose. damaged or missing. Doing so can cause over...

[Page 10: Caring for Your Dryer](#)

Caring for your dryer Remove sharp objects from clothing before drying - pins, buckles, etc. Close metal zippers. Wipe off all spills with a damp, soft cloth. Spills allowed to remain dull or damage the finish. Non-colorfast items stain the drum.

[Page 11: Assist, Nce](#)

1 is needed in order refer to your request assistan FSP IS a registered trademark of Whirlpool Corporation quality parts Look for the symbol of quality whenever need a replacement for your Whirlpool...

[Page 12](#) Making your world a little better Part No. 691271 Rev. A Printed in U.S.A © 1984 Whirlpool Corporation Washers Clothes Dryers. Freezers. Aerials. Freezers. Ice Makers. Dishwashers, Built-in Ovens and Surface Units. Ranges. Microwaves...

This manual is also suitable for:

[Lg580lxmlLe5800xmlG580lxmlG5801xml](#)