



Whirlpool 1185020 Use And Care Manual

Whirlpool dehumidifier 1185020 use & care guide

1
2
3
4
5
6
7
8
9
10
11
12
Table Of Contents
13
14
15
16
17

18
19
20
21
22
23
24




•

•

Bookmarks

Available languages



Quick Links

[1 Operating Dehumidifier](#)

[Download this manual](#)




Dehumidifier

Use & Care Guide

Contents

Safety information	2
Electrical requirements	3



Installing dehumidifier	4
Operating dehumidifier	5-6
Removing and emptying water bucket	7
Water level float and automatic shutoff	8
Caring for your dehumidifier	9
If you need assistance or service	10-11

Part No. 1185020 Rev. A

[Table of Contents](#)

1
2
3
4
5

Related Manuals for Whirlpool 1185020

[Dehumidifier Whirlpool 1182182 Use And Care Manual](#)

Whirlpool dehumidifier 1182182 use & care guide (24 pages)

[Dehumidifier Whirlpool AD25BBK0 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (24 pages)

[Dehumidifier Whirlpool AD35DSS0 Use And Care Manual](#)

Whirlpool dehumidifier use and care guide (16 pages)

[Dehumidifier Whirlpool 1187984 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (16 pages)

[Dehumidifier WHIRLPOOL 1184914-W Warranty](#)

(1 page)

[Dehumidifier Whirlpool 1188927 Use And Care Manual](#)

(20 pages)

[Dehumidifier Whirlpool 1ADM202XX0 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (13 pages)

[Dehumidifier Whirlpool Dehumidifier Use & Care Manual](#)

Dehumidifier (22 pages)

[Dehumidifier Whirlpool WHAD703AW Use And Care Manual](#)

(40 pages)

[Dehumidifier Whirlpool DE20W5252 Instructions For Use Manual](#)

(23 pages)

[Dehumidifier Whirlpool WDH70EAPW Use & Care Manual](#)

(15 pages)

[Dehumidifier Whirlpool DS201NB Operating Instructions Manual](#)

Household (54 pages)

[Dehumidifier Whirlpool AD50GUSB Use & Care Manual](#)

(22 pages)

[Dehumidifier Whirlpool AD70USS Manual](#)

(40 pages)

[Dehumidifier Whirlpool AD35DSS1 Use And Care Manual](#)

Whirlpool dehumidifier use & care guide (20 pages)

[Dehumidifier Whirlpool SS209 Owner's Instructions Manual](#)

(25 pages)

Summary of Contents for Whirlpool 1185020

[Page 1](#) Caring for your dehumidifier9 If you need assistance or service10-11 Part No. 1185020 Rev. A...

[Page 2: Safety Information](#)

Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages. This is the safety alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others.

[Page 3: Electrical Requirements](#)

Electrical requirements **WARNING Electrical Shock Hazard** Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. A 115-volt (103.5 min., 126.5 max.), 60-Hz, AC-only, 15- or 20-ampere fused and properly grounded electrical...

[Page 4: Installing Dehumidifier](#)

Installing dehumidifier Good air circulation is needed for best performance—allow at least 12-18 inches (30.5 - 45.7 cm) of air space on all sides of the dehumidifier. 12-18" (30.5 - 45.7 cm) Install dehumidifier on a level floor strong enough to support the dehumidifier with a full bucket of water.

[Page 5: Operating Dehumidifier](#)

Operating dehumidifier Note: Before turning dehumidifier on, be sure that: • Dehumidifier is plugged into the wall outlet • Bucket is properly inserted into dehumidifier • Bucket is empty Control A Control B selects fan speed If your control looks like A or B: TO TURN DEHUMIDIFIER ON: Turn DRYNESS CONTROL clockwise.

[Page 6: Operating Dehumidifier](#)

Operating dehumidifier Control C ON / OFF selects mode If your control looks like C: TO TURN DEHUMIDIFIER ON: Press the ON/OFF button. All lights will flash once. If the Empty/Adjust Bucket light comes on, the dehumidifier will not operate. Empty or adjust bucket. Each time you unplug the dehumidifier or power is interrupted, the control will return to your previous settings.

[Page 7: Removing And Emptying Water Bucket](#)

Removing & emptying water bucket **WARNING Sickness Hazard** Do not drink water collected in water bucket. Doing so can result in sickness. 1. Use both side handles to lift bucket. Pull bucket forward and remove. 2. Carry bucket to a large sink or tub. 3.

[Page 8: Water Level Float And Automatic Shutoff](#)

Water level float & automatic shutoff All dehumidifiers have automatic shutoff and a water level float. Some dehumidifiers feature an adjustable Water Level Float. The bucket must be properly aligned for the Water Level Float to work. For models with non-adjustable Water Level Float: The Water Level Float will shut off the dehumidifier automatically.

[Page 9: Caring For Your Dehumidifier](#)

Caring for your dehumidifier You may clean the exterior of your product: General cleaning and maintenance 1. Dust the front grille and side panels with a soft brush or the dusting attachment of your vacuum. 2. If cabinet paint chips, you can touch up the paint with a good grade enamel paint to prevent rust.

[Page 10: If You Need Assistance Or Service](#)

• Unit will put out heat. Safety information 2. If you need assistance in the U.S.A.... Call your local dealer or the Whirlpool Customer Interaction Center toll-free at 1-800-253-1301. When requesting assistance, please provide model number, serial number, date of purchase, and a complete description of the problem.

[Page 11: If You Need Assistance Or Service](#)

If you need assistance or service (cont.) 3. If you need assistance or service in Canada... Contact the dealer from whom you purchased your appliance, or call the Consumer Assistance Centre toll free, 8:30 a.m. - 6:00 p.m. (EST), at 1-800-461-5681. Contact your nearest direct service branch or authorized servicing outlet to service your appliance.

[Page 12](#) Part No. 1185020 Rev. A 01/02 ©2002 All rights reserved Printed in U.S.A.

[Page 13: Table Of Contents](#)

Cuidado de su deshumidificador9 Si necesita ayuda o servicio técnico10-11 Parte No. 1185020 Rev. A...

[Page 14: Información De Seguridad](#)

Información de seguridad Su seguridad y la seguridad de los demás es muy importante. Hemos incluido muchos mensajes importantes de seguridad en este manual y en su electrodoméstico. Lea y obedezca siempre todos los mensajes de seguridad. Este es el símbolo de advertencia de seguridad. Este símbolo le llama la atención sobre peligros potenciales que pueden ocasionar la muerte o una lesión a usted y a los demás.

[Page 15: Requisitos Eléctricos](#)

ADVERTENCIA Peligro de descarga eléctrica Enchúfelo en un contacto de pared de conexión a tierra con tres terminales. No quite la terminal para conexión a tierra. No use adaptador. No use cable alargador. No seguir estas instrucciones puede ocasionar la muerte, un incendio o descarga eléctrica.

[Page 16: Cómo Instalar El Deshumidificador](#)

Cómo instalar el deshumidificador Para mejor rendimiento, se necesita una buena circulación de aire—deje por lo menos 12-18 pulgadas (30.5-45.7 cm) de espacio para el aire alrededor del deshumidificador. 12-18" (30.5 - 45.7 cm) Instale el deshumidificador en un piso a nivel lo suficientemente fuerte como para soportar el deshumidificador con el balde de agua lleno.

[Page 17](#) Cómo operar el deshumidificador Si su control es como A o B: PARA ENCENDER EL DESHUMIDIFICADOR: Gire el DRYNESS CONTROL (CONTROL DE SEQUEDAD) en la dirección de las manecillas del reloj. VELOCIDAD DE VENTILACIÓN: (Sólo para modelos con Control B): esto controla el funcionamiento del ventilador.

[Page 18](#) Cómo operar el deshumidificador Control C ON / OFF Selecciona el modo Si su control es como C: PARA ENCENDER EL DESHUMIDIFICADOR: Oprima el botón de ON/OFF (Encendido/Apagado). Si se enciende la luz de EMPTY/ADJUST BUCKET (luz de VACÍE/AJUSTE EL BALDE), el deshumidificador no funcionará.

[Page 19: Cómo Sacar Y Vaciar El Balde De Agua](#)

Cómo sacar y vaciar el balde de agua ADVERTENCIA Peligro para la salud No beba el agua acumulada en el balde de agua. No seguir esta instrucción puede perjudicar su salud. Método para sacar y volver a vaciar el balde: 1.

[Page 20: Flotador De Nivel Del Agua Y Desconexión Automática](#)

Flotador de nivel del agua y desconexión automática Todos los deshumidificadores tienen mecanismo de desconexión automática y flotador de nivel del agua. Algunos deshumidificadores tienen un Flotador de Nivel del Agua ajustable. El balde tiene que estar debidamente alineado para que funcione el Flotador de Nivel del Agua.

[Page 21: Cuidado De Su Deshumidificador](#)

Cuidado de su deshumidificador Usted puede limpiar la parte exterior de su producto: Limpieza y mantenimiento generales 1. Limpie la rejilla delantera y los paneles laterales con un cepillo suave o con la boquilla para quitar el polvo de su aspiradora.

[Page 22: Si Necesita Ayuda O Servicio Técnico](#)

EE.UU..... Llame al distribuidor de su localidad o llame gratis al Centro de Ayuda al Consumidor de Whirlpool al 1-800-253- 1301. Cuando llame para pedir ayuda, tenga listos el número del modelo, el número de serie, la fecha de compra y una descripción completa del...

[Page 23](#) Si necesita ayuda o servicio 3. Si necesita ayuda o servicio técnico en Canadá... Contacte al distribuidor que le vendió su aparato, o llame gratis al Centro de Ayuda al Consumidor, de 8:30 a.m. a 6:00 p.m. (EST), al 1-800-461-5681. Contacte a la sucursal de servicio directo o al centro de servicio autorizado más cercano para reparar...

[Page 24](#) Parte No. 1185020 Rev. A 1/02 ©2002 Todos los derechos reservados Impreso en los EE.UU.

