



Whirlpool DU900PCDQ2 Parts Manual

Undercounter dishwasher

1
2
3
4
5
6
7
8

--

•

Bookmarks

[Download this manual](#)

Quick Links






Illus.
Part
No.
No.

DESCRIPTION

- 1 3375274 Console
(Includes Item 2)
- 2 3376025 Insert, Console
- 3 3376028 Switch
- 4 3369529 Follower, Cam
- 5

16



3373626 Timer

6

3369415 Cam

7

304231 Screw,

8

3374712 Door Frame
(Includes Item 24)

9

3368953 Bolt, Latch

10

3372231 Lever, Latch

11

3369325 Switch, (2)

12

3368955 Pin, Switch (2)

13

3373621 Harness and
Protector

14

3376405 Elbow, Harness

15

3400803 Screw

16

3375473 Cover Timer

17

3375349 Knob, Timer

18

3368979 Spacer,
Corrugated

19

Panel, Front

3369769 (Black/White)

20

3374011 Retainer, Panel

21

98997 Clip, Harness

24

3374716 Channel, Retainer
(Also Order Item

#20)

25

3373234 Bearing,
Spring (2)

8-95 Litho In U.S.A. (dah)

FRAME AND CONSOLE PARTS

For Model: DU900PCDQ2

Designer White



16

13

15

17

25

12

10

8

14

15

16

17

18

19

20

21

24

25

25

25

25

25

25

25

9

7

5

11

10

12

10

8

14

15

16

17

18

19

20

21

24

25

25


25

25

25

25

ManualsLib.com



Refer To Dishwasher Replacement

Panel Part No. 675345.

1

UNDERCOUNTER
DISHWASHER

Part No. 870356



[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool DU900PCDQ2

[Dishwasher Whirlpool DU900PCDB0 Parts List](#)

Undercounter dishwasher (8 pages)

[Dishwasher Whirlpool DU900PCDB2 Parts Manual](#)

Undercounter dishwasher (8 pages)

[Dishwasher Whirlpool DU9000XR Series Use & Care Manual](#)

Undercounter dishwasher (16 pages)

[Dishwasher Whirlpool DU900PCDB4 Parts Manual](#)

Undercounter dishwasher (9 pages)

[Dishwasher Whirlpool DU900PCDB5 Parts List](#)

Undercounter dishwasher (9 pages)

[Dishwasher Whirlpool DU900PCDQ5 Use And Care Manual](#)

(72 pages)

[Dishwasher Whirlpool DU900PCDB6 Parts List](#)

Undercounter dishwasher (9 pages)

[Dishwasher Whirlpool DU900PCDQ3 Parts Manual](#)

Undercounter dishwasher (9 pages)

[Dishwasher Whirlpool DU900 Use And Care Manual](#)

Undercounter dishwasher (40 pages)

[Dishwasher Whirlpool DU920PWKT0 Use & Care Manual](#)

Undercounter (40 pages)

[Dishwasher Whirlpool FSP DU9000XR-4 Parts List](#)

Undercounter dishwasher (16 pages)

[Dishwasher Whirlpool DP920QWDB3 Use And Care Manual](#)

(29 pages)

[Dishwasher Whirlpool DU920PWKQ0 Use And Care Manual](#)

(27 pages)

[Dishwasher Whirlpool DU948 Use And Care Manual](#)

(36 pages)

[Dishwasher Whirlpool DU920PFGQ2 Installation Instructions Manual](#)

(18 pages)

[Dishwasher Whirlpool 940 Series Use And Care Manual](#)

Whirlpool dishwasher 940, 945 use & care guide (43 pages)

Summary of Contents for Whirlpool DU900PCDQ2

[Page 1](#) 3374011 Retainer, Panel 98997 Clip, Harness 3374716 Channel, Retainer (Also Order Item #20) 3373234 Bearing, Spring (2) 8–95 Litho In U.S.A. (dah) For Model: DU900PCDQ2 Designer White Refer To Dishwasher Replacement Panel Parts List No. 675345. UNDERCOUNTER DISHWASHER Part No. 870356...

[Page 2](#) INNER DOOR PARTS For Model: DU900PCDQ2 Designer White Illus. Part DESCRIPTION 3371481 Inner Door (Also Order Latch Door Kit 676413) 3376066 Latch, Detergent Dispenser 3369061 Snap, Detergent Dispenser 3369055 Actuator Assembly 3368967 Wet Agent, Dispenser 3369000 Draw Bar (Upper Dispenser)

[Page 3](#) TUB ASSEMBLY PARTS For Model: DU900PCDQ2 Designer White 870356...

[Page 4](#) 3369052 Deflector (2) 3375558 Heater 717273 Washer, Rubber (2) 3369073 Nut (2) (Heater Terminal) 3374621 Water Valve 304392 Screw 3369777 Thermostat, TUB ASSEMBLY PARTS For Model: DU900PCDQ2 Designer White Illus. Part DESCRIPTION 3373359 Thermostat 301958 Clamp 3376149 Shield, Thermostat 3370555 Bracket,...

[Page 5](#) PUMP AND MOTOR PARTS Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher. Pump Centering Tool Required For Pump Re-Assembling Order Item 31. 870356 For Model: DU900PCDQ2 Designer White...

[Page 6](#) (Includes Items 12, 13 & 22) See Note A. 3400001 Screw 3376402 Impeller, Wash (Includes Items 12 & 13) 3371152 Screw & Seal For Model: DU900PCDQ2 Designer White Illus. Part DESCRIPTION 302711 Seal, Pump Outlet 3369478 Outlet, Pump (Includes Item 13)

[Page 7](#) DISHRACK PARTS For Model: DU900PCDQ2 Designer White 870356...

[Page 8](#) Assembly (4) 3371663 Dishrack, Upper 717528 Trim, Basket 300086 Handle, Basket 3369347 Sprayarm, Lower 3367910 Cap, Nozzle 719576 Bearing, Nozzle DISHRACK PARTS For Model: DU900PCDQ2 Designer White Illus. Part DESCRIPTION OPTIONAL PARTS NOT INCLUDED PAINT, TOUCH-UP (1/2oz.) 72017 White 72107 Almond...