



Whirlpool GC1000PE Dimension Manual

Food-waste disposer

1

--

•

Bookmarks

--

[Download this manual](#)

Quick Links

®

PRODUCT MODEL NUMBER

GC1000PE

GC3000XE

GC1000XE


GC5000XE

GC2000PE

GC2000XE

Electrical: A 120-volt, 60-Hz, AC-only 15- or 20-amp fused, grounded electrical supply is required. It is recommended that a separate circuit serving only your food-waste disposer be provided. Time-delay fuse or circuit breaker is recommended.

For continuous feed models, install a 15- or 20-amp wall switch above the countertop and junction box inside cabinet as shown. (Switch and electrical wiring can be obtained locally.) Position switch in a convenient location. Connect switch to junction box.



Products, we reserve the right to change m
d-Waste Disposal
Whirlpool
ALL DIMENSIONS CORPORATION

OVERALL DIMENSIONS CORPORATION

A
D
Model No.

B* - Distance from bottom of sink to center line of disposer outlet. Add 1/2 inch when stainless steel sink is used.

IMPORTANT: Plumb waste line to prevent standing water in disposer motor housing.

dishwasher drain
connection

B*

C*

E

 B^*

C*

D

E

4''

6-5/16"

5"

4''

6-5/16"

5"


4''

6-5/16"


5"

4''

6-5/16"



Lib.com



Related Manuals for Whirlpool GC1000PE

[Garbage Disposal Whirlpool GC1000XE Installation Care And Use Manual](#)

Food waste disposer (2 pages)

[Garbage Disposal Whirlpool GC2000 Use And Care Manual](#)

Food waste disposers (9 pages)

[Garbage Disposal WHIRLPOOL 4211597 Installation Instructions](#)

(5 pages)

[Garbage Disposal Whirlpool GC5000XE Parts List](#)

Whirlpool disposer parts list (2 pages)

[Garbage Disposal Whirlpool GC1000XE - 1/3 HP Continuous-Feed Food Disposal Warranty](#)

Warranty (1 page)

[Garbage Disposal Whirlpool GC1000 Use And Care Manual](#)

(9 pages)

[Garbage Disposal Whirlpool GC2000 Warranty](#)

Whirlpool washer - front load washing machine user manual (1 page)

[Garbage Disposal Whirlpool GC1000PE1 Parts List](#)

Whirlpool disposer parts list (2 pages)

[Garbage Disposal Whirlpool GC2000PE1 Parts Manual](#)

Disposer (2 pages)

[Garbage Disposal Whirlpool GC2000PE2 Parts Manual](#)

Whirlpool disposer parts manual (2 pages)

[Garbage Disposal Whirlpool GC5000XE2 Parts List](#)

Whirlpool disposer parts list (2 pages)

[Garbage Disposal WHIRLPOOL GC2000XE5 Installation Instructions](#)

(2 pages)

[Garbage Disposal Whirlpool GX900QPPQ0 Use & Care Manual](#)

(16 pages)

Related Products for Whirlpool GC1000PE

[Whirlpool GX900QPPT0](#)

[Whirlpool GX900QPPQ0](#)

[Whirlpool GC900QPPQ0](#)

[Whirlpool GX900QPPS0](#)

[Whirlpool GX900QPPB0](#)

[Whirlpool GC900QPPB0](#)

[Whirlpool GC1000](#)

[Whirlpool GC5000XE5](#)

[Whirlpool GC2000](#)

[Whirlpool GC2011HNKBS](#)

[Whirlpool GC5SHAXVS - 24.6 Cubic Foot Flat Texture Coun](#)

[Whirlpool GC4000](#)

[Whirlpool GCI3061X](#)

[Whirlpool GC5SHEXNS02](#)

[Whirlpool GC5SHEXNT02](#)

[Whirlpool GC5SHEXNQ04](#)

This manual is also suitable for:

[Gc2000pe](#)[Gc2000xe](#)[Gc3000xe](#)[Gc5000xe](#)[Gc1000pea](#)[Gc1000xea](#) ... [Show all](#)