




Whirlpool W10282149B Use And Care Manual

Whirlpool ice maker user manual

1	
Table Of Contents	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	

18
19
20
21
22
23
24
25
26
27
28

•

-


Troubleshooting

•

Bookmarks

--

Available languages



Quick Links

[1 How Your Ice Maker Works](#)


[2 Cleaning](#)

[3 Ice Maker Operation](#)

[4 Troubleshooting](#)

[5 Ice Production](#)

[Download this manual](#)



®

ICE MAKER

are Guide

For questions about features, operation/performance, parts, accessories or service, call: 1-800-253-1301.

In Canada, for assistance, installation or service call: 1-800-867-6777 or visit our website at...

www.whirlpool.com or www.whirlpoolappliances.ca

MACHINE À GLAÇONS

sation

Au Canada, pour assistance, installation



ou service, appeler le : 1-800-807-6777
ou visitez notre site web à
www.whirlpoolappliances.ca

Table of Contents/Table des matières2

W10282149B



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool W10282149B

[Ice Maker Whirlpool W10136155B Use And Care Manual](#)

Whirlpool ice maker use & care guide (28 pages)

[Ice Maker Whirlpool W10206421B Use And Care Manual](#)

Whirlpool ice maker use and care guide (32 pages)

[Ice Maker Whirlpool W11517113 Installation Manual](#)

(32 pages)

[Ice Maker Whirlpool ICE MAKER User Manual](#)

Whirlpool ice maker (17 pages)

[Ice Maker Whirlpool R-106 Training Manual](#)

Ice maker familiarization and troubleshooting (34 pages)

[Ice Maker Whirlpool AGB 024/01/G/WP Service Manual](#)

Ice cube maker (6 pages)

[Ice Maker Whirlpool AGH 326/01/G/NE Service Manual](#)

Ice cube maker (5 pages)

[Ice Maker Whirlpool AGS 836 Technical & Service Manual](#)

Ice cube makers (25 pages)

[Ice Maker Whirlpool AGH 327/01/G/NE Service Manual](#)

Ice cube maker (5 pages)

[Ice Maker Whirlpool GI1500XH Technical Manual](#)

15 inch automatic ice maker (40 pages)

[Whirlpool WUI95X15HZ - 15-inch Icemaker with Clear Ice Technology Manual](#)

(article)

[Ice Maker Whirlpool uki1500axx Installation Instructions Manual](#)

Automatic ice maker kit in side by side refrigerators (9 pages)

[Ice Maker Whirlpool EZ CONNECT Installation Manual](#)

(57 pages)

[Ice Maker Whirlpool K20 Instructions For Use And Installation](#)

(8 pages)

[Ice Maker Whirlpool W10190965 Installation Instructions](#)

(2 pages)

[Ice Maker Whirlpool WUI95X15HZ Installation Instructions Manual](#)

(36 pages)

Summary of Contents for Whirlpool W10282149B

[Page 1: Ice Maker](#)

For questions about features, operation/performance, parts, accessories or service, call: 1-800-253-1301. In Canada, for assistance, installation or service call: 1-800-807-6777 or visit our website at... www.whirlpool.com or www.whirlpoolappliances.ca MACHINE À GLAÇONS Guide d'utilisation et d'entretien Au Canada, pour assistance, installation ou service, appeler le : 1-800-807-6777 ou visitez notre site web à...

[Page 2: Table Of Contents](#)

ICE MAKER SAFETY... 2 INSTALLATION INSTRUCTIONS ... 3 Unpack the Ice Maker... 3 Location Requirements... 3 Electrical Requirements ... 4 Water Supply Requirements... 4 Leveling ... 4 Connect Water Supply... 5 Drain Connection ... 6 Ice Maker Door ... 7 Normal Sounds ...

[Page 3: Installation Instructions](#)

IMPORTANT SAFETY INSTRUCTIONS WARNING : To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic precautions : Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord.

[Page 4: Electrical Requirements](#)

Electrical Requirements WARNING Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. Before you move your ice maker into its final location, it is important to make sure you have the proper electrical connection: A 115 Volt, 60 Hz., AC only, 15- or 20-amp electrical supply,...

[Page 5: Connect Water Supply](#)

Plumbing shall be installed in accordance with the International Plumbing Code and any local codes and ordinances. Use copper tubing or Whirlpool supply line, Part Number 8212547RP, and check for leaks. Install tubing only in areas where temperatures will remain above freezing.

[Page 6: Drain Connection](#)

Gravity Drain System Connect the ice maker drain to your drain in accordance with all state and local codes and ordinances. If the ice maker is provided with a gravity drain system, follow these guidelines when installing drain lines. This will help keep water from flowing back into the ice maker storage bin and potentially flowing onto the floor, causing water damage.

[Page 7: Ice Maker Door](#)

Tools needed: Gather the required tools and parts before starting installation. " wrench " wrench
Hinge pin Handle screw Remove door 1. Unplug ice maker or disconnect power. 2. Remove the handle screws and handle (on some models). Keep the parts together and set them aside. 3.

[Page 8: Normal Sounds](#)

Reverse Door Catch 1. Remove the hole plugs from the opposite side of the door and set aside. 2. Remove the screws from the magnetic door catch and replace it on the opposite side of the door. 3. Push the hole plugs into place on the opposite side of the door.

[Page 9: Using The Controls](#)

5. Cubes fall into the storage bin. When the bin is full, the ice maker shuts off automatically and restarts when more ice is needed. The ice bin is not refrigerated, and some melting will occur. The amount of melting varies with room temperature. NOTE: As the room and water temperatures vary, so will the amount of ice produced and stored.

[Page 10: Condenser](#)

8. After the cleaning cycle is complete, remove the drain cap from the water pan. Look for any cleaning solution left in the water pan. If cleaning solution drains from the water pan, you should run the clean cycle again. Be sure to replace the drain cap securely on the water pan.

[Page 11: Vacation And Moving Care](#)

9. Remove, clean and replace the ice scoop and ice scoop holder. After removing the ice scoop, remove the holder by removing the two thumb screws. Wash the ice scoop holder along with the other interior components using the following instructions. Replace the ice scoop holder by replacing the thumb screws.

[Page 12: Troubleshooting](#)

Try the solutions suggested here first in order to avoid the cost of an unnecessary service call. Ice Maker Operation Your ice maker will not operate WARNING Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter.

[Page 13: Ice Quality](#)

Call a licensed, qualified plumber. ASSISTANCE OR SERVICE For further assistance If you need further assistance, you can write to Whirlpool Corporation with any questions or concerns at: Whirlpool Brand Home Appliances Customer eXperience Center...

[Page 14: Warranty](#)

Whirlpool Corporation or Whirlpool Canada LP (hereafter "Whirlpool") will pay for Factory Specified Parts and repair labor to correct defects in materials or workmanship. Service must be provided by a Whirlpool designated service company. This limited warranty is valid only in the United States or Canada and applies only when the major appliance is used in the country in which it was purchased.

[Page 15: Sécurité De La Machine À Glaçons](#)

SÉCURITÉ DE LA MACHINE À GLAÇONS Votre sécurité et celle des autres est très importante. Nous donnons de nombreux messages de sécurité importants dans ce manuel et sur votre appareil ménager. Assurez-vous de toujours lire tous les messages de sécurité et de vous y conformer. Voici le symbole d'alerte de sécurité.

[Page 16: Exigences D'emplacement](#)

Exigences d'emplacement Pour assurer une bonne aération de la machine à glaçons, l'avant doit être complètement dégagé. Les trois autres côtés et le dessus de la machine à glaçons peuvent être dissimulés, mais l'installation doit permettre de tirer la machine à glaçons vers l'avant pour l'entretien, si nécessaire.

[Page 17: Nivellement](#)

Code International de plomberie et respecter les codes et règlements locaux de plomberie. Utiliser un tuyau en cuivre ou le tuyau d'alimentation Whirlpool, pièce numéro 8212547RP et vérifier s'il y a des fuites. Installer les tuyaux seulement là où les températures resteront au-dessus du point de congélation.

[Page 18: Raccordement Au Drain De Vidange](#)

3. On est maintenant prêt à connecter le tuyau en cuivre. Utiliser un tuyau en cuivre souple de ¼" (6,35 mm) de diamètre extérieur pour l'alimentation en eau froide. S'assurer d'avoir la longueur nécessaire pour le raccordement. S'assurer que les deux extrémités du tuyau en cuivre sont bien coupées à...

[Page 19](#) VUE LATÉRALE 1 " (4,8 cm) 23" (58,4 cm) 2" - 1 " (5 cm - 3,8 cm) A. Tuyau de vidange B. Écart anti-retour de 1" (2,54 cm) C. Réducteur du drain de vidange PVC D. Le centre du drain doit se trouver à 23" (58,4 cm) du devant de la porte avec ou sans le panneau de drain doit aussi être centré...

[Page 20: Porte De La Machine À Glaçons](#)

Outils nécessaires : Rassembler les outils et pièces nécessaires avant de commencer l'installation. Clé de " Couteau à mastic plat Clé de " Tournevis Phillips Vis de charnière à tête hexagonale Vis de poignée Dépose de la porte 1. Débrancher la machine à glaçons ou déconnecter la source de courant électrique.

[Page 21: Sons Normaux](#)

Inversion du loquet de porte 1. Ôter les bouchons de trous du côté opposé de la porte et les mettre de côté. 2. Ôter les vis du loquet de porte magnétique et les réinstaller du côté opposé de la porte. 3.

[Page 22: Utilisation Des Commandes](#)

3. L'eau contenant les déchets minéraux est évacuée après chaque programme de congélation. 4. De l'eau fraîche s'infiltré de nouveau dans la machine en vue du prochain programme de fabrication de glaçons. 5. Les glaçons tombent dans le bac d'entreposage. La machine à...

[Page 23](#) 6. Verser une bouteille de cette solution dans le bac à eau. Remplir la bouteille à deux reprises avec de l'eau du robinet et verser le contenu dans le bac à eau. A. Bac à eau B. Vis à ailette du bac à eau C.

[Page 24: Précautions À Prendre Avant Les Vacances Ou Un Déménagement](#)

7. Retirer les vis de droite et de gauche. Soulever la grille de coupe et la sortir. REMARQUE : Il faut s'assurer que la cale d'espacement en plastique du côté droit du support de la grille de coupe suit cette dernière. A.

[Page 25: Dépannage](#)

5. Déconnecter les canalisations d'entrée et de sortie sur le robinet. Laisser l'eau s'écouler des canalisations, puis reconnecter les canalisations au robinet. 6. Réinstaller le panneau de l'ouverture d'accès inférieure et les vis. 7. Évacuer l'eau du bac à eau (ôter le capuchon de vidange). 8.

[Page 26: Qualité Des Glaçons](#)

Références aux concessionnaires, compagnies de service de réparation et distributeurs de pièces de rechange locaux. Les techniciens de service désignés par Whirlpool Canada sont formés pour remplir la garantie des produits et fournir un service après la garantie, partout au Canada.

[Page 27: Garantie](#)

5. Les défauts apparents, notamment les éraflures, les bosses, fissures ou tout autre dommage au fini du gros appareil ménager, à moins que ces dommages soient dus à des vices de matériaux ou de fabrication et soient signalés à Whirlpool dans les 30 jours suivant la date d'achat.

[Page 28](#) ® Registered Trademark/TM Trademark of Whirlpool, U.S.A., Whirlpool Canada LP Licensee in Canada Tous droits réservés. ® Marque déposée/TM Marque de commerce de Whirlpool, U.S.A., emploi sous licence par Whirlpool Canada LP au Canada Nom du marchand

____ Adresse
____ Numéro de téléphone
____ ...

This manual is also suitable for:

[gi15ndxxb](#) [gi15ndxxq](#) [gi15nfrxb](#) [gi15nflxb](#) [gi15ndxxs](#) [gi15nflxs](#) ... [Show all](#)