



Whirlpool GH4155XPB0 Parts Manual

Whirlpool microwave hood combination parts list

1
2
3
4
5
6
7

--

•

Bookmarks

Quick Links

[Download this manual](#) See also: [Use and Care Manual](#)



6-04 Litho In U.S.A. (jac)



CONTROL PANEL PARTS

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0
(White)

Illus.

Part

No.

No.

1

8204919 Use & Care Guide

8183731 Installation

8204908 Tech Sheet

8204929 Guide, Cooking



Literature Parts



3

8205330

8205331 Black

8205332 Biscuit

4

8183821 Bracket, Control

5

4393744 Plate, Hinge

6

8183726 Microcomputer

8

4393346 Screw

(Black)

(Biscuit)

DESCRIPTION

Literature Parts

Instructions

(Label)

Panel, Control



1

MICROWAVE

HOOD

COMBINATION

Part No. 8205163



[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool GH4155XPB0

[Microwave Oven WHIRLPOOL GH4155XPQ0 Use & Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven Whirlpool GH4155XP Use And Care Manual](#)

Whirlpool microwave hood combination use & care guide gh4155xp (20 pages)

[Microwave Oven Whirlpool GH4155XPQ Installation Instructions Manual](#)

Installation instructions (11 pages)

[Microwave Oven WHIRLPOOL 8183878-D-WH Dimensions And Installation Information](#)

(1 page)

[Microwave Oven WHIRLPOOL 8205964 Use And Care Manual](#)

(20 pages)

[Microwave Oven Whirlpool GH4155XP Use And Care Manual](#)

(20 pages)

[Microwave Oven Whirlpool GH4155XPB1 Parts Manual](#)

Whirlpool corporation microwave hood parts manual (7 pages)

[Microwave Oven Whirlpool GH4155XPB2 Parts Manual](#)

Whirlpool corporation microwave hood parts manual (7 pages)

[Microwave Oven Whirlpool GH4155XPB3 Parts Manual](#)

Whirlpool microwave/hood combination installation guide (7 pages)

[Microwave Oven Whirlpool GH4155XPS1 Parts Manual](#)

Whirlpool microwave hood combination parts list (7 pages)

[Microwave Oven Whirlpool GH4155XPS2 Parts Manual](#)

Whirlpool microwave hood combination control panel parts manual (7 pages)

[Microwave Oven Whirlpool GH4155XPS3 Parts Manual](#)

Whirlpool corporation microwave hood parts manual (7 pages)

[Microwave Oven Whirlpool GH4184XS Use And Care Manual](#)

Whirlpool microwave hood combination gh4184xs use & care guide (20 pages)

[Microwave Oven Whirlpool MH3184XPS Dimensions](#)

Microwave hood combination (1 page)

[Microwave Oven Whirlpool GH4184XSS0 Use & Care Manual](#)

Hood combination (20 pages)

[Microwave Oven Whirlpool MH3184XPB Service Manual](#)

Microwave oven/hood combination (71 pages)

Summary of Contents for Whirlpool GH4155XPB0

[Page 1: Control Panel Parts](#)

CONTROL PANEL PARTS For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 6-04 Litho In U.S.A. (jac) (White) (Black) Illus. Part DESCRIPTION Literature Parts 8204919 Use & Care Guide 8183731 Installation Instructions 8204908 Tech Sheet 8204929 Guide, Cooking (Label) Panel, Control 8205330 White 8205331 Black...

[Page 2: Door Parts](#)

For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 Illus. Part DESCRIPTION 8169545 Frame, Inner 4393913 Latch, Door Body, Door 8185107 White 8185109 Black 8185108 Biscuit DOOR PARTS (White) (Black) Illus. Part DESCRIPTION Handle, Door 4393777 White 4393782 Black 8169642 Biscuit 4393833 Screw (Biscuit) Illus.

[Page 3](#) INTERIOR AND VENTILATION PARTS For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) (Black) (Biscuit) 8205163...

[Page 4](#) INTERIOR AND VENTILATION PARTS For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 (White) Illus. Part 4393688 Reflector, Lamp 4393681 Lamp (2) 8169645 Filter, Charcoal 8169758 Filter, Grease 8185105 Plate, Bottom 8185210 Glass, Lamp 8184308 Holder, Glass 8205045 Guide, Air 8183823 Cover, Fan 8204656 Switch, Micro (3)

[Page 5](#) For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 Illus. Part DESCRIPTION 8184638 Deflector, Air 8169557 Reflector, Air 8185083 Duct, Air 8204653 Bracket, Thermostat 8183697 Thermostat 8184745 Housing, Lamp 4393681 Lamp 8204694 Wheel, Fan 8205163 AIR FLOW PARTS (White) (Black) Illus. Part DESCRIPTION 8204751 Motor, Fan...

[Page 6](#) MAGNETRON AND TURNTABLE PARTS For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 Illus. Part DESCRIPTION 8205044 Motor, Stirrer 8205315 Stirrer Shaft/Blade 8184476 Cover, Inlet 8204662 Hook, Rack (4) 8184549 Nails/Bushings (5 of Each) 4393799 Turntable 8184102 Ring, Turntable (White) (Black) Illus. Part DESCRIPTION...

[Page 7](#) CABINET AND INSTALLATION PARTS For Models: GH4155XPQ0, GH4155XPB0, GH4155XPT0 Illus. Part DESCRIPTION 8205317 Plate, Mounting 8183858 Door, Damper 8184313 Lid, Power Cord 8184898 Cord, Power Case, Outer 8169660 White 8169661 Black 8169664 Biscuit Grille, Vent 8183948 White 8183851 Black 8183852 Biscuit...

This manual is also suitable for:

[Gh4155xpq0Gh4155xpt0](#)