

Whirlpool MFL57066201 Use And Care Manual

Whirlpool microwave oven use & care guide

Table of Contents

•

Troubleshooting


•

Bookmarks

•

Quick Links

- 1 Table of Contents
- 2 Location Requirements
- 3 Installation Instructions
- 4 Troubleshooting
- 5 Replacement Parts
- 6 Built-In Kits



MICROWAVE OVEN

Use & Care Guido

For questions about features, operation/performance, parts, accessories or service, call: 1-800-255-1301. or visit our website at...

www.whirlpool.com Table of Contern

R

Model MT4155

W10217293

Table of Contents

Next Page

Related Manuals for Whirlpool MFL57066201

Oven Whirlpool GBS277PDB Technical Manual Electric built-in single oven (61 pages) Microwave Oven Whirlpool MT4155SPS3 Use & Care Manual (16 pages) Microwave Oven Whirlpool MT4155 Use And Care Manual Whirlpool microwave oven use & care guide (16 pages) Microwave Oven Whirlpool MT4155SP Use And Care Manual Whirlpool microwave oven use&careguide mt4155sp (16 pages) Microwave Oven WHIRLPOOL 8205987 Use And Care Manual (16 pages) Accessories WHIRLPOOL BUILT-IN TRIM KIT Installation Instructions Manual Microwave oven built-in trim kit (8 pages) **Oven Whirlpool GBD277PDS Dimension Manual** 7" electric built-in single and double ovens (1 page) Microwave Oven Whirlpool 8205085 Dimension Manual Countertop microwave ovens (1 page) Microwave Oven Whirlpool MH3184XP Use & Care Manual Whirlpool microwave hood combination mh3184xp use & care guide (16 pages) Microwave Oven Whirlpool MH6110XE Use And Care Manual Whirlpool microwave hood combination use and care guide mh6110xe (50 pages) Microwave Oven Whirlpool MT6120XBB Use And Care Manual Whirlpool microwave oven use and care guide mt6120xbb, mt6120xbg (51 pages) Microwave Oven Whirlpool MWX203 User Manual (14 pages) Microwave Oven Whirlpool MWO 616/01 SL Instructions For Use Manual (64 pages) Microwave Oven Whirlpool MWH 303 Instruction Manual (32 pages) Microwave Oven Whirlpool COOK 30 Manual (24 pages) Microwave Oven Whirlpool COOK20 MWP201SB Instructions For Use Manual (10 pages)

Summary of Contents for Whirlpool MFL57066201

Page 1 ® MICROWAVE OVEN Use & Care Guide For questions about features, operation/performance, parts, accessories or service, call: 1-800-253-1301. or visit our website at... www.whirlpool.com Table of Contents ... 2 Model MT4155 W10217293A...

Page 2: Table Of Contents

TABLE OF CONTENTS MICROWAVE OVEN SAFETY...3 INSTALLATION INSTRUCTIONS ...5 Unpacking ...5 Location Requirements...5 Electrical Requirements ...5 PARTS AND FEATURES...6 Turntable ...6 MICROWAVE OVEN CONTROL...6 Display...6 Start ...7 Jet Start Feature...7 Off...7 Clock ...7 Tones...7 Timer...7 Control Lock...7 Demo Mode...7 Options ...7 MICROWAVE OVEN USE ...8 Food Characteristics...8 Cooking Guidelines ...8...

Page 3: Microwave Oven Safety

MICROWAVE OVEN SAFETY Your safety and the safety of others are very important. We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages. This is the safety alert symbol. This symbol alerts you to potential hazards that can kill or hurt you and others.

Page 4: Precautions To Avoid Possible Exposure To Excessive Microwave Energy

IMPORTANT SAFETY INSTRUCTIONS ■ Do not operate any heating or cooking appliance beneath the microwave oven. ■ Do not mount microwave oven over or near any portion of a heating or cooking appliance. ■ Do not use paper products when appliance is operated in convection, combination, grill or "PAN BROWN"...

Page 5: Installation Instructions

INSTALLATION INSTRUCTIONS Unpacking 1. Empty the microwave oven of any packing materials. 2. Clean the inside with a soft, damp cloth. 3. Check for damage, such as: \blacksquare a door that is not lined up correctly \blacksquare damage around the door, or \blacksquare ...

Page 6: Parts And Features

PARTS AND FEATURES This manual may cover several different models. The model you have purchased may have some or all of the features shown here. The appearance of your particular model may differ slightly from the illustrations in this manual. A.

Page 7: Start

Start The START pad begins any function. If non-sensor cooking is interrupted, touching START will resume the preset cycle. Touching START will not resume an interrupted sensor cycle. Jet Start Feature The JET START control (START pad) automatically starts the microwave oven at 100% power for 30 seconds, and adds 30 seconds of cook time, up to 3 minutes, then 1 minute of cook time, up to 10 minutes with each additional touch of the control.

Page 8: Microwave Oven Use

A magnetron in the microwave oven produces microwaves which reflect off the metal floor, walls and ceiling and pass through the turntable and appropriate cookware to the food. Microwaves are attracted to and absorbed by fat, sugar and water molecules in the food, causing them to move, producing friction and heat which cooks the food.

Page 9: Aluminum Foil And Metal

MATERIAL RECOMMENDATIONS Melamine Follow manufacturer's recommendations. Paper: Towels, Use nonrecycled and those approved by Dinnerware, the manufacturer for microwave oven use. Napkins Plastic: Wraps, Use those approved by the manufacturer Bags, Covers, for microwave oven use. Dinnerware, Containers Pottery and Clay Follow manufacturer's recommendations.

Page 10: Cooking In Stages

Cooking in Stages The microwave oven can be set to cook at different cooking powers for various lengths of time, up to 3 stages, plus a defrosting stage. To Cook in Stages: 1. Place food on the turntable and close the door. 2.

Page 11: Sensor Cook

Sensor Cook The sensor in the microwave oven detects humidity released from the food and automatically sets a cooking time based on the selected food category. Use the following chart as a guide. FOOD QUANTITY/INSTRUCTIONS Baked 1-4 medium, 10-13 oz (283-369 g) each/Potatoes Pierce each one several times with a fork.

Page 12: Auto Defrost

Auto Defrost The Auto Defrost feature's preset programs can be used or the microwave oven can be manually set to defrost. I Unwrap foods and remove lids (for example, from fruit juice containers) before defrosting. Shallow packages will defrost more quickly than deep blocks.

Page 13: Microwave Oven Care

IMPORTANT: Before cleaning, make sure all controls are off and the microwave oven is cool. Always follow label instructions on cleaning products. Soap, water and a soft cloth or sponge are suggested unless otherwise noted. MICROWAVE OVEN CAVITY To avoid damage to the microwave oven cavity, do not use soap- filled scouring pads, abrasive cleaners, steel-wool pads, gritty washcloths or some recycled paper towels.

Page 14: Troubleshooting

Try the solutions suggested here first in order to avoid the cost of an unnecessary service call. Nothing will operate \blacksquare Has a household fuse blown, or has a circuit breaker tripped? Replace the fuse or reset the circuit breaker. If the problem continues, call an electrician.

Page 15: Assistance Or Service

To locate the Whirlpool designated service company in your area, you can also look in your telephone directory Yellow Pages. For further assistance If you need further assistance, you can write to Whirlpool Corporation with any questions or concerns at: Whirlpool Brand Home Appliances Customer eXperience Center...

Page 16: Warranty

Whirlpool Corporation or Whirlpool Canada LP (hereafter "Whirlpool") will pay for Factory Specified Parts and repair labor to correct defects in materials or workmanship. Service must be provided by a Whirlpool designated service company. This limited warranty is valid only in the United States or Canada and applies only when the major appliance is used in the country in which it was purchased.

This manual is also suitable for:

W10188233aW10217293a mt4155spt mt4155spb mt4155spq mt4155sps ... Show all