

Setting The Clock - Whirlpool MG2070XAQ Use And Care Manual

Vip crispwave microwave oven with grill element

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

•

[Table of Contents](#)

•

Bookmarks



GETTING TO KNOW YOUR MICROWAVE OVEN

Setting the clock

When your microwave oven is first plugged in or after a power failure, the Display will only show "?". If a time of day is not set, then the Display will only show ":" until the cooking time is set.

NOTE: You can only set the clock if the oven is not cooking food or timing with the Minute Timer.

To set time:

YOU SEE

(you will hear 3 short tones)

2. Enter time of day.

Setting the clock

When your microwave oven is first plugged in or after a power failure, the Display will only show "?". If a time of day is not set, then the Display will only show ":" until the cooking time is set.

NOTE: You can only set the clock if the oven is not cooking food or timing with the Minute Timer.

TOUCH

q mm

(example for 530)

3. Exit from clock setting.

TOUCH

YOU SEE

NOTE: If you touch CANCEL while setting the clock, the clock will be cleared and the Display

will show "Y".

(set time)

16

GETTING TO KNOW YOUR MICROWAVE OVEN

Setting the clock

When your microwave oven is first plugged in

NOTE: You can only set

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

[1](#)
[...](#)
[13](#)
[14](#)
[15](#)
[16](#)
[17](#)
[18](#)
[19](#)
[20](#)

Quick Links:

[Getting to Know Your Microwave Oven](#)

[Table of Contents](#)

[Microwave Oven Features](#)

[Control Panel Features](#)

Chapters

[Getting to Know Your Microwave Oven](#) 10

[With Microwaves Cooking Only](#) 18

Related Manuals for Whirlpool MG207OXAQ

[Microwave Oven Whirlpool MG8120XD Use And Care Manual](#)

Vip crispwave microwave oven with grill element (67 pages)

[Microwave Oven Whirlpool MG2006W Health & Safety, Use & Care, Installation Manual And Online Warranty Registration Information](#)

(26 pages)

[Microwave Oven Whirlpool MH1160XS Use & Care Manual](#)

Whirlpool microwave hood combination use & care guide mh1160xs (16 pages)

[Microwave Oven Whirlpool GH9115XE Use And Care Manual](#)

Whirlpool microwave hood combination use & care guide gh9115xe, mh9115xe (81 pages)

[Microwave Oven Whirlpool YMH6130XE Use And Care Manual](#)

(60 pages)

[Microwave Oven Whirlpool MH6150XM Use & Care Manual](#)

Whirlpool microwave hood combination use & care guide mh6150xm (16 pages)

[Microwave Oven Whirlpool MH6110XE Use And Care Manual](#)

Whirlpool microwave hood combination use and care guide mh6110xe (50 pages)

[Microwave Oven Whirlpool MH7140XF Use & Care Manual](#)

Whirlpool microwave hood combination mh7140xf, ymh7140xf user guide (48 pages)

[Microwave Oven Whirlpool MH7140XFZ0 Use & Care Manual](#)

Microwave hood combination (49 pages)

[Microwave Oven Whirlpool MHE14XM Use And Care Manual](#)

Whirlpool use & care guide microwave hood combination mhe14xm (16 pages)

[Microwave Oven Whirlpool MT4210SL Use & Care Manual](#)

Whirlpool microwave ovens use & care guide mt4210sl, 3828w5a2461/8184647 (24 pages)

[Microwave Oven Whirlpool MT9160XY Use And Care Manual](#)

Whirlpool microwave oven use & care guide mt9160xy (40 pages)

[Microwave Oven Whirlpool MWX203 User Manual](#)

(14 pages)

[Microwave Oven Whirlpool MWN 400 Instructions For Use Manual](#)

(29 pages)

[Microwave Oven Whirlpool AMW 494 Installation, Quick Start](#)

(17 pages)

[Microwave Oven Whirlpool COOK20 MWP201SB Instructions For Use Manual](#)

(10 pages)

Related Content for Whirlpool MG207OXAQ

[YMH6130XE Setting The Clock](#)

Whirlpool YMH6130XE

[AMW509/IX Setting The Clock](#)

Whirlpool AMW509/IX

[AMW 523 Clock Setting](#)

Whirlpool AMW 523

[AVM 754 Clock Setting](#)

Whirlpool AVM 754

[AMW 833 Clock Setting](#)

Whirlpool AMW 833
[AMW 798 Clock Setting](#)

Whirlpool AMW 798
[AMW 831 Clock Setting](#)

Whirlpool AMW 831
[AMW 761 Clock Setting](#)

Whirlpool AMW 761

This manual is also suitable for:

[Mg2070xabMg3090xabMg3090xaq](#)