



Whirlpool MH1170XSS2 Parts List

Microwave oven 1.7 cu. ft.

1
2
3
4
5
6
7

--

•

Bookmarks

Quick Links

[Download this manual](#) See also: [Use and Care Manual](#)



For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2
9-07 Litho in U.S.A. (rek)

CONTROL PANEL PARTS

(White) **Whirlpool**
(Biscuit) (Stainless Steel) (Universal Silver)

Illus.

Part


No.

No.

DESCRIPTION

1

Literature 1 →
W10110883 U & C Guide



W10132039 Tech Sheet
8205885 Cook Guide Label
8206587 Install, Instruct.

2

Panel Asy Control

Includes Lens and

Membrane Switch

W10166189 White

W10166192 Biscuit

W10166191 Stainless/Unv.Slv.

3 W10166184 Bracket, Control



4 W10166188 Microcomputer

1

Microwave Oven

1.7 Cu. Ft.

Part No. W10166281 Rev. B



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool MH1170XSS2

[Microwave Oven Whirlpool MH1170XSQ2 Use & Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven Whirlpool MODEL MH1170XS Use & Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven Whirlpool MH1170XSB Installation Instructions Manual](#)

Microwave hood combination (12 pages)

[Microwave Oven WHIRLPOOL 8206540 Use And Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven WHIRLPOOL 8206572 Use And Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven Whirlpool MH1170XS Installation Instructions Manual](#)

Microwave hood combination (12 pages)

[Microwave Oven Whirlpool MH1170XST Use And Care Manual](#)

Microwave hood combination (20 pages)

[Microwave Oven Whirlpool GMH3174XV Dimensions](#)

Microwave hood combination (1 page)

[Microwave Oven Whirlpool MH1160XS Product Dimensions](#)

Microwave hood combination (1 page)

[Microwave Oven WHIRLPOOL 8206555-D-WH Dimensions And Installation Information](#)

(1 page)

[Microwave Oven Whirlpool MH2175XS Installation Instructions Manual](#)

Whirlpool mh2175xs: install guide (12 pages)

[Microwave Oven Whirlpool MH2175XSS User Instructions](#)

Microwave hood combination (6 pages)

[Microwave Oven Whirlpool MH1170XSB1 Parts List](#)

Microwave oven 1.7 cu. ft. (7 pages)

[Microwave Oven Whirlpool MH1170XSB2 Parts List](#)

Microwave oven 1.7 cu. ft. (7 pages)

[Microwave Oven Whirlpool MH1160XSB5 User Instructions](#)

Hood combination (6 pages)

[Microwave Oven Whirlpool MH1170XSY4 User Instructions](#)

Hood combination (6 pages)

Summary of Contents for Whirlpool MH1170XSS2

[Page 1: Control Panel Parts](#)

CONTROL PANEL PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2
9-07 Litho in U.S.A. (rek) (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus. Part
DESCRIPTION Literature W10110883 U & C Guide W10132039 Tech Sheet 8205885 Cook Guide
Label 8206587 Install, Instruct. Panel Asy, Control...

[Page 2: Door Parts](#)

DOOR PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus. Part DESCRIPTION COMPLETE DOOR 8206394 White 8206396 Stainless 8206397 Biscuit 8206398 Silver 2 W10138802 Screw W10166281...

[Page 3](#) INTERIOR AND VENTILATION PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 (White) (Biscuit) (Stainless Steel) (Universal Silver) W10166281...

[Page 4](#) INTERIOR AND VENTILATION PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus. Part 1 W10139751 Reflector, Lamp 8206232 Lamp 8206374 Holder, Lamp 8206229 Filter, Grease 8206386 Plate, Bottom 8206376 Glass, Lamp 8206375 Holder, Glass 8206345 Switch, Micro...

[Page 5](#) For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 Illus. Part DESCRIPTION 8206340 Deflector, Air 8206382 Cover, Lamp 4393681 Lamp 4 W10163433 Cover, Side Inlet 5 W10114550 Motor, Fan Assy 6 W10138797 Air Guide 8206230 Filter, Charcoal W10166281 AIR FLOW PARTS (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus.

[Page 6: Turntable Parts](#)

TURNTABLE PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus. Part 8206389 Cover, Inlet 8206118 Hook, Rack (4) 3 W10138801 Plastic Rivets (4) 4393799 Turntable 8206227 Ring, Turntable 8206228 Driver, Turntable 8183953 Motor, Turntable 8 W10149406 Rack...

[Page 7](#) CABINET AND INSTALLATION PARTS For Models: MH1170XSQ2, MH1170XST2, MH1170XSS2, MH1170XSY2 Illus. Part DESCRIPTION 8206315 Plate, Mounting 8206385 Support, Wire Clip 8206442 Damper Assembly 8206388 Cord, Power Case, Outer W10163417 White W10163418 Black W10163419 Biscuit W10166281 (White) (Biscuit) (Stainless Steel) (Universal Silver) Illus.

This manual is also suitable for:

[Mh1170xst2Mh1170xsy2Mh1170xsq2](#)