

Whirlpool R82200XK Use & Care Manual

30-inch built-in continuous-cleaning electric oven

Table of Contents

•

Bookmarks

•

Quick Links

1 Installation

2 Control Panel and Knobs

Download this manual





Plate Broil Elemenf Copy Your Model and Serial Numbers Here it yoU need service, o-call with a questio? have rh~s Information ready: Ч. 1 Complete Model anil Serial Numbers [from The plate lust behind the oven door) ,'>, 2 Purchase date from vour sales slop Copy this information In these spaces. Keep This oook your warranty and the sales slip together In a handy place. . Serwce Company ans1 Pnone hu?;ber See the "Cooking Guide"for important safety information.

Number



Table of Contents

Next Page

Related Manuals for Whirlpool R82200XK

Oven Whirlpool R8700PXS Use & Care Manual 27-inch built-in electric oven (12 pages) Oven Whirlpool RBS275PV Use And Care Manual Whirlpool built-in electric oven use and care guide (28 pages) Oven Whirlpool RB220PXB Use And Care Manual Standard and continuous-cleaning electric built-in ovens (26 pages) Oven Whirlpool RB275PXK Use & Care Manual Self-cleaning & continuous-cleaning built-in ovens (28 pages) Oven Whirlpool RB275PXV Use & Care Manual Self-cleaning & continuous-cleaning built-in ovens (28 pages) Oven Whirlpool RM278BXV Use & Care Manual Self-cleaning lower built-in oven (21 pages) Oven Whirlpool GMC275 Use And Care Manual Whirlpool electric combination lower oven use & care guide (16 pages) Oven Whirlpool RB1300XK Use & Care Manual 24-inch built-in continuous-cleaning electric ovens (16 pages) Oven Whirlpool RB16 PXB Use And Care Manual Whirlpool self-cleaning electric built-in single and double ovens (40 pages) Oven Whirlpool RB260PXK Use & Care Manual Electric oven 30-inch built-in (16 pages) Oven WHIRLPOOL RBS240PD Use And Care Manual Electric built-in ovens (47 pages) Oven Whirlpool RBS275PRB00 Oven Parts 27" built-in electric single oven (7 pages) Oven Whirlpool RBS305PRB00 Oven Parts 30" built-in electric oven (7 pages) Oven Whirlpool RM278BXS Use & Care Manual Lower oven self-cleaning (20 pages) Oven Whirlpool RS675PXGB7 Cooktop Parts 30" drop-in electric oven self clean (8 pages) Oven Whirlpool Super Capacity 465 Use & Care Manual 4.65 cubic foot oven (44 pages)

Summary of Contents for Whirlpool R82200XK

Page 1 Copy this information In these spaces. your warranty and the sales slip together place. See the "Cooking Models R82200XK; RB220PXK and Serial Numbers Copy Your Model have rh~s [from The plate Keep This oook In a handy...

Page 2: Installation

Your responsibilities.. Proper installation and safe use of the oven are your personal responsibilities. Read this "Use and Care Guide" and Guide" carefully for important Installation must be sure your oven is... installed and leveled in a wall or cabinet that will hold the weight;...

Page 4: Using Your Oven

Automatic MEALTIMER- Clock Start Time Knob Minute Timer SETTING goes off. the oven. Put food When done baking, turn both knobs to OFF. RESETTING THE OVEN TEMPERATURE CONTROL Does your new oven seem to be hotter or colder old oven? The temperature over the years.

Page 5: Oven Rack Positions

BROILING Place the rack where you want it for broiling. (See below for suggestions.) Set Oven Temperature Control to BROIL [Set on a lower temperature slower broiling. below Broiling can be slowed lower than BROIL When it's on BROIL, the broil element on a temperature, the element the shorter are the times when the element...

<u>Page 6</u> Su gested oven- di # erent kinds of Food Beef Steaks Rare Medium Well done Beef Steaks Rare Medium Well Done Hamburgers Lamb Chops Medium Ham slice, precooked or tendered Canadian Bacon Pork Rib or Loin Chop Well done Chicken Fish Liver Frankfurters...

<u>Page 7</u> USING THE AUTO~IIC The Automatic MEALTIMER Clock you setteven when you are not around. To start and stop baking automatically: Put the racks where want them and place food In the oven Push in and turn the Stop Time Knob clockwise to the time you want 'he oven to shut off After baking...

Page 8: The Oven Light

The oven light wrll come the Oven light Swatch Close the oven door or push the switch again light To replace the light bulb: Turn off the electric power at the main power supply THE OPTIONAL If you would like a rotisserie 261880) from your dealer.

Page 9: Cleaning And Caring For Your Oven

Cleaning and caring for your oven CONTROL PANEL AND KNOBS Use warm soapy First make sure knobs are on OFF water and a soft cloth to wipe then knob DUII straight off. the panel. and wipe dry. REMOVING Open the door to the first stop REPLACING Fit the bottom corners...

Page 10: The Continuous-Cleaning

THE OUTER OVEN WINDOW If your oven has a window frame can be removed for cleaning. With the door closed, remove the screws from the top of the outer wrndow frame REPLACING Fit the bottom tabs of the frame into the bottom of the window opening.

Page 11: Using Foil

Usrng foil on the oven bottom Cut foil from a roll of heavy-duty [Part No. 241430) from your Whirlpool Slide the foil under the bake Lift the cool bake element element. slightly to lift the feet off the Make sure foil is centered,...

Page 12: Hand Cleaning

Continuous- Worm, soopy woter cleaning oven scrubbing Heavy-duty aluminum ovoiloble ot grocery order Port No. 241430 from your Whirlpool deoler or your TECH-CARE a servrce representotive. Most fat spatters on the continuous-cleaning reduce presentably HAND CLEANING WINDOW-Keep clean wrth hot sudsy water...

Page 13 Guide for more informa- tion on cooking problems and how to solve them. If you need assistance"... Call the Whirlpool with- sistance telephone Continental U.S..(800) 253-1301 Michigan(800) 632-2243 Alaska &...

Page 14 (see Step 2) and talk with one of our Consultants, or if you prefer, write to Mr. Guy Turner, Vice President Whirlpool Corporation Adminrstrative Center 2000 US-33 North Benton Harbor. MI 49022 If you must call orwrite,...

Page 15 THIS PAGE INTENTIONALLY LEFT BLANK...

Page 16 " will fit right and work right. becawe made to the same exacting us6U to build every new Whirlpool appliance. ;_" ~tii&&+3+#-@ fztxc A __-. FSP Is a registered trademark of Whirlpool Corporation quality parts. Cook for this symbol of quality whenever ~ you need a

r&placement...

This manual is also suitable for:

Rb220pxk