



Whirlpool W10032070 User Manual

30" (76.2 cm) freestanding gas ranges

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

-

[Table of Contents](#)


•

Bookmarks

--

[Download this manual](#)

Quick Links



30" (76.2 CM) FREESTANDING GAS RANGES

RANGE SAFETY	2
INSTALLATION REQUIREMENTS	3
Tools and Parts	3
Location Requirements	4
Electrical Requirements	5
Gas Supply Requirements	6
INSTALLATION INSTRUCTIONS	7
Unpack Range	7
Install Anti-Tip Bracket	7
Make Gas Connection	9
Verify Anti-Tip Bracket Location	10

[Level Range](#) 10

[Electronic Ignition System](#) 10

[Complete Installation](#) 11

[GAS CONVERSIONS](#) 12

[LP Gas Conversion](#)..... 12

[Complete Conversion](#)..... 14

[Natural Gas Conversion](#)..... 14

[Complete Conversion](#)..... 16

IMPORTANT:

Installer: Leave installation instructions with the homeowner.

Homeowner: Keep installation instructions for future reference.

W10032070B

INSTALLATION INSTRUCTIONS

with standard clean oven

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool W10032070

[Cooktop Whirlpool SF110AXS Use And Care Manual](#)

Whirlpool standard cleaning gas range use and care guide (28 pages)

[Ranges Whirlpool WFG110AV Dimension Manual](#)

30" freestanding gas range (1 page)

[Cooktop Whirlpool G7CE3034 Use & Care Manual](#)

Electric cooktop (32 pages)

[Cooktop Whirlpool GAS ON METAL COOKTOP G7CG3665 Use And Care Manual](#)

Gas on metal cooktop (24 pages)

[Cooktop Whirlpool G7CG3064XS Installation Instructions Manual](#)

30" (76.2 cm) and 36" (91.4 cm) gas built-in cooktop (24 pages)

[Cooktop Whirlpool W5CG3625XB Installation Manual](#)

30" (76.2 cm) and 36" (91.4 cm) gas built-in cooktop (20 pages)

[Cooktop Whirlpool W10131955C Installation Instructions Manual](#)

30" (76.2 cm) and 36" (91.4 cm) gas built-in cooktop (24 pages)

[Cooktop Whirlpool WCG97US6HS Installation Instructions Manual](#)

(24 pages)

[Cooktop Whirlpool WCC31430AB Use & Care Manual](#)

Use & care guide (16 pages)

[Cooktop Whirlpool WCC31430AB Installation Instructions Manual](#)

Electric built-in cooktops 30" (76.2 cm) and 36" (91.4 cm) (12 pages)