



Whirlpool Washer/Dryer User Manual

27" (69 cm) electric washer/dryer

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

• PAGE

1

OF 44 GO


•

[Table of Contents](#)

•

Bookmarks

Available languages



Quick Links

[1 Installation Instructions](#)

[2 Table of Contents](#)

[3 Tools and Parts](#)


[4 Washer/Dryer Dimensions](#)

[5 Electrical Requirements - U.s.a](#)

[6 Electrical Connection - U.s.a. Only](#)

[Download this manual](#)

See also: [Instructions for Using](#) , [Instruction and Installation Manual](#)



INSTRUCCIONES DE INSTALACIÓN DE LA LAVADORA/ LAVEUSE/SÉCHEUSE ÉLECTRIQUE DE 27" (69 CM)

WASHER/DRYER SAFETY	1
INSTALLATION INSTRUCTIONS	2
Tools and Parts	2
Alternate Parts	2
Location Requirements	3
Drain System	4
Electrical Requirements - U.S.A.	4
Electrical Requirements - Canada	5
Electrical Connection - U.S.A. Only	6
Venting Requirements	11
Remove Shipping Strap	12

Install Leveling Legs	12
Connect the Drain Hose	12
Connect the Inlet Hoses	13
Secure the Drain Hose	14
Plan Vent System	14
Install Vent System	15
Level Washer/Dryer	15
Connect Vent	15
Complete Installation	16

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.

This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING."

These words mean:

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

W10118289A

27" (69 CM) ELECTRIC WASHER/DRYER


INSTALLATION INSTRUCTIONS

SECADORA ELÉCTRICA DE 27" (69 CM)

INSTRUCTIONS D'INSTALLATION

Table of Contents / Índice / Table des matières

SEGURIDAD DE LA LAVADORA/SECADORA	17
INSTRUCCIONES DE INSTALACIÓN	17
Herramientas y piezas	17
Piezas alternativas	18
Requisitos de ubicación	18
Sistema de desagüe	19
Requisitos eléctricos - EE.UU.	19
Conexión eléctrica - Sólo en EE. UU.	21
Requisitos de ventilación	26
Quite el fleje de embalaje	27
Instalación de las patas niveladoras	28
Conecte la manguera de desagüe	28
Conecte las mangueras de entrada	29
Fijación de la manguera de desagüe	30
Planificación del sistema de ventilación	30
Instalación del sistema de ventilación	31
Cómo nivelar la lavadora/secadora	31
Conexión del ducto de escape	32
Complete la instalación	32



WASHER/DRYER SAFETY

Your safety and the safety of others are very important.

[SÉCURITÉ DE LA LAVEUSE/SÉCHEUSE ... 33](#)

[INSTRUCTIONS D'INSTALLATION..... 33](#)

You can be killed or seriously injured if you don't immediately follow instructions.

You can be killed or seriously injured if you don't follow instructions.

Outillage et pièces.....	33
Autres pièces	34
Exigences d'emplacement	34
Système de vidange	35
Spécifications électriques - Canada.....	36
Exigences concernant l'évacuation.....	37
Enlever la sangle d'expédition	38
Installation des pieds de nivellement.....	39
Raccordement du tuyau de vidange	39
Raccordement des tuyaux d'alimentation..	39
Immobilisation du tuyau de vidange.....	40
Planification du système d'évacuation	41
Installation du système d'évacuation	42
Nivellement de la laveuse/sécheuse.....	42
Raccordement du conduit d'évacuation	43
Achever l'installation	43

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool Washer/Dryer