



Whirlpool GH7208XRY Use & Care Manual

Microwave hood combination

1
2
3
4
5
6
7
8

Table Of Contents

9

--

•

[Table of Contents](#)

•

Troubleshooting

•

Bookmarks

--

Table of Contents

1 User Instructions

2 Important Safety Instructions

3 Precautions to Avoid Possible Exposure to Excessive Microwave Energy

4 Grounding Instructions

5 Electrical Requirements

6 Cookware and Dinnerware


[7 Microwave Oven Use](#)

[8 Microwave Oven Care](#)

[9 Troubleshooting](#)

[Download this manual](#)

[See also: Use and Care Manual](#) , [Instructions](#)



THANK YOU for purchasing this high-quality product. If you should experience a problem not covered in TROUBLESHOOTING,

please visit our website at www.whirlpool.com for additional information. If you still need assistance, call us at 1-800-253-1301.

You will need your model and serial number located on the front facing of the microwave oven opening, behind the door.

Para obtener acceso a "Instrucciones para el usuario de la combinación microondas campana" en español, o para obtener

información adicional acerca de su producto, visite: www.whirlpool.com

Tenga listo su número de modelo completo. Puede encontrar su número de modelo y de serie en la etiqueta ubicada en la parte

frontal de la abertura del horno de microondas, detrás de la puerta.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.

This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING."

These words mean:

WARNING

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING:

To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:

■ Read all instructions before using the microwave oven.

■ Read and follow the specific "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" found in this section.

■ The microwave oven must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" found in this section and in the provided Installation Instructions.

W10170439A

WARNING

Microwave Hood Combination Safety

Your safety and the safety of others are very important.

SAVE THESE INSTRUCTIONS

SAFETY INSTRUCTIONS

You can be killed or seriously injured if you don't immediately follow instructions.

You can be killed or seriously injured if you don't follow instructions.

■ Install or locate the microwave oven only in accordance with the provided Installation Instructions.

■ Some products such as whole eggs in the shell and sealed containers – for example, closed glass jars – are able to explode and should not be heated in the microwave oven.

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool GH7208XRY

[Microwave Oven Whirlpool Gold GH7208XRY Use And Care Manual](#)

Speedcook microwave hood combination with convection (36 pages)

[Microwave Oven Whirlpool GH7208XRY Instructions](#)

Microwave hood combination (1 page)

[Microwave Oven Whirlpool GH7208XR Use & Care Manual](#)

(36 pages)

[Convection Oven Whirlpool GH7208XR Use & Care Manual](#)

Whirlpool use&care guide speedcook microwave oven with convection gh7208xr

(36 pages)

[Ventilation Hood Whirlpool GH6177XPS Installation Instructions Manual](#)

Microwave hood combination (24 pages)

[Microwave Oven Whirlpool MICROWAVE HOOD COMBINATION](#)

[Installation Instructions Manual](#)

Microwave hood combination (12 pages)

[Microwave Oven Whirlpool Gold GH7208XR Installation Instructions](#)

[Manual](#)

Microwave hood combination (12 pages)

[Microwave Oven Whirlpool MICROWAVE HOOD COMBINATION](#)

[Installation Instructions Manual](#)

Microwave hood combination (12 pages)

[Microwave Oven Whirlpool Microwave Hood Combination User Manual](#)

Microwave hood combination (9 pages)

[Microwave Oven Whirlpool Microwave Hood Combination User Manual](#)

(9 pages)

[Microwave Oven Whirlpool W10560735A User Manual](#)

Microwave hood combination (9 pages)

[Microwave Oven Whirlpool Microwave Hood Combination Installation](#)

[Instructions Manual](#)

Microwave hood combination (7 pages)

[Microwave Oven WHIRLPOOL 8205272-D-WH Dimensions And](#)

[Installation Information](#)

(1 page)

[Microwave Oven Whirlpool GH7155XHS Use And Care Manual](#)

Microwave hood combination (30 pages)

[Microwave Oven Whirlpool GH7155XKQ Use And Care Manual](#)

Microwave hood combination (32 pages)

[Microwave Oven Whirlpool GH7155XK Installation Instructions Manual](#)

Microwave oven hood combination (7 pages)

Summary of Contents for Whirlpool GH7208XRY

[Page 1: User Instructions](#)

THANK YOU for purchasing this high-quality product. If you should experience a problem not

covered in TROUBLESHOOTING, please visit our website at www.whirlpool.com for additional information. If you still need assistance, call us at 1-800-253-1301. You will need your model and serial number located on the front facing of the microwave oven opening, behind the door.

[Page 2: Precautions To Avoid Possible Exposure To Excessive Microwave Energy](#)

IMPORTANT SAFETY INSTRUCTIONS ■ Use the microwave oven only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in the microwave oven. This type of oven is specifically designed to heat, cook, or dry food. It is not designed for industrial or laboratory use.

[Page 3: Grounding Instructions](#)

WARNING Electrical Shock Hazard Plug into a grounded 3 prong outlet. Do not remove ground prong. Do not use an adapter. Do not use an extension cord. Failure to follow these instructions can result in death, fire, or electrical shock. Observe all governing codes and ordinances.

[Page 4: Cookware And Dinnerware](#)

Pan (on some models) Use the provided pan for pan-frying (browning). The pan may be used to catch drippings during grill (on some models) and convection (on some models) functions.
Steamer Vessel (on some models) Use the steamer vessel base, insert and lid for steaming, or use just the base and lid for simmering.

[Page 5: Microwave Oven Use](#)

Sensor Cooking Make sure microwave oven has been plugged in for at least 2 minutes. Use microwave-safe dish with loose-fitting lid, or cover microwave-safe dish with plastic wrap and vent. For optimal performance, wait at least 30 minutes after convection cooking or grilling (on some models) before sensor cooking.

[Page 6: Troubleshooting](#)

■ Cooktop light bulb ■ Cavity light bulb Troubleshooting to possibly avoid the cost of a service call. www.whirlpool.com Quartz bulb does not appear to be on ■ This is not unusual. See "Grill Element" in the "Features" section. ■...

[Page 7](#) Notes...

[Page 8](#) For additional product information or to view FAQs (Frequently Asked Questions), visit www.whirlpool.com. If you do not have access to the Internet and you need assistance using your product, you may contact Whirlpool at the number below. Have your complete model number ready. You can find your model number and serial number on the label located on the upper or lower front facing of the microwave oven opening, behind the door.

This manual is also suitable for:

Gh7208xrqGh7208xrb gh7208xrsGh7208xrGh7208xr - 11-07Gh6177xpb ... [Show all](#)