

Viewing Existing Key Assignments; Changing Or Removing Existing Key Assignments; Hotkey Utility - Toshiba 1410-S105 User Manual

1410-s105 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

Table Of Contents

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267

268
269
270
271



•

[Table of Contents](#)

•

Bookmarks



196

Toshiba Utilities

Hotkey utility



Viewing existing key assignments

To view the existing key assignments, choose Assignments

from the Fn-esse keyboard. Fn-esse displays the Function Key Assignments window. This box lists all the key assignments and the program or document to which each key is assigned.

To view items in a popup list, click the Expand popup lists check box.

Changing or removing existing key assignments

1

In the Fn-esse keyboard, click the key you wish to change with the secondary button.

Fn-esse displays the Assignment Type window.

2

To change the key assignment, click Direct or Popup and continue as if you were creating a new assignment.

3

To remove the key assignment, click Clear.

Hotkey utility

The hotkey utility allows you to receive a confirmation message when you use the hot key combination for Standby

[
Fn + F3
To activate the utility:
Click Start, All Programs, Toshiba Utilities and then
click

Hotkey utility.

The Toshiba Hotkey utility window appears.

do this, refer to your operating system
documentation.

Click OK to associate the folder with the key you
just selected.

To open a popup list showing the items in that folder,
press
plus the appropriate key.

Fn
] and Hibernation [
].

Fn + F4

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

195

196

197

198

Quick Links:

[Wireless Interoperability](#)

Related Manuals for Toshiba 1410-S105

[Laptop TOSHIBA Satellite 1415 Series User Manual](#)

Toshiba satellite computer (266 pages)

[Laptop Toshiba PS241U-2DC2P7 User Manual](#)

User manual (240 pages)

[Laptop Toshiba Satellite 1410 User Manual](#)

(240 pages)

[Laptop Toshiba Satellite 1415-S105 Specifications](#)

Satellite 1415 series (2 pages)

[Laptop Toshiba Satellite 1415-S115 Specifications](#)

Satellite 1415 series (2 pages)

[Laptop Toshiba 1405-S171 User Manual](#)

1405-s171 user's guide (298 pages)

[Laptop TOSHIBA Satellite 1400 User Manual](#)

Portable personal computer (240 pages)

[Laptop TOSHIBA Satellite 1400 User Manual](#)

Toshiba satellite portable personal computer (232 pages)

[Laptop Toshiba Satellite Radius 14 L40W-C User Manual](#)

(117 pages)

[Laptop Toshiba Satellite 1130 Series User Manual](#)

Toshiba notebook computer user's guide (244 pages)

[Laptop Toshiba 1905-S301 User Manual](#)

1905-s301 user's guide (271 pages)

[Laptop Toshiba 1105 User Manual](#)

1105 user's guide (242 pages)

[Laptop Toshiba 100CS Manual](#)

(170 pages)

[Laptop Toshiba NB 105-SP2801A Manual Del Usuario](#)

Nb 105-sp2801a user's guide (106 pages)

[Laptop Toshiba KIRABook 13 i5 Quick Start Manual](#)

Quick start guide (13 pages)

[Laptop Toshiba Satellite Radius 12 P20W-C User Manual](#)

(116 pages)

Related Content for Toshiba 1410-S105

[Portege 2010 Viewing Existing Key Assignments](#)

Toshiba Portege 2010

[M45-S165 - Satellite - Celeron M 1.5 GHz Viewing Existing Key Assignments](#)

Toshiba M45-S165 - Satellite - Celeron M 1.5 GHz

[M45 S169 - Satellite - Celeron M 1.6 GHz Viewing Existing Key Assignments](#)

Toshiba M45 S169 - Satellite - Celeron M 1.6 GHz

[M115 S1061 - Satellite - Celeron M 1.6 GHz Viewing Existing Key Assignments](#)

Toshiba M115 S1061 - Satellite - Celeron M 1.6 GHz

[M105-S1021 - Satellite - Celeron M 1.46 GHz Viewing Existing Key Assignments](#)

Toshiba M105-S1021 - Satellite - Celeron M 1.46 GHz

[M205-S810 - Portege - Pentium M 1.5 GHz Viewing Existing Key Assignments](#)

Toshiba M205-S810 - Portege - Pentium M 1.5 GHz

[A8 S8514 - Tecra - Core 2 Duo GHz Viewing Existing Key Assignments](#)

Toshiba A8 S8514 - Tecra - Core 2 Duo GHz

[A105-S4004 - Satellite - Core Duo 1.66 GHz Viewing Existing Key Assignments](#)

Toshiba A105-S4004 - Satellite - Core Duo 1.66 GHz

This manual is also suitable for:

[1410-s1061410-s1731415-s1051415-s1061415-s1151415-s173](#) ... [Show all](#)