

Registering Your Computer With Toshiba; Adding External Devices - Toshiba A10-S100 User Manual

A10-s100 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18


19
20
21
22
23
24
25
Table Of Contents
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263



•

[Table of Contents](#)

•

Bookmarks



3

Follow the on-screen instructions to enter the information about your computer.

A window will display the message, "Thank you."

4

Click Finish to continue.

Your computer restarts automatically.

NOTE

Registering your computer with Toshiba

Registering your computer lets Toshiba keep you up-to-date with information about new products and upgrades, and also extends your Toshiba limited warranty worldwide at no charge to you. You can register your computer with Toshiba by double-clicking the icon on your desktop.

NOTE

Adding external devices

To register online, your computer's modem must be connected to a voice-grade telephone line.

If you chose not to register now, you may register with Toshiba by clicking the Register with Toshiba icon on the desktop.

To register online, your computer's modem must be connected to a voice-grade telephone line.

Before adding external devices, Toshiba recommends setting up your software first. See

[page](#)

54.

Getting Started

Setting up your computer

["Setting up your software" on](#)

55

ManualsLib.com

[Previous Page](#)
[Next Page](#)

1
...
52
53
54
55
56
57
58
59

Quick Links:

[Installing Additional Memory \(Optional\)](#)

Related Manuals for Toshiba A10-S100

[Laptop Toshiba Satellite A10-S100 Specifications](#)

Toshiba satellite a10-s100: specifications (9 pages)

[Laptop Toshiba PSA10C-035WM Maintenance Manual](#)

Maintenance manual (417 pages)

[Laptop Toshiba Satellite A10 Maintenance Manual](#)

Personal computer (417 pages)

[Laptop Toshiba Satellite A10 Series User Manual](#)

Toshiba satellite a10 series portable personal computer user's manual (259 pages)

[Laptop Toshiba A10-S3501 User Manual](#)

A10-s3501 user's guide (252 pages)

[Laptop Toshiba Satellite A15 Resource Manual](#)

Toshiba satellite resource guide (52 pages)

[Laptop Toshiba Satellite A10 Series Field Replaceable Unit Documentation](#)

(11 pages)

[Laptop Toshiba Satellite A15-S129 Specifications](#)

Satellite a15 series (9 pages)

[Laptop Toshiba Satellite A15-S157 Specifications](#)

Satellite a15 series (9 pages)

[Laptop Toshiba Satellite A10-S129 Specifications](#)

Toshiba satellite a10-s129: specifications (9 pages)

[Laptop Toshiba Satellite A10-S167 Specifications](#)

Toshiba satellite a10-s167: specifications (9 pages)

[Laptop Toshiba Satellite A10-S169 Specifications](#)

Toshiba satellite a10-s169: specifications (9 pages)

[Laptop Toshiba Satellite A10-S177 Specifications](#)

Satellite a10 series (9 pages)

[Laptop Toshiba Satellite A15-S127 Specifications](#)

Satellite a15 series (3 pages)

[Laptop Toshiba Satellite A10-S127 Specifications](#)

Toshiba satellite a10-s127: specifications (3 pages)

[Laptop Toshiba PSA10U-0ZH6M3 Brochure](#)

Brochure (2 pages)

Related Content for Toshiba A10-S100

[satellite fusion 15 series Registering Your Computer With Toshiba](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Registering Your Computer With Toshiba](#)

Toshiba Satellite CL10 Series

[Satellite S70-B Series Registering Your Computer With Toshiba](#)

Toshiba Satellite S70-B Series

[Satellite CL40 Series Registering Your Computer With Toshiba](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Registering Your Computer With Toshiba](#)

Toshiba Satellite E40-A

[Portege 2010 Registering Your Computer With Toshiba](#)

Toshiba Portege 2010

[Satellite A35 Series Registering Your Computer With Toshiba](#)

Toshiba Satellite A35 Series

[C50 Series Registering Your Computer With Toshiba](#)

Toshiba C50 Series

This manual is also suitable for:

[A10-s129A10-s1291A10-s169A10-s1691A10-s128A15-s127](#) ... [Show all](#)