

Toshiba Accessibility - Toshiba A205-S5800 User Manual

A205-s5800 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
Table Of Contents
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245

•

[Table of Contents](#)

•

Bookmarks



2

Click Set Quiet Mode to make the drive run more slowly and quietly for listening to music or audio files on a CD.

3

Click Set Normal Mode to run the drive at normal speed for transferring data.

TOSHIBA Accessibility

The TOSHIBA Accessibility utility allows you to use the

create a hot key combination with one of the function keys without pressing the two keys simultaneously as is usually required.

Using

Accessibility lets you make the

press it once, release it, and then press a function key to activate the hot key function.

(Sample Image) TOSHIBA Accessibility window

To use TOSHIBA Accessibility:

1

Click Start, All Programs, Toshiba, Utilities, and then

Accessibility, or click the Accessibility icon in the Optimize tab of

The TOSHIBA Accessibility window appears.

2

Check the Use Fn-StickyKey box.

3

Put a check mark next to the desired option.

4

Click OK.

TOSHIBA

Assist.

Toshiba Utilities

TOSHIBA Accessibility

Fn

key a sticky key, meaning you can

159

Fn

key to




Table of Contents

[Previous Page](#)
[Next Page](#)

1

...

158

159

160

161

Quick Links:

[Fcc Requirements](#)

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba A205-S5800

[Laptop Toshiba Satellite A200-0MD00X Resource Manual](#)

Toshiba satellite a200-0md00x: reference guide (52 pages)

[Laptop Toshiba Satellite A215 Maintenance Manual](#)

(256 pages)

[Laptop Toshiba Satellite A205 Series User Manual](#)

(244 pages)

[Laptop Toshiba Satellite A210 Series User Manual](#)

(220 pages)

[Laptop Toshiba A200 series User Manual](#)

(194 pages)

[Laptop Toshiba A210 Series User Manual](#)

Notebook pc a210 series (186 pages)

[Laptop Toshiba Satellite A205-S4577 Resource Manual](#)

Toshiba satellite a205-s4577: reference guide (56 pages)

[Laptop Toshiba Satellite A205-S7468 Specifications](#)

Toshiba satellite a205-s7468: specifications (5 pages)

[Laptop Toshiba Satellite A205-S4707 Specifications](#)

Toshiba satellite a205-s4707: specifications (4 pages)

[Laptop Toshiba Satellite A215-S4697 Specifications](#)

Toshiba satellite a215-s4697: specifications (4 pages)

[Laptop Toshiba Satellite A215-S4757 Specifications](#)

Toshiba satellite a215-s4757: specifications (4 pages)

[Laptop Toshiba Satellite A215-S6816 Specifications](#)

Toshiba satellite a215-s6816: specifications (4 pages)

[Laptop Toshiba Satellite A215-S7422 Specifications](#)

Toshiba satellite a215-s7422: specifications (4 pages)

[Laptop Toshiba Satellite A215-S5818 Specifications](#)

Toshiba satellite a215-s5818: specifications (3 pages)

[Laptop Toshiba Satellite A205-S5855 Specification](#)

Toshiba notebook pc product specification (3 pages)

[Laptop Toshiba PSAF0U-06H009 Brochure](#)

Brochure (2 pages)

Related Content for Toshiba A205-S5800

[Satellite R10 Toshiba Accessibility](#)

Toshiba Satellite R10

[Satellite A200 Series Toshiba Accessibility](#)

TOSHIBA Satellite A200 Series

[Satellite 1415 Series Toshiba Accessibility](#)

TOSHIBA Satellite 1415 Series

[Satellite A40-S200 Accessibility De Toshiba](#)

Toshiba Satellite A40-S200

[X305-Q705 - Qosmio - Core 2 Duo GHz Toshiba Accessibility](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

[U205-S5002 - Satellite - Core Duo 1.66 GHz Toshiba Accessibility](#)

Toshiba U205-S5002 - Satellite - Core Duo 1.66 GHz

[P105 S6197 - Satellite - Core 2 Duo 1.6 GHz Toshiba Accessibility](#)

Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Toshiba Accessibility](#)

Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz

This manual is also suitable for:

[A205-s5803A205-s5804A205-s5801A205-s5806A205-s5809A205-s5810 ... Show all](#)