

Display Problems - Toshiba A205-S5800 User Manual

A205-s5800 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
Table Of Contents
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245

•

[Table of Contents](#)

•

Bookmarks



Display problems

Here are some typical display problems and their solutions:

The screen is blank.

Display Auto Off may have gone into effect. Press any key to activate the screen.

You may have activated the instant password feature by pressing and

Fn

F1

any key, type the password and press registered, press any key. The screen reactivates and allows you to continue working.

If you are using the built-in screen, make sure the display priority is not set for an external monitor. To do this, press simultaneously (once). If this does not correct the problem, press and

simultaneously again to return the display priority to its F5

previous setting.

If you are using an external monitor:



Check that the monitor is turned on.



Check that the monitor's power cord/cable is firmly plugged into a working power outlet.



Check that the cable connecting the external monitor to the computer is firmly attached.



Try adjusting the contrast and brightness controls on the external monitor.



Press priority is not set for the built-in screen.

The screen does not look right.

You can change the display settings by clicking a blank area of the desktop with the secondary control button, then clicking

Personalize. This opens the Personalization window. Click Windows Color and Appearance to choose the colors for the screen. Click Display settings to choose the screen resolution.

simultaneously. If you have registered a password, press
HINT: Holding the Fn key and pressing the F5 key several times will advance you through the display options.

and

simultaneously to make sure the display

Fn

F5

If Something Goes Wrong

Resolving a hardware conflict

Enter

. If no password is

Fn

and

F5

185

Fn

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

184

185

186

187

Quick Links:

[Fcc Requirements](#)

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba A205-S5800

[Laptop Toshiba Satellite A200-0MD00X Resource Manual](#)

Toshiba satellite a200-0md00x: reference guide (52 pages)

[Laptop Toshiba Satellite A215 Maintenance Manual](#)

(256 pages)

[Laptop Toshiba Satellite A205 Series User Manual](#)

(244 pages)

[Laptop Toshiba Satellite A210 Series User Manual](#)

(220 pages)

[Laptop Toshiba A200 series User Manual](#)

(194 pages)

[Laptop Toshiba A210 Series User Manual](#)

Notebook pc a210 series (186 pages)

[Laptop Toshiba Satellite A205-S4577 Resource Manual](#)

Toshiba satellite a205-s4577: reference guide (56 pages)

[Laptop Toshiba Satellite A205-S7468 Specifications](#)

Toshiba satellite a205-s7468: specifications (5 pages)

[Laptop Toshiba Satellite A205-S4707 Specifications](#)

Toshiba satellite a205-s4707: specifications (4 pages)

[Laptop Toshiba Satellite A215-S4697 Specifications](#)

Toshiba satellite a215-s4697: specifications (4 pages)

[Laptop Toshiba Satellite A215-S4757 Specifications](#)

Toshiba satellite a215-s4757: specifications (4 pages)

[Laptop Toshiba Satellite A215-S6816 Specifications](#)

Toshiba satellite a215-s6816: specifications (4 pages)

[Laptop Toshiba Satellite A215-S7422 Specifications](#)

Toshiba satellite a215-s7422: specifications (4 pages)

[Laptop Toshiba Satellite A215-S5818 Specifications](#)

Toshiba satellite a215-s5818: specifications (3 pages)

[Laptop Toshiba Satellite A205-S5855 Specification](#)

Toshiba notebook pc product specification (3 pages)

[Laptop Toshiba PSAF0U-06H009 Brochure](#)

Brochure (2 pages)

Related Content for Toshiba A205-S5800

[Satellite Radius 15 Display Problems](#)

Toshiba Satellite Radius 15

[satellite fusion 15 series Display Problems](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Display Problems](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Display Problems](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Display Problems](#)

Toshiba Satellite S70-B Series

[Tecra A3 Series Display Problems](#)

Toshiba Tecra A3 Series

[Satellite Click 2 PRO Display Problems](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Display Problems](#)

Toshiba Satellite CL40 Series

This manual is also suitable for:

[A205-s5803A205-s5804A205-s5801A205-s5806A205-s5809A205-s5810](#) ... [Show all](#)