



# Power Plans - Toshiba A500-ST5605 User Manual

A500-st5605 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
Table Of Contents  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67


68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248



•

[Table of Contents](#)

•

## Bookmarks





## **Power Plans**

You can choose a predefined Power Plan or select your own combination of power options. To do this:

**1**

Click Start, Control Panel, System and Security, and then **Power Options.**

The Windows

*(Sample Image) Windows*

2

Select an appropriate plan for your work environment or create your own custom plan.

3

Click Create a power plan in the left pane to set up a new plan.

NOTE

4

Click Change plan settings to choose the plan you want to edit.

This screen allows you to change basic settings.

5

Click Change advanced power settings to access settings for battery notification levels, internal storage drive power save time, etc.

You can click on the plus signs to expand each item and to see what settings are available for each item.

*Monitoring main battery power*

®


Power Options window appears.

To edit a plan or to edit advanced settings, continue to the following steps.

**Mobile Computing**

®

*Power Options window*



121

[Previous Page](#)  
[Next Page](#)



1  
...  
120  
121  
122  
123

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

## Related Manuals for Toshiba A500-ST5605

[Laptop Toshiba A500-ST5602 User Manual](#)

A500-st5602 user's guide (252 pages)

[Laptop Toshiba Satellite A500-ST5601 Resource Manual](#)

Toshiba satellite a500-st5601: reference guide (60 pages)

[Laptop Toshiba Satellite A500-ST5605 Specifications](#)

Toshiba satellite a500-st5605: specifications (4 pages)

[Laptop Toshiba Satellite A500 series User Manual](#)

(269 pages)

[Laptop Toshiba Satellite A500 Series User Manual](#)

(269 pages)

[Laptop Toshiba Satellite A500 User Manual](#)

(258 pages)

[Laptop Toshiba a500 Series User Manual](#)

(234 pages)

[Laptop Toshiba Satellite A500-ST56X7 Specifications](#)

Toshiba satellite a500-st56x7: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6004 Specifications](#)

Toshiba satellite a505-s6004: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6005 Specifications](#)

Toshiba satellite a505-s6005: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6009 Specifications](#)

Toshiba satellite a505-s6009: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6025 Specifications](#)

Toshiba satellite a505-s6025: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6969 Specifications](#)

Toshiba satellite a505-s6969: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6970 Specifications](#)

Toshiba satellite a505-s6970: specifications (4 pages)

[Laptop Toshiba Satellite A505-S6980 Specifications](#)

Toshiba satellite a505-s6980: specifications (4 pages)

[Laptop Toshiba Satellite A505D-S6958 Specifications](#)

Toshiba satellite a505d-s6958: specifications (4 pages)

## Related Content for Toshiba A500-ST5605

[satellite fusion 15 series Power Plans](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Power Plans](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Power Plans](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Power Plans](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Power Plans](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Power Plans](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Power Plans](#)

Toshiba Satellite E40-A

[C50 Series Power Plans](#)

Toshiba C50 Series

This manual is also suitable for:

[A500-st5606A500-st5607A500-st5608A500-st56exA500-st56x3A500-st56x4](#) ... [Show all](#)