

Toshiba Zooming Utility - Toshiba L500-ST2521 User Manual

L500-st2521 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234

--

•

[Table of Contents](#)

•

Bookmarks



156

Utilities

TOSHIBA Zooming Utility

TOSHIBA Zooming Utility

This utility allows you to select which applications will work with

the zoom in/out hot keys (see



page

211). You may select all applications or any subset of the following:

Microsoft

Microsoft

Windows Media

Adobe

Icons on the desktop

To access the TOSHIBA Zooming Utility:

1

Click Start, All Programs, Toshiba, Utilities, and then

TOSHIBA Zooming Utility.

The TOSHIBA Zooming Utility Properties screen appears.

(Sample Image) TOSHIBA Zooming Utility Properties screen

2

Select the desired option(s).

3

Click OK.

The zoom in and zoom out hot keys will now work with the applications you selected.

To zoom in, hold down the

down the

For more information about how to use the TOSHIBA Zooming

Utility, right-click the

click Help.


®

Internet Explorer

®

Office

®



Player

®

®

Acrobat

Reader

Fn

key and press

"Zoom (Display resolution)" on

®

®

Fn



key and press



1



.

icon in the Notification Area and then



2



; to zoom out, hold

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

155

156

157

158

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba L500-ST2521

[Laptop Toshiba L305D S5897 - Satellite - Turion 64 X2 2 GHz Manual Del Usuario](#)

User's guide for satellite l300d/l305d spanish (233 pages)

[Laptop Toshiba L515-S4007 User Manual](#)

L515-s4007 user's guide (232 pages)

[Laptop Toshiba Satellite L505 Manual Del Usuario](#)

User guide 2 (231 pages)

[Laptop Toshiba L300-ST3502 User Manual](#)

L300-st3502 user's guide (230 pages)

[Laptop Toshiba Satellite L550 series User Manual](#)

(218 pages)

[Laptop Toshiba Satellite L500 User Manual](#)

(214 pages)

[Laptop Toshiba Satellite L500-01K00Y Resource Manual](#)

Toshiba satellite I500 series reference guide (56 pages)

[Laptop Toshiba Satellite L505D-LS5007 Specifications](#)

Toshiba satellite I505d-ls5007: specifications (4 pages)

[Laptop Toshiba Satellite L505D-S6947 Specifications](#)

Toshiba satellite I505d-s6947: specifications (4 pages)

[Laptop Toshiba PSLU0U-0MX035 Brochure](#)

Brochure (4 pages)

[Laptop Toshiba Satellite L505-GS5035 Specifications](#)

Toshiba satellite I505-gs5035: specifications (4 pages)

[Laptop Toshiba Satellite L505-S5969 Specifications](#)

Toshiba satellite I505-s5969: specifications (4 pages)

[Laptop Toshiba Satellite L505-S5984 Specifications](#)

Toshiba satellite I505-s5984: specifications (4 pages)

[Laptop Toshiba Satellite L505-S5997 Specifications](#)

Toshiba satellite I505-s5997: specifications (4 pages)

[Laptop Toshiba Satellite L505-ES5018 Specifications](#)

Toshiba satellite I505-es5018: specifications (3 pages)

[Laptop Toshiba Satellite L505-S5966 Specifications](#)

Toshiba satellite I505-s5966: specifications (3 pages)

Related Content for Toshiba L500-ST2521

[Satellite A200 Series Toshiba Zooming Utility](#)

TOSHIBA Satellite A200 Series

[X305-Q705 - Qosmio - Core 2 Duo GHz Toshiba Zooming Utility](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

[U205-S5002 - Satellite - Core Duo 1.66 GHz Toshiba Zooming Utility](#)

Toshiba U205-S5002 - Satellite - Core Duo 1.66 GHz

[P105 S6197 - Satellite - Core 2 Duo 1.6 GHz Toshiba Zooming Utility](#)

Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Toshiba Zooming Utility](#)

Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz

[S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz Toshiba Zooming Utility](#)

Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz

[R10 S4401 - Tecra - Core 2 Duo 2.26 GHz Toshiba Zooming Utility](#)

Toshiba R10 S4401 - Tecra - Core 2 Duo 2.26 GHz

[M45-S165 - Satellite - Celeron M 1.5 GHz Using The Toshiba Zooming Utility](#)

This manual is also suitable for:

[L500-st5507L500-st55x2L500d-st5501L500d-st5506L500d-st55x1L505-es5011](#) ... [Show all](#)