



# Printer Problems - Toshiba P15-S4091 User Manual

P15-s4091 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
Table Of Contents  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67


68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240



•

[Table of Contents](#)

•

## Bookmarks





# 190

## **If Something Goes Wrong**

*Resolving a hardware conflict*

---

## **Printer problems**

This section lists some of the most common printer problems:

## **The printer will not print.**

Check that the printer is connected to a working power outlet, turned on and ready (on line).

Check that the printer has plenty of paper. Some printers will not start printing when there are just two or three sheets of paper left in the tray.

Make sure the USB printer cable is firmly attached to the computer and the printer.

Run the printer's self-test to check for any problem with the printer itself.

Make sure you installed the proper printer drivers, as shown in

["Setting up a printer" on page](#)

You may have connected the printer while the computer is on.

Disable Standby mode, turn off the computer, and turn off the printer. Turn the printer back on, make sure it is on line, then turn the computer back on.

Try printing another file. For example, you could create and attempt to print a short test file using Notepad. If a

Notepad

file prints correctly, the problem may be in your original file.

If you cannot resolve the problem, contact the printer's manufacturer.

### **The printer will not print what you see on the screen.**

Many programs display information on the screen differently

from the way they print it. See if your program has a print preview mode. This mode lets you see your work exactly as it

will print. Contact the software manufacturer for more information.

68.



[Previous Page](#)  
[Next Page](#)

1

...

189

190

191

192

## Related Manuals for Toshiba P15-S4091

### [Laptop Toshiba Satellite P15 Series Specifications](#)

Satellite p15 series (21 pages)

### [Laptop Toshiba Satellite P15-S409 Specifications](#)

Satellite p15 series (9 pages)

### [Laptop Toshiba P15-S470 User Manual](#)

P15-s470 user's guide (290 pages)

### [Desktop Toshiba Satellite P10 Series Maintenance Manual](#)

Personal computer (213 pages)

### [Laptop Toshiba Satellite P10-304 User Manual](#)

Toshiba satellite p10-304: user guide (182 pages)

### [Laptop Toshiba Satellite P10 series User Manual](#)

(172 pages)

### [Laptop Toshiba Satellite 5205 Series Setup Manual](#)

How to set up your computer to use the media center with a tv tuner (12 pages)

### [Laptop Toshiba Satellite P10-S429 Specifications](#)

Small business series (9 pages)

### [Laptop Toshiba Satellite P15-S420 Specifications](#)

Satellite p15 series (9 pages)

### [Laptop Toshiba Satellite P15-S470 Specifications](#)

Satellite p15 series (9 pages)

### [Laptop Toshiba Satellite P15-S479 Specifications](#)

Satellite p15 series (9 pages)

### [Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

### [Laptop Toshiba Satellite P105-S6024 Specifications](#)

Toshiba satellite p105-s6024: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6064 Specifications](#)

Toshiba satellite p105-s6064: specifications (11 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

### [Laptop Toshiba TECRA A11 User Manual](#)

Portable personal computer (238 pages)

## Related Content for Toshiba P15-S4091

### [satellite fusion 15 series Printer Problems](#)

Toshiba satellite fusion 15 series

### [Satellite CL10 Series Printer Problems](#)

Toshiba Satellite CL10 Series

### [Portege Z20-B Series Printer Problems](#)

Toshiba Portege Z20-B Series

### [Satellite S70-B Series Printer Problems](#)

Toshiba Satellite S70-B Series

### [Satellite Click 2 PRO Printer Problems](#)

Toshiba Satellite Click 2 PRO  
[Satellite CL40 Series Printer Problems](#)  
Toshiba Satellite CL40 Series  
[Satellite E40-A Printer Problems](#)  
Toshiba Satellite E40-A  
[Portege 2010 Printer Problems](#)  
Toshiba Portege 2010

This manual is also suitable for:

[P15-s420P10-s429P15-s409P10-s4291P15-s4201Psp10u-0dxpgr](#) ... [Show all](#)