

Removing A Memory Module - Toshiba P25-S509 User Manual

P25-s509 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19

20

21

22

23

Table Of Contents

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66


67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230



•

•

Bookmarks



64

Getting Started

Installing additional memory (optional)

10

Replace the expansion memory slot cover.

11

Replace the screws and tighten them.

12

Turn the computer over and reconnect any cables you removed.

13

Turn on the computer.

To verify that the computer correctly recognizes the memory, click Start, Control Panel and click

Performance and Maintenance. Click System to view

the recognized memory.

14

If the computer does not recognize the memory, shut down the computer, remove the memory slot cover, and make sure the memory module is seated properly, as described in step 8.

Removing a memory module

1

Follow steps 1 through 6 in ["memory \(optional\)"](#) on page

2

Gently push the memory locks outward until the memory module pops up.

Removing the memory module

Avoid touching the connectors on the memory module or on the computer. Grease or dust on the connectors may cause memory access problems.

"Installing additional 61.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
61
62
63
64
65
66
67
68

Quick Links:

[Disk Drive Problems](#)

[Index](#)

Related Manuals for Toshiba P25-S509

[Laptop Toshiba Satellite P25-S509 Specifications](#)

Satellite p25 series (18 pages)

[Laptop Toshiba P25-S607 User Manual](#)

P25-s607 user's guide (282 pages)

[Laptop Toshiba P25-S609 User Manual](#)

P25-s609 user's guide (278 pages)

[Laptop Toshiba P25-S670 User Manual](#)

P25-s670 user's guide (277 pages)

[Laptop Toshiba P25-S526 User Manual](#)

P25-s526 user's guide (235 pages)

[Laptop Toshiba P25-S477 User Manual](#)

P25-s477 user's guide (232 pages)

[Laptop Toshiba Satellite M20 Resource Manual](#)

Toshiba modem resource guide (52 pages)

[Laptop Toshiba Satellite P25 Series Resource Manual](#)

(52 pages)

[Laptop Toshiba Satellite 5205 Series Setup Manual](#)

How to set up your computer to use the media center with a tv tuner (12 pages)

[Laptop Toshiba Satellite P25-S5092 Specifications](#)

Satellite p25 series (9 pages)

[Laptop Toshiba Satellite P25-S5093 Specifications](#)

Satellite p25 series (9 pages)

[Laptop Toshiba Satellite P25-S520 Specifications](#)

Satellite p25 series notebook (9 pages)

[Laptop Toshiba Satellite P25-S487 Specifications](#)

Satellite p25 series (9 pages)

[Laptop Toshiba P25 Series Specification Sheet](#)

Satellite p25 series (9 pages)

[Laptop Toshiba Satellite P25-S507 Specifications](#)

Satellite p25 series (9 pages)

[Laptop Toshiba Satellite P25-S609 Specifications](#)

Satellite p25 series; (9 pages)

Related Content for Toshiba P25-S509

[Satellite C50-C Removing A Memory Module](#)

Toshiba Satellite C50-C

[Satellite A205 Series Removing A Memory Module](#)

Toshiba Satellite A205 Series

[SATELLITE R850 Removing A Memory Module](#)

Toshiba SATELLITE R850

[NB500 Removing A Memory Module](#)

Toshiba NB500

[Satellite L630 Series Removing Memory Module](#)

Toshiba Satellite L630 Series

[Satellite Removing A Memory Module](#)

Toshiba Satellite

[Satellite P500 Removing A Memory Module](#)

Toshiba Satellite P500

[R30-C Removing A Memory Module](#)

Toshiba R30-C

This manual is also suitable for:

[P25-s5201P25-s5091P25-s5092P25-s5093P25-s520Psp20u-012rjr ...](#) [Show all](#)