

Using External Speakers Or Headphones - Toshiba P30-S6362ST User Manual

P30-s6362st user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230



•

•

Bookmarks



142

Exploring Your Options

Exploring audio features

Adjusting recording quality

The better the quality of the recording, the more disk space

the sound file requires. Experiment to find a balance that

fits

your needs.

1

Open Sound Recorder, if necessary. (Click Start, point to **All Programs, Accessories, Entertainment, then click Sound Recorder.**)

2

In the Sound Recorder window, click Edit, then click **Audio Properties.**

3

In the Audio Properties dialog box, adjust the Recording Volume, Preferred device, and Preferred quality.

4

Click OK.

Your new settings take effect the next time you record.

Using external speakers or headphones

Your computer is equipped with a full stereo sound system

with internal speakers. Instead of using the internal speakers,

you can connect headphones or a pair of external stereo speakers.

To play back sound files through external speakers or headphones:

1

Locate the headphone jack on the right side of the computer.

2

Using any necessary adapters, plug the cable from the headphones or external speakers into the headphone jack.

The headphone jack requires a 16-ohm, stereo mini-jack.

TECHNICAL NOTE: Use amplified speakers that require an external power source. Other types of speakers will be inadequate to produce sound from the computer.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

141

142

143

144

Related Manuals for Toshiba P30-S6362ST

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P35-S605 Specification Sheet](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S609 Specifications](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S6053 Specifications](#)

Toshiba satellite p35-s6053: specifications (10 pages)

[Laptop Toshiba Satellite P35-S611 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P35-S6112 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P30-S701TD Specifications](#)

Satellite p30 series (4 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

Related Content for Toshiba P30-S6362ST

[Satellite Radius 15 Using External Speakers Or Headphones](#)

Toshiba Satellite Radius 15

[satellite fusion 15 series Using External Speakers Or Headphones](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Using External Speakers Or Headphones](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Using External Speakers Or Headphones](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Using External Speakers Or Headphones](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Using External Speakers Or Headphones](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Using External Speakers Or Headphones](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Using External Speakers Or Headphones](#)

Toshiba Satellite E40-A

This manual is also suitable for:

[P30-s6363stP30-s701tdP35-s605P35-s6051P35-s6052P35-s6053](#) ... [Show all](#)