

The Windows Operating System Is Not Working - Toshiba P30-S6362ST User Manual

P30-s6362st user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
Table Of Contents
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230



•

•

Bookmarks



160

If Something Goes Wrong

The Windows

The computer displays the message.

The computer was placed in Stand By mode and the battery

has discharged. Data stored in the computer's memory has been lost.

To charge the battery, leave the computer plugged into a live

wall outlet for several hours. For more information, see ["Power and the batteries" on page](#)

The computer displays the

Make sure there is no diskette in the diskette drive. If there is

one, remove it and press any key to continue. If pressing any

key does not work, press computer.

The Windows working

Once you are familiar with the desktop and used to the way the operating system responds to your work routine, you can

easily detect if the operating system is not working correctly.

For example:



The operating system fails to start after the Windows XP



The operating system takes a long time to start.



The operating system responds differently from the normal routine.



The screen does not look right.

Unless a hardware device has failed, problems usually occur

when you change the system in some way such as installing a new program or adding a device.

If you experience any of these problems, use the options in

the Startup menu to fix the problem.

®

operating system is not working

Non-System disk

Ctrl, Alt

®

operating system is not ManualsLib.com

message appears.

WARNING RESUME FAILURE

168.

or

, and

Del to

message.

disk error

restart the

Starting

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1

...

159

160

161

162

Related Manuals for Toshiba P30-S6362ST

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P35-S605 Specification Sheet](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S609 Specifications](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S6053 Specifications](#)

Toshiba satellite p35-s6053: specifications (10 pages)

[Laptop Toshiba Satellite P35-S611 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P35-S6112 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P30-S701TD Specifications](#)

Satellite p30 series (4 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

Related Content for Toshiba P30-S6362ST

[satellite fusion 15 series The Windows Operating System Is Not Working](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series The Windows Operating System Is Not Working](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series The Windows Operating System Is Not Working](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series The Windows Operating System Is Not Working](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO The Windows Operating System Is Not Working](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series The Windows Operating System Is Not Working](#)

Toshiba Satellite CL40 Series

[Satellite E40-A The Windows Operating System Is Not Working](#)

Toshiba Satellite E40-A

[Portege 2010 The Windows ® Operating System Is Not Working](#)

Toshiba Portege 2010

This manual is also suitable for:

[P30-s6363stP30-s701tdP35-s605P35-s6051P35-s6052P35-s6053](#) ... [Show all](#)