

Adjusting The Quality Of The External Display - Toshiba P30-S6362ST User Manual

P30-s6362st user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217


218
219
220
221
222
223
224
225
226
227
228
229
230



•

•

Bookmarks





3

Release the

For more information on switching the display output,
see

["Directing the display output when you turn on the](#)

[computer" on page](#)

Adjusting the quality of the external display

To obtain the best picture quality from your television (or other video display device), you may need to adjust the video

settings. See the video device documentation for additional configuration steps.

Built-in display and TV (or other external video device) simultaneously

TV (or other external video device) only

key.

Fn



TECHNICAL NOTE: You can also change these settings using the Display Properties Box.

Set the option for the video controller by clicking Start, then Control Panel and clicking Display. Choose the Settings tab, click the Advanced button, select Display Device, select the applicable Monitor type, click Apply or OK.

70.

TECHNICAL NOTE: In order to use one of the simultaneous modes, you must set the resolution of the internal display panel to match the resolution of the external display device. The external display device must support a resolution of 640 X 480 or higher.

Getting Started

Using external display devices

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
68
69
70
71
72
73
74
75

Related Manuals for Toshiba P30-S6362ST

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P35-S605 Specification Sheet](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S609 Specifications](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S6053 Specifications](#)

Toshiba satellite p35-s6053: specifications (10 pages)

[Laptop Toshiba Satellite P35-S611 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P35-S6112 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P30-S701TD Specifications](#)

Satellite p30 series (4 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

Related Content for Toshiba P30-S6362ST

[satellite fusion 15 series Adjusting The Quality Of The External Display](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Adjusting The Quality Of The External Display](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Adjusting The Quality Of The External Display](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Adjusting The Quality Of The External Display](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Adjusting The Quality Of The External Display](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Adjusting The Quality Of The External Display](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Adjusting The Quality Of The External Display](#)

Toshiba Satellite E40-A

[Satellite A35 Series Adjusting The Quality Of The External Display](#)

Toshiba Satellite A35 Series

This manual is also suitable for:

[P30-s6363stP30-s701tdP35-s605P35-s6051P35-s6052P35-s6053](#) ... [Show all](#)