

Turning Off The Computer - Toshiba P30-S6362ST User Manual

P30-s6362st user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230



•

•

Bookmarks



72

Getting Started

Turning off the computer

Turning off the computer

It is a good idea to turn off your computer when you are not using it for a while.

If you are using the computer for the first time, leave the computer plugged into a power source (even though the computer is off) to fully charge the main battery. With the

computer off, it may take up to three hours to recharge the main battery.

When you power down the computer, you have three options

to choose from: Turn Off (or Shut down), Hibernate and Standby. Each option has its advantages.



Use the Turn Off command if you are using the Windows
Windows
connected to a domain server.



Use the Shut down command if you are using the Windows
connected to a domain server.



If you have work in progress and are not connected to a network, use the Windows
commands to save your system settings to memory so that, when you turn on the computer again, you will automatically return to where you left off.



To leave the computer off for a longer period, you can use the Windows
a domain server or the Shut down when connected to a
domain server instead.

®

XP Home version operating system, or the

®

XP Professional operating system when not

®

XP Professional operating system and

®

Turn Off command when not connected to

Never turn off the computer while any drive is in use. Doing so
may damage the media in use and result in loss of data. For
more information, see

[page](#)

99.

®

Standby or Hibernate

["Powering down the computer" on](#)

[Previous Page](#)
[Next Page](#)

1
...
69
70
71
72
73
74
75
76

Related Manuals for Toshiba P30-S6362ST

[Laptop Toshiba Satellite P30 Maintenance Manual](#)

Toshiba personal computer (208 pages)

[Laptop Toshiba Satellite P30 User Manual](#)

(170 pages)

[Laptop Toshiba Satellite P30-132 User Manual](#)

Toshiba satellite p30-132: user guide (165 pages)

[Laptop Toshiba Satellite P35-S605 Specification Sheet](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S609 Specifications](#)

Satellite p35 series (12 pages)

[Laptop Toshiba Satellite P35-S6053 Specifications](#)

Toshiba satellite p35-s6053: specifications (10 pages)

[Laptop Toshiba Satellite P35-S611 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P35-S6112 Specifications](#)

Satellite p35 series (9 pages)

[Laptop Toshiba Satellite P30-S701TD Specifications](#)

Satellite p30 series (4 pages)

[Laptop Toshiba P300-ST3014 User Manual](#)

P300-st3014 user's guide (231 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba PSPCDC-03H00C User Manual](#)

User manual (185 pages)

[Laptop Toshiba dynabook P53 Series User Manual](#)

(129 pages)

Related Content for Toshiba P30-S6362ST

[Qosmio X300 Series Turning Off The Computer](#)

Toshiba Qosmio X300 Series

[Tecra A9 Series Turning Off The Computer](#)

Toshiba Tecra A9 Series

[Satellite 200 Series Lesson 13: Turning Your Computer Off](#)

Toshiba Satellite 200 Series

[Portégé R830 Series Turning Off The Computer](#)

Toshiba Portégé R830 Series

[SatellitePro L700 Series Turning Off The Computer](#)

Toshiba SatellitePro L700 Series

[Satellite Pro 4600 Series Turning Off The Computer](#)

Toshiba Satellite Pro 4600 Series

[Satellite 110 Series Lesson 13: Turning Your Computer Off](#)

Toshiba Satellite 110 Series

[Satellite R10 Turning Off The Computer](#)

Toshiba Satellite R10

This manual is also suitable for:

[P30-s6363stP30-s701tdP35-s605P35-s6051P35-s6052P35-s6053](#) ... [Show all](#)