



# Chapter 5: Toshiba Utilities - Toshiba P100-ST1072 User Manual

P100-st1072 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
Table Of Contents  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67


68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237



•

[Table of Contents](#)

•

## Bookmarks





# Chapter 5

## Toshiba Utilities

Your computer includes several utilities designed to help you to reconfigure your system to best meet your individual needs. Together, these allow you to ascertain certain system details, set

additional options, or change default options. These utilities are described in this chapter.



TOSHIBA Assist



Supervisor password



User password



TOSHIBA PC Diagnostic Tool Utility



TOSHIBA SD™ Memory Card Format Utility



Mouse Utility



Toshiba Hardware Setup



TOSHIBA Zooming Utility



TOSHIBA Button Support



CD/DVD Drive Acoustic Silencer



## TOSHIBA Accessibility



### Fingerprint Authentication Utility



### ConfigFree™

**136**

Table of Contents



[Previous Page](#)  
[Next Page](#)

1

...

135

136

137

138

## Related Manuals for Toshiba P100-ST1072

### [Laptop Toshiba Satellite P100-ST1072 Series Specifications](#)

Toshiba satellite p100-st1072: specifications (8 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

### [Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

### [Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

### [Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

### [Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

### [Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

### [Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

### [Laptop Toshiba Satellite P105-S6157 Specifications](#)

Toshiba satellite p105-s6157: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6177 Specifications](#)

Toshiba satellite p105-s6177: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6197 Specifications](#)

Toshiba satellite p105-s6197: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6207 Specifications](#)

Toshiba satellite p105-s6207: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6217 Specifications](#)

Toshiba satellite p105-s6217: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6227 Specifications](#)

Toshiba satellite p105-s6227: specifications (11 pages)

### [Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

## Related Content for Toshiba P100-ST1072

### [TECRA M4 Method 1: Changing The Screen Orientation Using Toshiba Accelerometer Utilities](#)

Toshiba TECRA M4

### [TE2000 Restoring Toshiba Utilities And Drivers](#)

Toshiba TE2000

### [Tecra S3 Restoring Toshiba Utilities And Drivers](#)

Toshiba Tecra S3

### [Satellite Pro M10 Restoring Toshiba Utilities And Drivers](#)

Toshiba Satellite Pro M10

[Satellite M45 Chapter 5: Toshiba Utilities](#)

[Toshiba Satellite M45](#)

[Satellite 2670 series Restoring Toshiba Utilities And Drivers](#)

[TOSHIBA Satellite 2670 series](#)

[Portege R200 Restoring Toshiba Utilities And Drivers](#)

[TOSHIBA Portege R200](#)

[Satellite 1130 Restoring Toshiba Utilities And Drivers](#)

[TOSHIBA Satellite 1130](#)

This manual is also suitable for:

[P100-st1071P105-s6147P105-s6148P105-s6157P105-s6158P105-s6167](#) ... [Show all](#)