



# Mouse Utility - Toshiba P100-ST1072 User Manual

P100-st1072 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

Table Of Contents

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217

218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237

|  |
|--|
|  |
|--|

•


[Table of Contents](#)

•

Bookmarks

|  |
|--|
|  |
|--|





# 148

## Toshiba Utilities

---

### *Mouse Utility*

## **Mouse Utility**

The Mouse utility allows you to change your pointing device or mouse settings.

To access the Mouse utility:



1

Click Start, Control Panel, and then Mouse, or click the **Mouse icon in the Optimize tab of**

The Mouse Properties screen appears.

*(Sample Image) Mouse Properties screen*

The settings you can change are divided into these categories:



You may see additional categories depending on your particular pointing device. For information on these settings, see

[Mode Pad" on page](#)

2

Adjust the settings as desired, then click OK.

Buttons

Pointers

Pointer options


Wheel

Hardware

Device Settings

["Using the TouchPad™" on page 63](#)

**TOSHIBA**



65.  
Assist.  
and  
"Using the Dual

Table of Contents

Previous Page  
Next Page

1

...

147

148

149

150

## Related Manuals for Toshiba P100-ST1072

### [Laptop Toshiba Satellite P100-ST1072 Series Specifications](#)

Toshiba satellite p100-st1072: specifications (8 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

### [Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

### [Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

### [Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

### [Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

### [Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

### [Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

### [Laptop Toshiba Satellite P105-S6157 Specifications](#)

Toshiba satellite p105-s6157: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6177 Specifications](#)

Toshiba satellite p105-s6177: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6197 Specifications](#)

Toshiba satellite p105-s6197: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6207 Specifications](#)

Toshiba satellite p105-s6207: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6217 Specifications](#)

Toshiba satellite p105-s6217: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6227 Specifications](#)

Toshiba satellite p105-s6227: specifications (11 pages)

### [Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

## Related Content for Toshiba P100-ST1072

### [Satellite M45 Mouse Utility](#)

Toshiba Satellite M45

### [Satellite A200 Series Mouse Utility](#)

TOSHIBA Satellite A200 Series

### [X305-Q705 - Qosmio - Core 2 Duo GHz Mouse Utility](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

### [U205-S5002 - Satellite - Core Duo 1.66 GHz Mouse Utility](#)

Toshiba U205-S5002 - Satellite - Core Duo 1.66 GHz

### [P105 S6197 - Satellite - Core 2 Duo 1.6 GHz Mouse Utility](#)

[Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz](#)

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Mouse Utility](#)

[Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz](#)

[S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz Mouse Utility](#)

[Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz](#)

[R10 S4401 - Tecra - Core 2 Duo 2.26 GHz Mouse Utility](#)

[Toshiba R10 S4401 - Tecra - Core 2 Duo 2.26 GHz](#)

This manual is also suitable for:

[P100-st1071P105-s6147P105-s6148P105-s6157P105-s6158P105-s6167](#) ... [Show all](#)