

Toshiba Button Support - Toshiba P100-ST1072 User Manual

P100-st1072 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237

--

•

[Table of Contents](#)

•

Bookmarks

--



152

Toshiba Utilities

TOSHIBA Button Support

The zoom in and zoom out hot keys will now work with the applications you selected.

To zoom in, hold down the
down the

For more information about how to use the TOSHIBA Zooming



utility, right-click the
click Help.

TOSHIBA Button Support

TOSHIBA Button Support allows you to customize the Mail button.

This button is located under the display.

To access TOSHIBA Button Support:

1

Click the TOSHIBA Button Control icon in the Optimize tab
of



The TOSHIBA Button Support window appears.

(Sample Image) TOSHIBA Button Support screen

2

Click [Button name] and select the button whose function is to be customized.

3

Make the desired selections.



4

Click Close.

Fn

key and press

TOSHIBA

Assist.

key and press

Fn


1

.

icon in the Notification Area and then

; to zoom out, hold

2



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

151

152

153

154

Related Manuals for Toshiba P100-ST1072

[Laptop Toshiba Satellite P100-ST1072 Series Specifications](#)

Toshiba satellite p100-st1072: specifications (8 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P105-S6157 Specifications](#)

Toshiba satellite p105-s6157: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6177 Specifications](#)

Toshiba satellite p105-s6177: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6197 Specifications](#)

Toshiba satellite p105-s6197: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6207 Specifications](#)

Toshiba satellite p105-s6207: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6217 Specifications](#)

Toshiba satellite p105-s6217: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6227 Specifications](#)

Toshiba satellite p105-s6227: specifications (11 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

Related Content for Toshiba P100-ST1072

[Qosmio F60 Series Toshiba Button Support](#)

Toshiba Qosmio F60 Series

[Portege M780 Toshiba Button Support](#)

Toshiba Portege M780

[Satellite E200 Series Toshiba Button Support](#)

Toshiba Satellite E200 Series

[X305-Q705 - Qosmio - Core 2 Duo GHz Toshiba Button Support](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

[Satellite P770D Series Toshiba Button Support](#)

Toshiba Satellite P770D Series

[PSBY5C-03K00Q Toshiba Button Support](#)

Toshiba PSBY5C-03K00Q

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Toshiba Button Support](#)

Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz

[S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz Toshiba Button Support](#)

Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz

This manual is also suitable for:

[P100-st1071P105-s6147P105-s6148P105-s6157P105-s6158P105-s6167](#) ... [Show all](#)