



# Using External Display Devices - Toshiba P100-ST1072 User Manual

P100-st1072 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
Table Of Contents  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67


68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237



•

[Table of Contents](#)

•

## Bookmarks





## **Configuring virtual buttons**

The virtual buttons at the top of the Dual Mode Pad are pre-configured for the Email, ConfigFree, and Print functions. You can

assign different functions to these buttons if you wish.

The virtual buttons on the bottom of the Dual Mode Pad (buttons 4, 5, and 6 in the Properties for Synaptics LuxPad window) are unassigned by default. In order to use one of these buttons, you must first configure that button so that it is associated with a

function.

To configure a virtual button:

**1**

Perform steps 1-5 in

**2**

Select the virtual button you wish to configure.

**3**

Select the desired options, and then click OK.

**4**

Click OK.

**5**

Click OK to close the Mouse Properties window.

## Using external display devices

Your computer comes with a built-in display, but you can also connect an external display device to an available video port, as follows:



An external monitor or projector via the RGB (monitor) port



A TV, VCR, or DVD recorder via the S-video (TV-out) port



A projector or a monitor via the DVI video port (available on certain models)

### NOTE

Before connecting an external monitor or video projector, configure your computer for the type of device you are connecting. To do

this,  
refer to the documentation for your operating system and devices.

---

## NOTE

### *Using external display devices*

DVI stands for Digital Visual Interface, and is a standard for connecting computers to digital monitors.

Coaxial cable connection to this computer must only be used if the cable's outer conductive shielding has been grounded by the cable installer at the building premises as close to the point of cable entrance, or attachment, as practicable and the connection complies with all local cable installation requirements that are applicable in your area.

### **Getting Started**

["Enabling Dual Mode" on page](#)

# 67

66.

[Table of Contents](#)



[Previous Page](#)  
[Next Page](#)

1  
...  
64  
65  
66  
67  
68  
69  
70  
71

## Related Manuals for Toshiba P100-ST1072

### [Laptop Toshiba Satellite P100-ST1072 Series Specifications](#)

Toshiba satellite p100-st1072: specifications (8 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

### [Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

### [Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

### [Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

### [Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

### [Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

### [Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

### [Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

### [Laptop Toshiba Satellite P105-S6157 Specifications](#)

Toshiba satellite p105-s6157: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6177 Specifications](#)

Toshiba satellite p105-s6177: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6197 Specifications](#)

Toshiba satellite p105-s6197: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6207 Specifications](#)

Toshiba satellite p105-s6207: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6217 Specifications](#)

Toshiba satellite p105-s6217: specifications (11 pages)

### [Laptop Toshiba Satellite P105-S6227 Specifications](#)

Toshiba satellite p105-s6227: specifications (11 pages)

### [Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

## Related Content for Toshiba P100-ST1072

### [satellite fusion 15 series Using External Display Devices](#)

Toshiba satellite fusion 15 series

### [Satellite CL10 Series Using External Display Devices](#)

Toshiba Satellite CL10 Series

### [Portege Z20-B Series Using External Display Devices](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Using External Display Devices](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Using External Display Devices](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Using External Display Devices](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Using External Display Devices](#)

Toshiba Satellite E40-A

[Satellite A35 Series Using External Display Devices](#)

Toshiba Satellite A35 Series

This manual is also suitable for:

[P100-st1071P105-s6147P105-s6148P105-s6157P105-s6158P105-s6167 ... Show all](#)