

Using The Keyboard - Toshiba P100-ST1072 User Manual

P100-st1072 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237

--

•

[Table of Contents](#)

•

Bookmarks

--





Use Error-checking and Disk Defragmenter regularly to conserve disk space and improve performance.



Scan all new files for viruses.

This precaution is especially important for files you receive via diskette, email, or download from the Internet.



Take frequent breaks to avoid repetitive-motion injuries and eyestrain.



Do not turn off the computer if a drive indicator light indicates a drive is active.

Turning off the computer while it is reading from or writing to a disk may damage the disk, the drive, or both.



Before turning off the computer, use the Turn off computer command or Sleep command. See

[Sleep mode" on page 79](#)

NOTE

Using the keyboard

Your computer's keyboard contains character keys, control keys, function keys, and special Windows

(Sample Illustration) Keyboard

®

The Windows

operating system records information, such as your desktop setup, during its shutdown procedure. If you do not let the

®

Windows

operating system shut down normally, details such as new icon positions may be lost.

Learning the Basics

Using the keyboard

["Using and configuring](#)

to learn more about Sleep.

®

keys.



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
82
83
84
85
86
87
88
89

Related Manuals for Toshiba P100-ST1072

[Laptop Toshiba Satellite P100-ST1072 Series Specifications](#)

Toshiba satellite p100-st1072: specifications (8 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P100-ST9732 User Manual](#)

P100-st9732 user's guide (278 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P105-S6157 Specifications](#)

Toshiba satellite p105-s6157: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6177 Specifications](#)

Toshiba satellite p105-s6177: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6197 Specifications](#)

Toshiba satellite p105-s6197: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6207 Specifications](#)

Toshiba satellite p105-s6207: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6217 Specifications](#)

Toshiba satellite p105-s6217: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6227 Specifications](#)

Toshiba satellite p105-s6227: specifications (11 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

Related Content for Toshiba P100-ST1072

[Satellite Pro R50-C Series The Keyboard](#)

Toshiba Satellite Pro R50-C Series

[Satellite L40-C Series Keyboard Shortcuts](#)

Toshiba Satellite L40-C Series

[PORTEGE R35-C The Keyboard](#)

Toshiba PORTEGE R35-C

[Satellite U930 Series The Keyboard](#)

Toshiba Satellite U930 Series

[Tecra A40 C Series Keyboard Shortcuts](#)

Toshiba Tecra A40 C Series

[Satellite Radius 15 P50W-C The Keyboard](#)

Toshiba Satellite Radius 15 P50W-C

[PT930 Keyboard Indicators](#)

Toshiba PT930

[Satellite Pro R50-D Series The Keyboard](#)

Toshiba Satellite Pro R50-D Series

This manual is also suitable for:

[P100-st1071P105-s6147P105-s6148P105-s6157P105-s6158P105-s6167](#) ... [Show all](#)