

Conserving Battery Power - Toshiba P300-ST3014 User Manual

P300-st3014 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231


•

Table of Contents

-

Bookmarks

--



110

Mobile Computing

Monitoring main battery power

To change the default notification settings:

1

Click Start, Control Panel, Mobile PC, and then Power
Options.

The Power Options window appears.

2

Click Change plan settings under the power plan to be customized.

The Edit Plan Settings window appears.

3

Click Change advanced power settings.

The Advanced settings tab of the Power Options window appears.

(Sample Image) Advanced settings tab of Power Options screen

4

Click Battery to display the battery options.

5

Configure the alarm settings to suit your needs.


Conserving battery power

How long a fully charged battery pack lasts when you are using the computer depends on a number of factors, such as:

How the computer is configured

How much you use the hard disk, optical drive, diskette drives, or other optional devices

Where you are working, since operating time decreases at low temperatures



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

[1](#)

...

[109](#)

110

[111](#)

[112](#)

Quick Links:

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba P300-ST3014

[Desktop Toshiba Satellite P300 Maintenance Manual](#)

Personal computer (315 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba Satellite P305-S8838 Specifications](#)

Toshiba satellite p305-s8838: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8842 Specifications](#)

Toshiba satellite p305-s8842: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8828 Specifications](#)

Toshiba satellite p305d-s8828: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8829 Specifications](#)

Toshiba satellite p305d-s8829: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8900 Specifications](#)

Toshiba satellite p305d-s8900: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8903 Specifications](#)

Toshiba satellite p305d-s8903: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8814 Product Specifications](#)

(3 pages)

[Laptop Toshiba Satellite P305-S8822 Specifications](#)

Toshiba satellite p305-s8822: specifications (3 pages)

[Laptop Toshiba Satellite P305-S8832 Specifications](#)

Toshiba satellite p305-s8832: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8818 Specifications](#)

Toshiba satellite p305d-s8818: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8834 Specifications](#)

Toshiba satellite p305d-s8834: specifications (3 pages)

Related Content for Toshiba P300-ST3014

[Satellite Radius 15 Conserving Battery Power](#)

Toshiba Satellite Radius 15

[satellite fusion 15 series Conserving Battery Power](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Conserving Battery Power](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Conserving Battery Power](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Conserving Battery Power](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Conserving Battery Power](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Conserving Battery Power](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Conserving Battery Power](#)

Toshiba Satellite E40-A

This manual is also suitable for:

P305-s8830P305-s8832P305-s8837P305-s8838P305-s8842P305-s8844 ... [Show all](#)