

Expresscard® Problems - Toshiba P300-ST3014 User Manual

P300-st3014 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231

•

Table of Contents

-

Bookmarks

--



180

If Something Goes Wrong

Resolving a hardware conflict

The computer emits a loud, high-pitched noise.

This is feedback between the microphone and the speakers. It occurs in any sound system when input from a microphone is fed to the speakers and the speaker volume is too loud. Adjust the volume control.

ExpressCard problems

ExpressCards

hard disk, additional memory, or a pager.

Most ExpressCard problems occur during installation and setup of

new cards. If you are having trouble getting one or more of these devices to work together, several sections in this chapter may apply.

Resource conflicts can cause problems when using ExpressCards.

See

["Resolving a hardware conflict" on page](#)

If your system does not have built-in drivers for your ExpressCard

and the card did not come with an operating system driver, it may not work under the operating system. Contact the manufacturer of

the ExpressCard for information about using the card under the operating system.

ExpressCard

Make sure the card is inserted properly into the slot.

Make sure all cables are securely connected.

Occasionally a defective ExpressCard

control. If another computer with a ExpressCard slot is available, try the card in that machine. If the card malfunctions again, it may be defective.

Resolving ExpressCard

Here are some common problems and their solutions:

The slot appears to be dead. ExpressCards

no longer work.

Check the ExpressCard

1

Click Start, Control Panel, System and Maintenance, and then Device Manager.

®

include many types of devices, such as a removable

®

checklist

®

problems

®

status:

170.

®

slips through quality

®

that used to work

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

179

180

181

182

Quick Links:

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba P300-ST3014

[Desktop Toshiba Satellite P300 Maintenance Manual](#)

Personal computer (315 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba Satellite P305-S8838 Specifications](#)

Toshiba satellite p305-s8838: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8842 Specifications](#)

Toshiba satellite p305-s8842: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8828 Specifications](#)

Toshiba satellite p305d-s8828: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8829 Specifications](#)

Toshiba satellite p305d-s8829: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8900 Specifications](#)

Toshiba satellite p305d-s8900: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8903 Specifications](#)

Toshiba satellite p305d-s8903: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8814 Product Specifications](#)

(3 pages)

[Laptop Toshiba Satellite P305-S8822 Specifications](#)

Toshiba satellite p305-s8822: specifications (3 pages)

[Laptop Toshiba Satellite P305-S8832 Specifications](#)

Toshiba satellite p305-s8832: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8818 Specifications](#)

Toshiba satellite p305d-s8818: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8834 Specifications](#)

Toshiba satellite p305d-s8834: specifications (3 pages)

Related Content for Toshiba P300-ST3014

[Portege R930-Landis-PT331U-023002 Expresscard ® Problems](#)

Toshiba Portege R930-Landis-PT331U-023002

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Expresscard ® Problems](#)

Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz

[R10 S4401 - Tecra - Core 2 Duo 2.26 GHz Expresscard ® Problems](#)

Toshiba R10 S4401 - Tecra - Core 2 Duo 2.26 GHz

[R950-S9520 Expresscard ® Problems](#)

Toshiba R950-S9520

[L45-S7423 - Satellite - Pentium Dual Core 1.46 GHz Expresscard™ Problems](#)

Toshiba L45-S7423 - Satellite - Pentium Dual Core 1.46 GHz

[R950-BT9500 Expresscard ® Problems](#)

Toshiba R950-BT9500

[ORACLER940 Expresscard ® Problems](#)

Toshiba ORACLER940

[R930-BT9300 Expresscard ® Problems](#)

Toshiba R930-BT9300

This manual is also suitable for:

P305-s8830P305-s8832P305-s8837P305-s8838P305-s8842P305-s8844 ... [Show all](#)