

Directing The Display Output When You Turn On The Computer - Toshiba P300-ST3014 User Manual

P300-st3014 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

Table Of Contents

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231


•

Table of Contents

-

Bookmarks

--



NOTE

Connecting to a TV using HDMI™-CEC

(Available on certain models)

HDMI™-CEC (Consumer Electronics Control) is a standard in the

CE Industry which allows devices to work together over an HDMI cable. Toshiba computers with HDMI-CEC include a Toshiba utility (that may need to be installed) dedicated to take advantage of

its capabilities which can allow you to:

Use the TV remote control to output the computer screen onto the TV screen.

Use the TV remote control to launch, operate and close applications on your computer.

Turn on the TV when the HDMI output is selected using the Fn+F5

Switch the video output (HDMI or LCD) when executing certain desktop icons.

Enable/Disable the HDMI-CEC function on the computer.

For more detailed HDMI-CEC information visit pcsupport.toshiba.com.

Directing the display output when you turn on the computer

Once you have connected an external display device, you can choose to use the internal display only, the external device only, or both simultaneously.

NOTE

The quickest way to change the display output settings is to use the display hot key (

1

While holding down

you want takes effect. Briefly pause each time you press the key to allow time for the display to change.

Using external display devices

In the future you can change the display settings by pressing or by configuring the display properties settings.

key.

Some modes are only available with the appropriate device attached and turned on.

+

):

Fn

F5

Getting Started

, press

repeatedly until the setting

Fn

F5

71

,

Fn+F5

F5

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

[1](#)
[...](#)
[68](#)
[69](#)
[70](#)
[71](#)
[72](#)
[73](#)
[74](#)
[75](#)

Quick Links:

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba P300-ST3014

[Desktop Toshiba Satellite P300 Maintenance Manual](#)

Personal computer (315 pages)

[Laptop Toshiba Satellite A305-S6839 User Manual](#)

Portable personal computer (226 pages)

[Laptop Toshiba SATELLITE P300 User Manual](#)

Portable personal computer (208 pages)

[Laptop Toshiba P300 User Manual](#)

Notebook computer (199 pages)

[Laptop Toshiba Satellite P300-0E2028 Resource Manual](#)

Toshiba satellite p300-0e2028: reference guide (52 pages)

[Laptop Toshiba Satellite P305-S8838 Specifications](#)

Toshiba satellite p305-s8838: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8842 Specifications](#)

Toshiba satellite p305-s8842: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8828 Specifications](#)

Toshiba satellite p305d-s8828: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8829 Specifications](#)

Toshiba satellite p305d-s8829: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8900 Specifications](#)

Toshiba satellite p305d-s8900: specifications (4 pages)

[Laptop Toshiba Satellite P305D-S8903 Specifications](#)

Toshiba satellite p305d-s8903: specifications (4 pages)

[Laptop Toshiba Satellite P305-S8814 Product Specifications](#)

(3 pages)

[Laptop Toshiba Satellite P305-S8822 Specifications](#)

Toshiba satellite p305-s8822: specifications (3 pages)

[Laptop Toshiba Satellite P305-S8832 Specifications](#)

Toshiba satellite p305-s8832: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8818 Specifications](#)

Toshiba satellite p305d-s8818: specifications (3 pages)

[Laptop Toshiba Satellite P305D-S8834 Specifications](#)

Toshiba satellite p305d-s8834: specifications (3 pages)

Related Content for Toshiba P300-ST3014

[Satellite CL10 Series Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite CL10 Series

[Satellite S70-B Series Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite S70-B Series

[Satellite CL40 Series Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite E40-A

[Satellite A35 Series Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite A35 Series

[C50 Series Directing The Display Output When You Turn On The Computer](#)

Toshiba C50 Series

[Qosmio X70-A series Directing The Display Output When You Turn On The Computer](#)

Toshiba Qosmio X70-A series

[Satellite L40 series Directing The Display Output When You Turn On The Computer](#)

Toshiba Satellite L40 series

This manual is also suitable for:

P305-s8830P305-s8832P305-s8837P305-s8838P305-s8842P305-s8844 ... [Show all](#)