

Configfree; Getting Started - Toshiba P500-ST5801 User Manual

P500-st5801 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18


19
20
21
22
23
24
25
26
27
28
29
Table Of Contents
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254



•

[Table of Contents](#)

•

Bookmarks



180

Utilities

ConfigFree®

®

ConfigFree

NOTE

ConfigFree

communication devices and network connections. ConfigFree also lets you identify communication problems and create profiles for easy switching between locations and communication networks.

NOTE

The ConfigFree utilities include the following:

Connectivity Doctor—The Connectivity Doctor utility is used to analyze network connections and fix networking problems with your computer. For more information, see

["Doctor" on page](#)

Profile Settings—The Profiles utility lets you switch between network configurations. For more information, see

["Settings" on page](#)

Getting Started

This section contains information about the ConfigFree screen, and how to start and set up ConfigFree.

For more detailed information on setting up and using ConfigFree,

see the Help File included in the application.

Starting ConfigFree

To start ConfigFree connection. Then perform any of the following steps:

Click Start, All Programs, Toshiba, and then ConfigFree.

Double-click the ConfigFree icon

Press the TOSHIBA Assist button (if applicable to your system) to open the TOSHIBA Assist, and then click the ConfigFree icon.

Click the ConfigFree icon then click the desired utility.

All references to Bluetooth

Bluetooth

is available on your system.

®

®

is a set of utilities that makes it easy to control

For more information on using ConfigFree, see the ConfigFree
online Help.

181.

182.

®

®

, be sure the computer has a wired or wireless

®

in this section are applicable only if
in the Notification Area.

in the Notification Area, and

["Connectivity](#)

["Profile](#)

®

main

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

179

180

181

182

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba P500-ST5801

[Laptop Toshiba Satellite P500 Maintenance Manual](#)

Personal computer (288 pages)

[Laptop Toshiba Satellite P500 Maintenance Manual](#)

(288 pages)

[Laptop Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz User Manual](#)

User's guide for satellite p500/p505 series (253 pages)

[Laptop Toshiba M500-ST54E2 User Manual](#)

M500-st54e2 user's guide (252 pages)

[Laptop Toshiba Satellite P500 User Manual](#)

(227 pages)

[Laptop Toshiba Satellite P500 User Manual](#)

Portable personal computer (223 pages)

[Laptop Toshiba Satellite P500-BT2G22 User Manual](#)

Portable personal computer (213 pages)

[Laptop Toshiba Satellite P5001 User Manual](#)

(208 pages)

[Laptop TOSHIBA Satellite P500 User Manual](#)

Portable personal computer (208 pages)

[Laptop TOSHIBA P500 User Manual](#)

Portable personal computer (202 pages)

[Laptop Toshiba Satellite P500-BT2G22 Resource Manual](#)

Toshiba satellite p500-bt2g22: reference guide (60 pages)

[Laptop Toshiba Satellite P505D-S8935 Specifications](#)

Toshiba satellite p505d-s8935: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8940 Specifications](#)

Toshiba satellite p505-s8940: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8945 Specifications](#)

Toshiba satellite p505-s8945: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8950 Specifications](#)

Toshiba satellite p505-s8950: specifications (4 pages)

[Laptop Toshiba Satellite P500-ST68X2 Specifications](#)

Toshiba satellite p500-st68x2: specifications (4 pages)

Related Content for Toshiba P500-ST5801

[Satellite M45 Appendix C: Using Configfree™ With Your Toshiba Computer](#)

Toshiba Satellite M45

[Satellite A200 Series Configfree](#)

TOSHIBA Satellite A200 Series

[T115 S1100 - Satellite - Celeron 1.3 GHz Configfree](#)

Toshiba T115 S1100 - Satellite - Celeron 1.3 GHz

[Satellite A40-S200 Pantalla Principal De Configfree](#)

Toshiba Satellite A40-S200

[Portege R600-SP2803C Configfree](#)

Toshiba Portege R600-SP2803C

[X305-Q705 - Qosmio - Core 2 Duo GHz Configfree](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

[U205-S5002 - Satellite - Core Duo 1.66 GHz Appendix C: Using Configfree™ With Your Toshiba Computer](#)

Toshiba U205-S5002 - Satellite - Core Duo 1.66 GHz

[Satellite M100-ST5211 Configfree](#)

This manual is also suitable for:

[P500-st6821P505-s8940P505-s8941P505-s8945P505-s8946P505-s8950 ... Show all](#)