



# Adding Optional External Devices; Adding Memory (Optional) - Toshiba P500-ST5801 User Manual

P500-st5801 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

Table Of Contents

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217

218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254

|  |
|--|
|  |
|--|

•

[Table of Contents](#)

•

Bookmarks

|  |
|--|
|  |
|--|





## Adding optional external devices

### NOTE

After starting your computer for the first time you may want to:

Add more memory (see

[page](#)

Connect a mouse (see

Connect a full-size keyboard (see

[keyboard" on page](#)

Connect an external monitor (see [devices" on page](#)

Connect a local printer (see

Install an ExpressCard  
[page](#)

## **Adding memory (optional)**

Your computer comes with enough memory to run most of today's popular applications. You may want to increase the computer's memory if you use complex software or process large amounts of data.

### **NOTE**

#### *Adding optional external devices*

Before adding external devices or memory, Toshiba recommends setting up your software. See

53)

80)

77)

142)

HINT: To purchase additional memory modules, see the accessories information packaged with your system or visit [accessories.toshiba.com](http://accessories.toshiba.com).

Before adding external devices or memory, Toshiba recommends setting up your software. See

### **Getting Started**

"Setting up your software" on page

"Adding memory (optional)" on

"Using a mouse" on page

"Using an external

"Using external display

"Connecting a printer" on page

®

(see

"Using an ExpressCard

"Setting up your software" on page

53

52.

80)

81)

®

" on

52.



Table of Contents

[Previous Page](#)  
[Next Page](#)

1  
...  
50  
51  
52  
53  
54  
55  
56  
57

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

## Related Manuals for Toshiba P500-ST5801

[Laptop Toshiba Satellite P500 Maintenance Manual](#)

Personal computer (288 pages)

[Laptop Toshiba Satellite P500 Maintenance Manual](#)

(288 pages)

[Laptop Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz User Manual](#)

User's guide for satellite p500/p505 series (253 pages)

[Laptop Toshiba M500-ST54E2 User Manual](#)

M500-st54e2 user's guide (252 pages)

[Laptop Toshiba Satellite P500 User Manual](#)

(227 pages)

[Laptop Toshiba Satellite P500 User Manual](#)

Portable personal computer (223 pages)

[Laptop Toshiba Satellite P500-BT2G22 User Manual](#)

Portable personal computer (213 pages)

[Laptop Toshiba Satellite P5001 User Manual](#)

(208 pages)

[Laptop TOSHIBA Satellite P500 User Manual](#)

Portable personal computer (208 pages)

[Laptop TOSHIBA P500 User Manual](#)

Portable personal computer (202 pages)

[Laptop Toshiba Satellite P500-BT2G22 Resource Manual](#)

Toshiba satellite p500-bt2g22: reference guide (60 pages)

[Laptop Toshiba Satellite P505D-S8935 Specifications](#)

Toshiba satellite p505d-s8935: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8940 Specifications](#)

Toshiba satellite p505-s8940: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8945 Specifications](#)

Toshiba satellite p505-s8945: specifications (4 pages)

[Laptop Toshiba Satellite P505-S8950 Specifications](#)

Toshiba satellite p505-s8950: specifications (4 pages)

[Laptop Toshiba Satellite P500-ST68X2 Specifications](#)

Toshiba satellite p500-st68x2: specifications (4 pages)

## Related Content for Toshiba P500-ST5801

[Satellite Radius 15 Adding Optional External Devices](#)

Toshiba Satellite Radius 15

[satellite fusion 15 series Adding Optional External Devices](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Adding Optional External Devices](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Adding Optional External Devices](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Adding Optional External Devices](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Adding Optional External Devices](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Adding Optional External Devices](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Adding Optional External Devices](#)

Toshiba Satellite E40-A

This manual is also suitable for:

P500-st6821P505-s8940P505-s8941P505-s8945P505-s8946P505-s8950 ... [Show all](#)