



Asus R300 Quick Start Manual

Information about navigation map usage

1
2
3
4

--


•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [User Manual](#), [Quick Start Manual](#)



Navigation Map



for R300/R600/R700

e3701_pnd map data card.indd 1

ManualsLib.com



E3701

2008.3.20 9:33:00 AM

ASUS[®]
Rock Solid · Heart Touching



[Next Page](#)

1
2
3
4

Related Manuals for Asus R300

[GPS Asus R300 User Manual](#)

Portable navigation device (192 pages)

[GPS Asus R300 User Manual](#)

Portable navigation device (89 pages)

[GPS Asus R300 User Manual](#)

Asus r300 english user manual (72 pages)

[GPS Asus R300 Quick Start Manual](#)

Asus pnd r300 qsg in english version (17 pages)

[GPS Asus R600 User Manual](#)

Portable navigation device (109 pages)

[GPS Asus R700 Quick Start Manual](#)

Asus r700: quick start (16 pages)

[GPS Asus R700 User Manual](#)

User manual (10 pages)

[GPS Asus R600 Quick Start Manual](#)

Portable navigation device (10 pages)

[GPS Asus GPS-BT100 Quick Start Manual](#)

Asus gps-bt100 gps receiver with bluetooth quick start guide (11 pages)

[GPS Asus S102 - Automotive GPS Receiver User Manual](#)

Automotive gps receiver (51 pages)

[GPS Asus PATHFINDER Quick Start Manual](#)

(16 pages)

Summary of Contents for Asus R300

[Page 1: Navigation Map](#)

Navigation Map for R300/R600/R700 e3701_pnd map data card.indd 1 Quick Start Guide Quick Start Guide E3701 2008.3.20 9:33:00 AM...

[Page 2: Using The Navigation Map](#)

Using the Navigation Map R300 Insert the microSD card into the microSD card slot () on top of the device when the device is either turned off or in sleep mode. Switch the power ON () to turn on the device, or press the sleep mode button () to wake up the device. From the main screen, tap Navigation and follow the screen instructions. Note If you turn on or wake up the device without inserting the microSD card into the microSD card slot, when tap Navigation from the main screen, a warning message appears: "Operation failed! Insert the SD card or remove USB and try again".

[Page 3](#) Using the Navigation Map R600 Insert the microSD card into the adapter. Insert the adapter with the microSD card into the SD card slot () on the right side of the device when the device is switched off or when the device is in sleep mode. Switch the power ON () to turn on the device, or press the sleep mode button () to wake up the device. From the main screen, tap Navigation and follow the screen instructions. Note If you turn on or wake up the device without inserting the microSD card into the card slot, when tap Navigation from the main menu, a "Map initialisation error" message appears: couldn't find any map files!.

[Page 4](#) Using the Navigation Map R700 Insert the microSD card into the microSD card slot () on the left side of the device. Note You can insert the microSD card into the device when it is in

sleep mode or is switched off. Note If you insert the microSD card when the device is in sleep mode, press the Sleep Mode Button (a few seconds until the main menu appears, then tap Navigation to proceed.

This manual is also suitable for:

R700R600