



Asus Eee Keyboard & Mouse Kit Manual

1
2

--

•

Bookmarks

--

[Download this manual](#)

Quick Links



Eee Keyboard & Mouse Kit



Installing the batteries

1. Insert the batteries (two AAA batteries for keyboard and two AA batteries for mouse) into the battery slots of your keyboard and mouse.

2. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

Your keyboard and mouse is set at the factory to automatically connect to your computer. To manually connect, press the Connect button on the bottom of the keyboard and mouse.

Keyboard hotkeys and function keys

Windows 2000 / XP / Vista / 7 support the Eee Keyboard and Mouse functions.

Hotkeys

1. Caps Lock key
5. Wi-Fi Track
3. Start key
2. Number Lock key 6. Play / Pause
10. Function key
3. Scroll Lock key
7. Previous Track
4. Stop
8. Menu launcher

Function keys

- <Fn + F1>: Sleep mode
- <Fn + F2>: Brightness up
- <Fn + F3>: Brightness down
- <Fn + F4>: Wi-Fi on/off
- <Fn + F5>: LCD on/off
- <Fn + F6>: Volume up
- <Fn + F7>: Volume down
- <Fn + F8>: Mute

Keyboard and mouse

After installing the driver

Caps Lock icon: Turns green when on

Num Lock icon: Turns green when on

Scroll Lock: Turns green when on

Keyboard battery indicator: Turns green when the batteries are getting weak and should be replaced

Mouse battery indicator: Turns green when the battery is getting weak and should be replaced

A

1. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.
2. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

B

Windows 2000 / XP / Vista / 7 support the Eee Keyboard and Mouse functions.

Hotkeys

1. Caps Lock

4. Wi-Fi Track

2. Start key

5. Number Lock key 6. Play / Pause

10. Function key

3. Scroll Lock key

7. Previous Track

4. Stop

8. Menu launcher

• <Fn + F1>: Sleep mode

• <Fn + F2>: Brightness up

• <Fn + F3>: Brightness down

• <Fn + F4>: Wi-Fi on/off

• <Fn + F5>: LCD on/off

• <Fn + F6>: Volume up

• <Fn + F7>: Volume down

• <Fn + F8>: Mute

C

After installing the driver

Caps Lock icon: Turns green when on

Num Lock icon: Turns green when on

Scroll Lock: Turns green when on

Keyboard battery indicator: Turns green when the batteries are getting weak and should be replaced

Mouse battery indicator: Turns green when the battery is getting weak and should be replaced

A

1. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

2. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

B

Windows 2000 / XP / Vista / 7 support the Eee Keyboard and Mouse functions.

Hotkeys

1. Caps Lock

4. Wi-Fi Track

2. Start key

5. Number Lock key 6. Play / Pause

10. Function key

3. Scroll Lock key

7. Previous Track

4. Stop

8. Menu launcher

• <Fn + F1>: Sleep mode

• <Fn + F2>: Brightness up

• <Fn + F3>: Brightness down

• <Fn + F4>: Wi-Fi on/off

• <Fn + F5>: LCD on/off

• <Fn + F6>: Volume up

• <Fn + F7>: Volume down

• <Fn + F8>: Mute

C

After installing the driver

Caps Lock icon: Turns green when on

Num Lock icon: Turns green when on

Scroll Lock: Turns green when on

Keyboard battery indicator: Turns green when the batteries are getting weak and should be replaced

Mouse battery indicator: Turns green when the battery is getting weak and should be replaced

A

1. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

2. Insert the bundled USB dongle into your computer's USB port. It takes about ten seconds for the system to automatically connect to your wireless keyboard and mouse.

B

Windows 2000 / XP / Vista / 7 support the Eee Keyboard and Mouse functions.

Hotkeys

1. Caps Lock

4. Wi-Fi Track

2. Start key

5. Number Lock key 6. Play / Pause

10. Function key

3. Scroll Lock key

7. Previous Track

4. Stop

8. Menu launcher

• <Fn + F1>: Sleep mode

• <Fn + F2>: Brightness up

• <Fn + F3>: Brightness down

• <Fn + F4>: Wi-Fi on/off

• <Fn + F5>: LCD on/off

• <Fn + F6>: Volume up

• <Fn + F7>: Volume down

• <Fn + F8>: Mute



7. ASUS

10. ASUS

8. ASUS

9. ASUS

<Fn + F2> [Wi-Fi ON/OFF] <Fn + F5> [ASUS]

<Fn + F6> [ASUS]

<Fn + F11> [ASUS]

<Fn + F12> [ASUS]

ASUS

A

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

ASUS

A6300 / First Edition / Dec. 2010

Blank area for notes or diagrams.

Blank area for notes or diagrams.

Blank area for notes or diagrams.

메모리 열기

키보드 닫기

단축키

기능키

<Fn + F1>

<Fn + F2>

키보드 닫기

[Next Page](#)

1
2

Related Manuals for Asus Eee Keyboard & Mouse Kit

[Desktop Asus Eee Box User Manual](#)

(32 pages)

